Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Steelite EDG010

STEELITE 21V Cordless Electric Leaf Blower Instruction Manual

Model: EDG010

INTRODUCTION

Thank you for choosing the STEELITE 21V Cordless Electric Leaf Blower, Model EDG010. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new leaf blower. Please read this manual thoroughly before first use and retain it for future reference.



Image: The STEELITE 21V Cordless Electric Leaf Blower, including the main unit, two 4.0Ah batteries, and a charger, packaged in its retail box.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury. Read all instructions before using this product.

- Wear appropriate personal protective equipment (PPE) such as safety glasses, hearing protection, and gloves.
- Keep children and bystanders away while operating the leaf blower.
- Do not operate the blower in wet conditions or rain.
- Ensure the battery is fully charged before use and remove it when not in use or during maintenance.
- Inspect the blower for any damage before each use. Do not operate if damaged.
- Use only STEELITE approved batteries and chargers.

Package Contents

Verify that all items are present in the package:

- STEELITE Cordless Electric Leaf Blower Unit
- 4.0Ah Lithium-Ion Battery (x2)
- Battery Charger
- Extension Nozzle
- Instruction Manual (this document)

Assembly and Setup

1. Attaching the Blower Tube

1. Align the extension nozzle with the blower outlet.
2. Push the nozzle onto the blower outlet until it clicks into place, ensuring it is securely fastened.



Image: A diagram illustrating the quick-release blower tube assembly and identifying key components: Battery Case, Stepless Speed Control, and Turbo button.

2. Charging the Battery

1. Insert the 4.0Ah battery into the charger.
2. Plug the charger into a standard electrical outlet.
3. The indicator light on the charger will show the charging status. A full charge typically takes approximately 60 minutes per battery.
4. Once fully charged, remove the battery from the charger.



Image: A close-up of the STEELITE 20V 4.0Ah battery, highlighting its 4-LED battery indicator and built-in protections such as overcharge, low voltage, overheat, and short circuit protection.

3. Installing the Battery

1. Ensure the leaf blower is turned off.
2. Slide the charged battery into the battery case on the blower until it locks securely into place.

Operating Instructions

1. Starting and Stopping

- To start: Press and hold the power trigger.
- To stop: Release the power trigger.

2. Variable Speed Control

The leaf blower features a variable-speed trigger. Press the trigger lightly for lower airflow and press it further for increased airflow, up to 120 MPH and 480 CFM.



Image: A transparent view of the leaf blower's internal motor, illustrating the variable speed control mechanism and indicating airflow capabilities of 400 CFM / 480 CFM and speeds of 120 MPH / 150 MPH.

3. Turbo Boost Function

For maximum power, press the Turbo button located on the handle. This will temporarily increase the airflow to its highest setting (up to 150 MPH).

4. General Operation Tips

- Hold the blower firmly with one hand using the ergonomic handle.
- Sweep from side to side to move debris effectively.
- For stubborn or wet debris, use the Turbo Boost function.
- The blower is suitable for clearing leaves, dust, light snow, and grass clippings from various surfaces.



Image: A user operating the STEELITE cordless leaf blower on a paved path, demonstrating its lightweight design (approximately 3.9 lbs) for effortless operation while clearing leaves.




Image: A collage of four images demonstrating the versatility of the leaf blower for various cleaning tasks, including blowing dust, clearing light snow, moving dry leaves, and tidying up grass clippings.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your leaf blower.

- **Cleaning:** After each use, wipe down the exterior of the blower with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure air vents are clear of debris.
- **Battery Care:** Store batteries in a cool, dry place away from direct sunlight. Do not store fully discharged batteries for extended periods. Charge them periodically if not in use.
- **Storage:** When not in use, store the leaf blower in a dry, secure location out of reach of children. Remove the battery before storage.

Troubleshooting

Problem	Possible Cause	Solution
Blower does not start.	Battery not inserted correctly. Battery is discharged.	Ensure battery is fully seated. Charge the battery.
Reduced airflow.	Air intake or nozzle blocked. Battery low.	Clear any obstructions from the air intake or nozzle. Charge the battery.
Blower stops unexpectedly.	Battery overheated or discharged. Overload protection activated.	Allow battery to cool down and recharge. Reduce load on the blower.

Specifications

Feature	Detail
Brand	Steelite
Model Name	EDG010
Power Source	Battery Powered
Voltage	21 Volts (Max), 20 Volts (Nominal)
Battery Type	Lithium-Ion
Battery Capacity	2 x 4.0Ah
Air Flow Capacity	Up to 480 CFM
Maximum Air Speed	Up to 150 MPH
Noise Level	78 dB
Item Weight	2.27 kg (4.99 lbs)
Product Dimensions	7"L x 10"W x 16"H
Material	Aluminum, Copper
Special Features	Adjustable Speed, Adjustable Tube Length, Compact Design, Lightweight, Overload Protection

Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please refer to the official STEELITE website or contact their customer service department. Contact details are typically provided on the product packaging or on the manufacturer's official website.

© 2025 STEELITE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4LTCL4K

More documents and user manuals: **https://manuals.plus/**