

[Manuals.plus](#) /

› [Alvantor](#) /

› [Alvantor Pop Up Playpen Instruction Manual - Model B0D4M12VDV](#)

Alvantor B0D4M12VDV

Alvantor Pop Up Playpen Instruction Manual

Model: B0D4M12VDV

1. SAFETY INFORMATION

Please read and understand all instructions before assembling and using the Alvantor Pop Up Playpen. Failure to follow these instructions may result in serious injury or death.

- Always supervise children when they are in the playpen.
- Ensure the playpen is fully assembled and all locking mechanisms are secure before placing a child inside.
- Do not leave children unattended.
- Keep all small parts and packaging materials away from children to prevent choking hazards.
- Do not modify the product in any way. Use only original Alvantor parts.
- Avoid placing the playpen near open flames, heaters, or other heat sources.
- Do not use the playpen if any parts are damaged or missing. Contact customer support for replacement parts.
- The playpen is designed for children aged 36 months to 5 years.

2. PACKAGE CONTENTS

Verify that all components are present before assembly:

- 1 x Alvantor Pop Up Playpen
- 1 x Removable Fabric Top Cover (UV SPF 50+)
- 1 x Carry Bag

3. SETUP INSTRUCTIONS

The Alvantor Pop Up Playpen features a patented hub construction for quick and easy setup.

1. **Unpack the Playpen:** Remove the playpen from its carry bag. It will be in a folded, compact state.
2. **Lay Flat:** Lay the playpen flat on a clean, level surface with the central hub upright.
3. **Lift and Expand:** Gently lift the playpen from the top. The fiberglass frame will begin to expand automatically.
4. **Secure the Hub:** Push the lower central hub down firmly until it clicks into place, securing the entire frame.
5. **Attach Top Cover (Optional):** If outdoor use requires sun protection, attach the removable fabric top cover. Align the cover with the top of the playpen and secure it using the integrated fasteners.



Figure 3.1: Visual guide for quick playpen setup.

For a visual demonstration of the setup process, please watch the video below:

Video 3.1: Demonstration of the Alvantor Pop Up Playpen setup.

4. OPERATING THE PLAYPEN

4.1 Entry and Exit

The playpen features a zipped U-door for easy entry and exit. Ensure the zipper is fully closed when a child is inside to prevent unsupervised exit.

4.2 Ventilation and Visibility

The playpen is designed with a fully mesh body, including the top part, to provide excellent air ventilation and allow for convenient adult supervision. This mesh also offers protection from mosquitoes and other insects.

SET UP IN SECONDS



1. Lay the tent flat with hub upright.



2. Lift up the tent.



3. Push the lower hub down to click fix the whole frame.

Figure 4.1: Playpen with breathable mesh design for visibility and ventilation.

Alvantor Sandwich Style Floor, Soft & Padded Mat



Figure 4.2: Upgraded design with enclosed top mesh for enhanced protection.

4.3 Sun Protection

The removable fabric top cover provides UV SPF 50+ sun protection, making the playpen suitable for outdoor use. Attach it as described in the setup section when sun exposure is a concern.

Protective Design, Safe for Your Kids

- **Extra foam**
Prevented clamps the hand
- **Protective cover**
around the frame joints
- **lock on zipper**
kids won't open door
and crawl in & out by
themselves easily



Figure 4.3: Playpen with UV SPF 50+ sunshade for outdoor protection.

4.4 Comfort and Safety Features

The playpen includes an extra sandwich-style floor with soft foam for comfort and insulation from ground elements. Protective covers around frame joints and additional foam around poles enhance safety.



Figure 4.4: Key protective design elements for child safety.



Figure 4.5: Soft and padded mat for enhanced comfort.

5. FOLDING AND STORAGE

To fold the playpen for storage or transport:

1. **Remove Top Cover:** If attached, detach the fabric top cover.
2. **Release Hub:** Gently pull the central hub upwards to release the locking mechanism.
3. **Collapse Frame:** Allow the frame to collapse inward. Guide the sides to fold neatly.
4. **Secure for Storage:** Once collapsed, the playpen can be secured with the integrated straps or placed directly into the provided carry bag.

6. MAINTENANCE AND CARE

To ensure the longevity and hygiene of your Alvantor Pop Up Playpen:

- **Cleaning:** The soft fabric floor and mesh sides can be spot cleaned with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Allow all parts to air dry completely before folding and storing to prevent mold and mildew.
- **Storage:** Store the playpen in its carry bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect the playpen for any signs of wear, tear, or damage to the fabric, mesh, or frame.

7. TROUBLESHOOTING

If you encounter any issues with your playpen, refer to the following common solutions:

- **Playpen not expanding fully:** Ensure the central hub is pulled up completely before pushing it down to lock. Check for any fabric caught in the frame.
- **Difficulty folding:** Make sure the central hub is fully released before attempting to collapse the frame. Gently guide the frame sections.
- **Tears in mesh or fabric:** Discontinue use immediately. Contact Alvantor customer support for repair or replacement options.

8. SPECIFICATIONS

Feature	Detail
Model Number	B0D4M12VDV
Brand	Alvantor
Product Dimensions (L x W x H)	1008 x 1008 x 44 inches (approx. 7'x7'x44"H)
Item Weight	8 pounds
Folded Size (L x W x H)	12 x 12 x 4 inches
Material	Polyester
Color	Pink
Recommended Age	36 months - 5 years
UV Protection	SPF UV 50+ (with top cover)
Floor Area	35 Square Feet

9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please contact Alvantor directly through their official website or the retailer where the product was purchased. Keep your proof of purchase for warranty claims.

