

SZLWSM A6

SZLWSM A6 Pro Wireless Earbuds Instruction Manual

MODEL: A6

1. Introduction and Overview

Thank you for choosing the SZLWSM A6 Pro Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features for convenience and durability. Featuring Bluetooth 5.3 technology, IPX7 waterproofing, and Environmental Noise Cancellation (ENC) microphones, they are suitable for various activities, from daily commutes to sports workouts. The earbuds are equipped with graphene composite speakers and 14.2mm dynamic coils for clear and rich sound. The compact charging case offers extended battery life and includes a detachable hanging rope for portability.

2. What's in the Box

- Wireless Earbuds (x2)
- Wireless Charging Case (x1)
- USB Charging Cable (x1)
- User Manual (x1)
- Hanging Rope (x1)

3. Product Features

- **Bluetooth 5.3:** Ensures higher data rates, lower power consumption, and more stable connections. Supports HID, HFP, A2DP, and AVRCP profiles.
- **High Fidelity Sound:** Graphene composite speakers and 14.2mm dynamic coils deliver clear and realistic sound quality with enhanced bass.
- **Dual ENC Microphones:** Provides clear calls by reducing environmental noise.

- **IPX7 Waterproof:** Protects against sweat and light rain, ideal for sports and outdoor activities.
- **Touch One-Button Operation:** Intuitive controls for various functions.
- **Voice Assistant Compatibility:** Easily activate your device's voice assistant.
- **Extended Battery Life:** Up to 6-8 hours of continuous playback per charge, with the charging case extending total listening time to 50 hours.
- **Energy-Saving Chip:** Features the JL6983 chip for optimized power consumption.
- **Lightweight Design:** Each earbud weighs approximately 3.5g for comfortable wear.
- **Portable Charging Case:** Compact design with a hanging rope hole and detachable rope for easy carrying.
- **Wide Compatibility:** Seamlessly connects with iPhone, Android, tablets, laptops, and smart TVs.



Figure 1: Wide device compatibility with SZLWSM A6 Pro Wireless Earbuds.

IPX7 Waterproof Headphones



Rowing



Riding



Fitness



Jumping rope



Mountaineering



Walk



Figure 2: IPX7 waterproof rating for various activities.

ENJOY CRYSTAL-CLEAR CALLS

Hi-Fi Sound Perfected

Hi-Fi Stereo Sound and Enhanced Bass



Figure 3: Enjoy crystal-clear calls with ENC microphones.

4. Setup

4.1 Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

1. Place the earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and to a power source.
3. The indicator light on the charging case will show charging status. A full charge typically takes about 1 hour.

4.2 Pairing with Your Device

The earbuds feature a super simple pairing process.

1. First Use:

- Take both Bluetooth earbuds out of the charging case. They will automatically enter pairing mode.
- On your smartphone or other Bluetooth-enabled device, open the Bluetooth settings menu.
- Search for available devices and select "A6 Pro" from the list.

- Confirm pairing when prompted.

2. Subsequent Use:

- Once successfully paired, the earbuds will automatically connect to your phone when taken out of the charging case, provided Bluetooth is enabled on your device.


5. Operating Instructions

The SZLWSM A6 Pro earbuds are equipped with intelligent touch controls for easy management of your audio and calls.

5.1 Touch Controls

- **Play/Pause:** Click once on either the left or right earbud.
- **Next Song:** Click twice on the left earbud.
- **Previous Song:** Click twice on the right earbud.
- **Answer/End Call:** One click on either earbud.
- **Reject Call:** Long press for 2 seconds on either earbud.
- **Activate Voice Assistant:** Long press for 3 seconds on either earbud.

LIGHTWIGHT / COMFORT





Play or Pause
Click once left/right



Next Song
Click twice left



Previous Song
Click twice right



Answer or end call
One click answer



Reject a Call
Long press for 2 s



Voice Assistant
Long press for 3 s







Figure 4: Touch control functions and lightweight comfort.

5.2 Volume Control

Volume control can be managed directly through your connected device (smartphone, tablet, etc.) or via the voice assistant feature if supported.

6. Maintenance

To ensure the longevity and optimal performance of your SZLWSM A6 Pro Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Water Exposure:** While IPX7 waterproof, avoid prolonged submersion in water. Dry the earbuds thoroughly if they get wet from sweat or splashes before placing them back in the charging case.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from dust, damage, and to keep them charged.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) or high humidity.

7. Troubleshooting

If you encounter any issues with your earbuds, please refer to the following common solutions:

- **Earbuds Not Connecting/Pairing:**
 - Ensure both earbuds and the charging case are sufficiently charged.
 - Turn off and then turn on Bluetooth on your device.
 - Forget "A6 Pro" from your device's Bluetooth list and attempt to re-pair.
 - Ensure the earbuds are taken out of the charging case when attempting to pair.
- **No Sound:**
 - Check the volume level on your connected device.
 - Ensure the earbuds are properly connected to your device.
 - Try playing audio from a different application or source.
- **Charging Issues:**
 - Verify that the USB charging cable is securely connected to both the case and the power source.
 - Try using a different USB cable or power adapter.
 - Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **One Earbud Not Working:**
 - Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again.
 - Ensure both earbuds are charged.
 - Try re-pairing the earbuds with your device.

If these steps do not resolve the issue, please contact SZLWSM customer support for further assistance.

8. Specifications

Product Name	Wireless Bluetooth Earbuds
Model	A6 Pro
Bluetooth Version	V5.3+EDR
Bluetooth Distance	15 meters
Headset Weight	3.5g (each)
Earbud Battery Capacity	45mAh
Charging Box Battery Capacity	450mAh
Charging Power	DC5V
Standby Time	Up to 120 hours
Music/Talk Time	6-8 hours
Charging Time	Approx. 1 hour
Impedance	32 Ohms
Sensitivity	32 dB
Audio Driver Type	Dynamic Driver
Enclosure Material	Plastic, Silicone
Carrying Case Material	Plastic
Carrying Case Dimensions (L x W x H)	55mm x 20mm x 48mm (2.16in x 0.79in x 1.88in)
Earbud Dimensions (W x H)	20mm x 35mm (0.78in x 1.37in)
Carrying Case Weight	29.99 Grams

Product size



Figure 5: Product dimensions of the earbuds and charging case.

9. Official Product Video

Your browser does not support the video tag.

Video 1: Official product overview of the SZLWSM A6 Wireless Earbuds, highlighting key features and design.

10. Warranty and Support

For warranty information and support, please refer to the product packaging or contact SZLWSM customer service through the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

