havit HV-ST7033

Havit ST7033 Bluetooth Tripod Selfie Stick

User Manual - Model: HV-ST7033

1. Introduction

Thank you for choosing the Havit ST7033 Bluetooth Tripod Selfie Stick. This versatile device is designed to enhance your mobile photography and videography experience, offering convenience and stability for capturing perfect moments. It features a 360-degree rotating design, a stable triangular fixed bracket, and a removable Bluetooth 4.0 controller for easy operation. Its extendable length from 185mm to 680mm makes it suitable for various shot angles, from solo selfies to group pictures. Lightweight, compact, and portable, the ST7033 is an ideal companion for travel and everyday use.

2. Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble, repair, or modify the device yourself. Refer to qualified service personnel.
- Ensure the phone is securely mounted before extending the stick or using it as a tripod to prevent accidental drops.
- Keep the Bluetooth remote control out of reach of small children.
- Dispose of the product and its battery responsibly according to local regulations.

3. Package Contents

- Havit ST7033 Bluetooth Tripod Selfie Stick
- Removable Bluetooth Remote Controller
- User Manual (this document)

4. Product Overview

The Havit ST7033 combines a selfie stick and a tripod into one compact device. It features a phone holder, an extendable aluminum alloy rod, a stable tripod base, and a detachable Bluetooth remote.



Figure 4.1: Overall view of the Havit ST7033 in both selfie stick and tripod configurations, showing the remote control.



Figure 4.2: Key features of the Havit ST7033, including its extendable length, rotational capability, and the wireless remote.

- **Phone Holder:** Securely grips your smartphone. Features 360-degree rotation for horizontal or vertical shooting.
- **Extendable Rod:** Made of durable aluminum alloy, extends from 185mm (compact) to 680mm (fully extended).
- **Tripod Base:** Foldable triangular bracket provides stable support when used as a tripod.
- **Bluetooth Remote Controller:** Detachable for convenient remote photo and video capture.

5. Setup

1. **Charge the Remote (if necessary):** The remote control typically comes with a pre-installed battery. If it does not power on, ensure the battery is correctly inserted or replace it if needed.
2. **Pairing the Bluetooth Remote:**
   - Press and hold the button on the Bluetooth remote control until the indicator light starts flashing, indicating it is in pairing mode.
   - On your smartphone, go to **Settings** > **Bluetooth**.
   - Turn on Bluetooth and search for available devices.
   - Select "Havit ST7033" or a similar name from the list of devices.
   - Once paired, the indicator light on the remote will stop flashing and remain solid or turn off.
3. **Attaching Your Phone:**
   - Gently pull open the phone holder clamps.
   - Carefully insert your smartphone into the holder, ensuring it is securely gripped by both clamps.
   - Adjust the phone holder's angle as desired. It supports 360-degree rotation.

4. **Extending the Selfie Stick / Setting up the Tripod:**
    - **For Selfie Stick Use:** Hold the handle firmly and pull the extendable rod upwards to your desired length (up to 680mm).
    - **For Tripod Use:** Unfold the three legs at the base of the stick until they form a stable triangular support. Place the tripod on a flat, stable surface. You can then extend the rod to adjust height.

6. Operating Instructions

1. **Power On/Off the Remote:** Press and hold the button on the remote to power it on or off.
2. **Taking Photos/Videos:**
    - Open your smartphone's camera application.
    - Position your phone and adjust the angle using the 360-degree rotating holder.
    - Press the button on the Bluetooth remote control to trigger the camera shutter. For video recording, press the button to start and stop recording.
3. **Adjusting Length and Angle:**
    - The extendable rod can be adjusted to any length between 185mm and 680mm.
    - The phone holder allows for 360-degree rotation, enabling you to switch between portrait and landscape orientations or find the perfect shooting angle.

7. Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, fold the selfie stick to its compact size and store it in a cool, dry place away from direct sunlight.
- **Battery:** If the remote control is not used for an extended period, consider removing the battery to prevent leakage.

8. Troubleshooting

Problem	Possible Cause	Solution
Remote control not pairing.	Remote not in pairing mode; Bluetooth off on phone; battery low.	Ensure remote is flashing; turn on phone's Bluetooth; check/replace remote battery.
Remote not triggering camera.	Not paired; camera app settings; phone volume button conflict.	Re-pair the remote; ensure camera app is active; check if camera settings allow volume button as shutter.
Selfie stick unstable.	Phone not centered; tripod legs not fully extended; uneven surface.	Center phone in holder; fully extend tripod legs; use on a flat, stable surface.

9. Specifications

Model Name	HV-ST7033
Brand	Havit
Material	ABS (Acrylonitrile Butadiene Styrene), Aluminum Alloy

Color	Black
Extended Length	185mm - 680mm
Compact Size	32 x 48 x 185 mm
Wireless Connectivity	Bluetooth 4.0
Wireless Range	Up to 10 meters (33 feet)
Special Features	360-degree Rotation, Removable Bluetooth Controller, Triangular Fixed Bracket
Weight	Approx. 100 g
Country of Origin	China

10. Warranty and Support

Havit products are manufactured to high quality standards. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your purchase or visit the official Havit website. Please retain your proof of purchase for any warranty claims.

© 2025 Havit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question