

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [CASIO](#) /
- > [CASIO G-SHOCK GST-B600A-1A6 User Manual](#)

CASIO GST-B600A-1A6

CASIO G-SHOCK GST-B600A-1A6 User Manual

Model: GST-B600A-1A6

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your CASIO G-SHOCK GST-B600A-1A6 watch. Please read this manual carefully to ensure proper use and to fully utilize all features of your new timepiece. Keep this manual for future reference.





Figure 1: CASIO G-SHOCK GST-B600A-1A6 Watch

This image displays the front view of the CASIO G-SHOCK GST-B600A-1A6 watch. It features a robust black resin band, a silver-tone stainless steel bezel, and a distinctive purple dial with analog hands and a small digital display. The watch face clearly shows the G-SHOCK logo, "TOUGH SOLAR," and "Bluetooth" indicators, highlighting its key functionalities.

SETUP

Initial Charging

Your G-SHOCK GST-B600A-1A6 is equipped with Tough Solar technology, which converts light into power. Before initial use, ensure the watch is sufficiently charged.

- Place the watch in a location where it can receive direct sunlight or strong artificial light.
- Avoid placing the watch in extremely hot environments during charging.
- A full charge from a completely depleted state can take several hours depending on light intensity. Refer to the "Power Saving Function" in the Specifications section for battery life details.

Time Setting and Mobile Link

The watch supports automatic time correction via Bluetooth connection to your smartphone using the "CASIO WATCHES" app.

1. Download the "CASIO WATCHES" app from your smartphone's app store.
2. Enable Bluetooth on your smartphone.
3. Follow the instructions within the "CASIO WATCHES" app to pair your watch. This will automatically correct the time and date.

4. If not linked with a smartphone, the watch operates with normal quartz accuracy (average monthly difference of 15 seconds).

OPERATING INSTRUCTIONS

Your G-SHOCK GST-B600A-1A6 features multiple functions accessible via its buttons and smartphone link.

Button Functions

Button	Function
ADJUST (Top Left)	Used for entering and exiting setting modes.
MODE (Bottom Left)	Cycles through different modes (Timekeeping, Stopwatch, Timer, Alarm, World Time).
LIGHT (Top Right)	Activates the Double LED light for illumination.
SEARCH (Bottom Right)	Used for adjusting settings or initiating Mobile Phone Search.

Key Features

- **World Time:** Displays time for 38 cities worldwide (38 time zones), with automatic summer time setting and home time city switching.
- **Stopwatch:** 1-second stopwatch, 60-minute counter, with lap/split time measurement.
- **Timer:** Countdown timer with a set unit of 1 second, maximum set time of 60 minutes.
- **Alarms:** Five daily alarms and an hourly time signal.
- **Mobile Phone Search:** Use the watch to trigger an audible alert on your paired smartphone.
- **Hand Shift Feature:** Temporarily moves the analog hands away from the digital display for easier viewing.
- **Date and Day Display:** Displays date (month/day switching) and day of the week (available in 6 languages: English, Spanish, French, German, Italian, Russian).

MAINTENANCE

Cleaning Your Watch

- Wipe the watch regularly with a soft, dry cloth to remove dirt and moisture.
- For resin bands and cases, you can use a mild soap solution and a soft brush, then rinse thoroughly with clean water and dry completely.
- Avoid using chemical cleaners, solvents, or abrasive materials, as they can damage the watch's finish.

Water Resistance

Your watch is 20 ATM water resistant. This means it is suitable for everyday use, showering, swimming, and snorkeling. However, it is not suitable for scuba diving.

- Do not operate buttons while the watch is wet or submerged in water.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Watch is not charging.	Ensure the watch is exposed to sufficient light. Check for obstructions on the dial. If the battery charge warning is active, expose to strong light for an extended period.

Problem	Possible Cause / Solution
Time is incorrect.	Ensure the watch is paired with the "CASIO WATCHES" app and Bluetooth is enabled on your smartphone for automatic time correction. If not using Mobile Link, manually adjust the time.
Cannot connect to smartphone.	Check if Bluetooth is enabled on your phone and the watch. Ensure the "CASIO WATCHES" app is running. Try restarting both devices.
Hands are not aligned with digital time.	Use the hand shift feature or perform a hand home position correction via the app or manual settings.

SPECIFICATIONS

- **Model Number:** GST-B600A-1A6
- **Case Size (H x W x D):** 41.4 x 42.3 x 11.4 mm
- **Weight:** 60 g
- **Case/Bezel Material:** Resin / Stainless Steel
- **Band Material:** Resin
- **Construction:** Shock Resistant
- **Water Resistance:** 200 meters (20 ATM)
- **Power Supply:** Tough Solar (Solar powered)
- **Mobile Link:** Bluetooth® Smart (Wireless linking with Bluetooth® devices)
- **Glass:** Inorganic Glass
- **Surface Treatment:** Black IP (bezel part)
- **Compatible Band Size:** 140 to 205 mm
- **Neobrite:** Yes
- **World Time:** 38 time zones (38 cities + coordinated universal time), daylight saving on/off auto switching, Home city/World time city swapping
- **Stopwatch:** 1/100-second stopwatch, Measuring capacity: 00'00"00~59'59"99 (for the first 60 minutes), 1:00'00~23:59'59 (after 60 minutes), Measuring unit: 1/100 second (for the first 60 minutes), 1 second (after 60 minutes), Measuring modes: Elapsed time, lap/split time
- **Timer:** Countdown timer, Measuring unit: 1 second, Countdown range: 60 minutes, Countdown start time setting range: 1 second to 60 minutes (1-second increments)
- **Alarm/Hourly Time Signal:** 5 daily alarms, Hourly time signal
- **Light:** Double LED light (Super Illuminator, afterglow), LED: White
- **Calendar:** Full auto-calendar (to year 2099)
- **Mute Feature:** Operation tone on/off
- **Power Saving Function:** Yes (display goes blank to save power when the watch is left in the dark)
- **Battery Display/Alert:** Battery level indicator, Power Saving
- **Run Time:** Approx. battery operating time: 7 months on rechargeable battery (operation period with normal use without exposure to light after charge), 18 months on rechargeable battery (operation period when stored in total darkness with the power save function on after full charge)
- **Accuracy:** ±15 seconds per month (with no Mobile Link function)
- **12/24-hour format:** Yes
- **Hand Shift Feature:** Yes
- **Day Display:** Day of week display (selectable from six languages)
- **Date Display:** Date display (month/day display switching)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official CASIO website. As this is an overseas parallel import model, warranty terms may vary from domestic models. Please contact your point of purchase for specific warranty details.

For further assistance or inquiries, please visit the [G-SHOCK Brand Store on Amazon](#).