

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar Travel Hair Dryer User Manual

Aigostar ESFBA1_BID_209830

Aigostar Travel Hair Dryer User Manual

Model: **ESFBA1_BID_209830** | Brand: **Aigostar**

1. INTRODUCTION

Thank you for choosing the Aigostar Travel Hair Dryer. This manual provides essential information for the safe and effective use of your new appliance. Please read it thoroughly before first use and keep it for future reference.

What's Included:

- Aigostar Travel Hair Dryer (Purple)
- Concentrator Nozzle
- Storage Bag

2. SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances.

- Do not use this appliance near water (e.g., in a bathtub, shower, or basin).
- Always unplug the appliance immediately after use.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Keep the air inlet and outlet clear of obstructions to prevent overheating. The appliance is equipped with overheat protection and will automatically shut off if it gets too hot.
- Do not operate any appliance with a damaged cord or plug, or if it malfunctions or has been dropped or damaged in any manner.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Product packaging may contain different information than what is shown on our site. Please always read the label,

warnings, and instructions provided on the product before using or consuming it.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Aigostar Travel Hair Dryer.



This image displays the Aigostar Travel Hair Dryer in its complete form, including the main unit, the detachable concentrator nozzle, and the accompanying black storage bag. The hair dryer is purple and features a foldable handle.

2100W

Motore potente che asciuga i capelli
2 volte più velocemente



An internal diagram illustrating the powerful 2100W motor and the ionic technology at work within the hair dryer, designed for efficient and quick drying.

Key Components:

- **Air Inlet Grille:** Located at the back, draws in air.
- **Air Outlet:** Front opening where air is expelled.
- **Concentrator Nozzle:** Attachable accessory for focused airflow.
- **Handle:** Foldable for compact storage.
- **Power Cord:** For electrical connection.
- **Control Switches:** For power, speed, temperature, and cool shot function.



This image provides a detailed view of the hair dryer's control panel, highlighting the cool shot button (snowflake icon) and the main switch for adjusting temperature and speed settings.

4. SETUP

Before using your hair dryer for the first time, follow these simple steps:

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for storage or future transport if desired.
2. **Attach Concentrator Nozzle (Optional):** Align the concentrator nozzle with the air outlet and push it firmly into place until it clicks. Ensure it is securely attached.
3. **Unfold Handle:** If the handle is folded, gently unfold it until it locks into the upright position.
4. **Connect to Power:** Plug the power cord into a suitable electrical outlet. Ensure your power supply matches the voltage requirements of the appliance.

5. OPERATING INSTRUCTIONS

Your Aigostar Travel Hair Dryer offers customizable settings for optimal drying and styling.

Power and Speed Settings:

Use the main switch on the handle to control power and airflow speed:

- **'0' (Off):** Turns the appliance off.
- **'I' (Low Speed):** Provides a gentle airflow, suitable for delicate drying or styling.
- **'II' (High Speed):** Delivers powerful airflow for rapid drying.

Temperature Settings:

The main switch also controls temperature, typically linked to speed settings:

- **Low Speed:** Generally provides a warm temperature.
- **High Speed:** Provides a hot temperature for faster drying.

Cool Shot Function:



A detailed view of the cool air button, marked with a snowflake icon, used to set hairstyles.

Press and hold the cool shot button (marked with a snowflake icon) to instantly switch to cool air. This function is ideal for setting your hairstyle and adding shine after drying with heat.

Ionic Technology:

This hair dryer incorporates ionic technology, which releases negative ions during operation. These ions help to:

- Lock in moisture, protecting your hair's natural shine.
- Reduce frizz and static electricity.
- Smooth the hair cuticle for a softer, healthier look.

Asciugacapelli professionale

Design leggero e portatile



Per la casa



Per i viaggi



Per il Salone

A visual comparison demonstrating the effectiveness of the ionic technology, showing hair before and after use, with a noticeable reduction in frizz and improved smoothness.

Drying Techniques:

- **Rough Drying:** For initial drying, use a higher speed and temperature setting. Move the dryer continuously to avoid concentrating heat in one area.
- **Styling with Concentrator:** For precise styling, attach the concentrator nozzle. Use a brush to guide sections of hair and direct the airflow from roots to ends.
- **Finishing:** Use the cool shot button to set your style and add shine.

Uso normale

Il flusso d'aria è distribuito in modo uniforme per ridurre i danni ai capelli



Ugello concentrato

L'aria stabilizzante ammorbidisce i capelli e riduce il crespo



This image contrasts the effect of normal airflow with the precise styling achieved using the concentrator nozzle, which helps to smooth hair and reduce frizz.

30%


Asciugatura più rapida



Capelli corti
2-3min



Capelli medi
4-6min



Capelli lunghi
7-9min

A graphic indicating approximate drying times for different hair lengths: 2-3 minutes for short hair, 4-6 minutes for medium hair, and 7-9 minutes for long hair, highlighting its efficiency.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your hair dryer.

Cleaning the Air Inlet Filter:

Dust and hair can accumulate on the air inlet grille, reducing airflow and potentially causing overheating. Clean it regularly:

1. Ensure the hair dryer is switched off and unplugged from the power outlet.
2. Gently wipe the air inlet grille with a soft, dry cloth to remove any dust or lint.
3. For stubborn debris, use a soft brush (e.g., an old toothbrush) to carefully dislodge it.
4. Do not use abrasive cleaners or solvents.

General Cleaning:

- Wipe the exterior of the hair dryer with a soft, damp cloth.
- Ensure the appliance is completely dry before plugging it in.

Storage:



A visual representation of the hair dryer's foldable handle, designed for compact storage and portability.



The hair dryer being stored in its dedicated black storage bag, emphasizing its travel-friendly design.

- Ensure the appliance is cool and dry before storing.
- Fold the handle for compact storage.
- Store the hair dryer in its provided storage bag to protect it from dust and damage.
- Do not wrap the power cord tightly around the appliance, as this can damage the cord.

7. TROUBLESHOOTING

If you encounter any issues with your hair dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet. Test the outlet with another appliance.
Hair dryer stops working during use.	Overheat protection activated.	Unplug the appliance and allow it to cool down for several minutes. Clean the air inlet filter to ensure proper airflow.
Weak or inconsistent airflow.	Blocked air inlet filter.	Clean the air inlet filter as described in the Maintenance section.

Problem	Possible Cause	Solution
Unusual noise or burning smell.	Internal malfunction or debris.	Immediately unplug the appliance. Do not attempt to repair it yourself. Contact customer support.

If the problem persists after trying these solutions, please contact Aigostar customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Aigostar
Model Number	ESFBA1_BID_209830
Power	2100 Watts
Color	Purple
Dimensions (Packaging)	26.1 x 14.1 x 8.4 cm
Weight (Packaging)	640 grams
Power Source	Corded Electric
Included Components	Concentrator Nozzle
Special Features	Ionic Technology, 3 Temperature Settings, 2 Speed Settings, Overheat Protection, Foldable Handle

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. Aigostar products typically come with a manufacturer's warranty covering defects in materials and workmanship.

If you require technical assistance, have questions about your product, or need to report a defect, please contact Aigostar customer support through their official website or the contact information provided in your product packaging.

Please have your model number (ESFBA1_BID_209830) and proof of purchase ready when contacting support.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D4Q97NRH>

More documents and user manuals: **<https://manuals.plus/>**