

Rulefiss BX27

Rulefiss BX27 Wireless Sport Earbuds User Manual

Model: BX27

PRODUCT OVERVIEW

The Rulefiss BX27 Wireless Sport Earbuds are designed for an active lifestyle, featuring advanced Bluetooth 5.4 technology, extended battery life, and a secure, waterproof design.

Key Features

- Bluetooth 5.4 for stable and efficient connection.
- Flexible ear hooks and ergonomic design for a secure and comfortable fit.
- Up to 75 hours of total playtime with the charging case.
- Immersive Hi-Fi stereo sound with 14.2mm dynamic drivers.
- 4 ENC noise-cancelling microphones for clear calls.
- IP7 waterproof rating for sweat and rain resistance.
- Intuitive touch controls.



Image: Rulefiss BX27 Wireless Sport Earbuds in their charging case, showcasing the sleek red design and LED display.

GETTING STARTED

Package Contents

- 2 x BX27 Wireless Sport Earbuds
- 1 x Portable Charging Case
- 1 x USB-C Charging Cable
- 3 x Pairs of Soft Silicone Ear Caps (S/M/L)
- 1 x User Manual



Image: A visual representation of all items included in the Rulefiss BX27 package, including earbuds, charging case, cable, and ear tips.

SETUP

Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the charging case and a power source.
3. The LED display on the case will show the battery percentage, and the earbud indicators will flash during charging.
4. Charging is complete when the LED display shows 100% and earbud indicators turn off or show full charge.

Dual LED Power Display



Charging case with LED power Display shows its battery from 1% to 100%


The LED display will show the power of the 2 earphones and will flash when charging

Image: The charging case with earbuds inside, displaying the battery levels for both the case and individual earbuds via LED indicators.

Pairing with Your Device

The BX27 earbuds feature one-step auto-pairing for convenience.

1. Ensure Bluetooth is enabled on your device (smartphone, tablet, etc.).
2. Open the charging case and take out both earbuds. They will automatically enter pairing mode.
3. On your device, search for Bluetooth devices and select "BX27" from the list.
4. Once connected, you will hear a confirmation prompt, and the earbud indicator lights will change.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.



ONE-STEP AUTO PAIRING

It only takes two steps to establish a link with "BX27". Open the headphone box and take out the Bluetooth headset. Search for Bluetooth devices on your phone and click "BX27"

Image: A smartphone screen showing the Bluetooth pairing menu with "BX27" listed as an available device, next to the earbuds.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The BX27 earbuds are designed with flexible ear hooks for a secure and comfortable fit, especially during physical activity.

1. Choose the correct size silicone ear tips (S/M/L) for optimal comfort and sound quality.
2. Gently insert the earbud into your ear canal.
3. Adjust the flexible ear hook over your ear to secure the earbud in place.



Image: A visual guide demonstrating the steps to correctly wear the earbuds, highlighting the flexible ear hook and ergonomic design.

Touch Controls

The BX27 earbuds feature intuitive touch controls for managing audio playback and calls.

Earbud Touch Control Functions

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause	2 Clicks	2 Clicks
Volume Up		1 Click
Volume Down	1 Click	
Next Track		Press & Hold (2s)
Previous Track	Press & Hold (2s)	
Answer/End Call	1 Click	1 Click
Reject Call	Press & Hold (2s)	Press & Hold (2s)
Activate Voice Assistant	3 Clicks	3 Clicks

Easy Touch Control



Image: A visual guide illustrating the various touch control gestures on the earbuds for music playback and call management.

MAINTENANCE

Cleaning

To ensure longevity and optimal performance, regular cleaning of your earbuds is recommended.

- After intense exercise or exposure to sweat/rain, wipe the metallic parts of the earbuds with a dry cloth to prevent corrosion.
- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical sprays.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

IP7 Waterproof

Nano-coated to resist sweat damage,
ideal for outdoor work, gym, cycling, or taking a jog



Image: The earbuds shown with water splashes, emphasizing their IP7 waterproof capability, suitable for workouts and light rain.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing in dusty environments.

TROUBLESHOOTING

If you encounter issues with your Rulefiss BX27 earbuds, please refer to the following common solutions.

Common Issues and Solutions

Problem	Possible Cause	Solution
Earbuds not pairing/connecting.	Bluetooth is off; earbuds not in pairing mode; interference.	Ensure Bluetooth is on. Place earbuds back in case, then remove to re-enter pairing mode. Turn off other Bluetooth devices.

Problem	Possible Cause	Solution
Only one earbud working.	Earbuds not properly synced; low battery on one earbud.	Place both earbuds back in the charging case, close the lid, wait a few seconds, then open and remove them. Ensure both are charged.
Poor sound quality.	Improper fit; ear tips dirty; device volume too low; distance from device.	Adjust earbud fit and try different ear tip sizes. Clean ear tips. Increase device volume. Stay within Bluetooth range (approx. 10 meters).
Charging issue.	Cable or power source issue; dirty charging contacts.	Try a different USB-C cable and power adapter. Clean the charging contacts on both earbuds and case with a dry cotton swab.
Touch controls unresponsive.	Earbuds not properly worn; temporary software glitch.	Ensure earbuds are securely in place. Place earbuds back in the case, close, then reopen to reset.

SPECIFICATIONS

Rulefiss BX27 Technical Specifications

Feature	Detail
Model Number	BX27
Bluetooth Version	5.4
Playtime (Earbuds)	Up to 15 hours per charge
Total Playtime (with Case)	Up to 75 hours
Charging Port	USB-C
Waterproof Rating	IP7
Microphones	4 ENC Noise-Cancelling Mics
Driver Size	14.2mm Dynamic Driver
Control Type	Touch Control
Weight (Single Earbud)	4.3 grams
Recommended Use	Exercise, Sport
Compatible Devices	Bluetooth-compatible devices

WARRANTY AND SUPPORT

Rulefiss provides a comprehensive warranty for your BX27 Wireless Sport Earbuds.

- **Warranty Period:** 2 years from the date of purchase.
- **Quality Issues:** For any quality-related problems within one month of purchase, you may return or exchange the product.
- **Customer Service:** For support or inquiries, please contact Rulefiss customer service.

For further assistance, please visit the official Rulefiss store or contact their support channels.

Visit Rulefiss
Store