Ninja DT551

Ninja Prestige Smart XL with Pro Cook System

10-in-1 Air Fry Digital Countertop Convection Toaster Oven

Model: DT551

1. Introduction

This manual provides essential information for the safe and efficient operation of your Ninja Prestige Smart XL Air Fry Digital Countertop Convection Toaster Oven. Please read all instructions thoroughly before first use and retain for future reference.



Image: The Ninja Prestige Smart XL Oven showcasing its spacious interior with a whole roasted chicken and air-fried vegetables, highlighting its cooking capacity.

2. What's Included

Your Ninja Prestige Smart XL Air Fry Digital Countertop Convection Toaster Oven package includes the following components:

- Prestige Smart XL Air Fryer & Countertop Oven with Pro Cook System
- (2) Wire Racks
- (2) Sheet Pans
- Roast Tray
- Removable Crumb Tray
- Air Fry Basket
- Pro Cook Thermometer
- 15 Chef Created Recipes and Cooking Charts





Image: A visual representation of all included accessories: wire racks, sheet pans, roast tray, crumb tray, air fry basket, and the Pro Cook Thermometer.

3. Setup

Before first use, ensure the oven is placed on a flat, stable, heat-resistant surface. Allow adequate clearance (at least 6 inches) on all sides for proper ventilation. Remove all packaging materials, including any protective films or inserts from inside the oven. Wash all removable accessories (wire racks, sheet pans, roast tray, air fry basket, crumb tray) in warm, soapy water or in the dishwasher. Wipe the interior and exterior of the oven with a damp cloth. Ensure all parts are completely dry before plugging in the unit.

---

4. Operating the Oven

Control Panel Overview



Image: A detailed view of the intuitive digital display and control buttons on the oven's handle, showing various settings and rack positions.

The digital display handle provides easy access to all cooking functions and settings. The display freezes when the door is open to prevent accidental changes. Use the dedicated buttons to select functions, adjust time, temperature, and rack levels.

10-in-1 Cooking Functions




Image: A collage illustrating the diverse capabilities of the oven, including Air Fry, Air Roast, Broil, Bake, Whole Roast, Pizza, Toast, Bagel, Reheat, and Dehydrate.

The Ninja Prestige Smart XL offers 10 versatile cooking programs:

- **Air Fry:** For crispy results with little to no oil.
- **Whole Roast:** Ideal for larger cuts of meat or whole poultry.
- **Air Roast:** Perfect for roasting vegetables and smaller meats.
- **Bake:** For cakes, cookies, and other baked goods.
- **Dehydrate:** To create dried fruits, vegetables, or jerky.
- **Pizza:** Optimized for baking pizzas.

- **Broil:** For quick browning and melting.
- **Toast:** For perfectly toasted bread.
- **Bagel:** Specifically designed for bagels.
- **Reheat:** To warm up leftovers without drying them out.

Smart Surround Convection



Image: A diagram showing the high-velocity fan and rear heat source working together to circulate air for all-around crisping.

This technology ensures even cooking and crisping by completely surrounding your food with powerful convection air. Flipping and rotating food is often not required, saving you time and effort.

Pro Cook System



Image: The integrated Pro Cook System with Auto Temp Detect Intelligence, showing a meat probe and various doneness levels for precise cooking.

The integrated Pro Cook System with Auto Temp Detect Intelligence monitors the internal doneness of your food, ensuring perfect results from rare to well done without guesswork.

Official Product Videos

Video: Watch this before buying Ninja Air Fryer & Toaster Oven. This video provides a comprehensive overview of the product's features and benefits.

Video: 10-in-1 XL Pro Air Fry Oven A Versatile Kitchen Powerhouse. This video highlights the oven's versatility and various cooking capabilities.

Video: Honest Opinion on the Ninja Air Oven. This video offers a user's perspective on the oven's performance and features.

---

5. Cooking Guidelines



Image: The oven demonstrating its XL capacity, capable of cooking a 6-lb chicken and vegetables simultaneously for family meals.

The Ninja Prestige Smart XL is designed for family-sized meals. It can fit up to two 9x9 baking trays, bake up to 20 cookies, accommodate 9 slices of toast or 9 bagel halves, and roast up to a 12 lb turkey. Its 8 lb air fry capacity is perfect for larger batches of crispy favorites.



Image: The oven demonstrating its ability to cook evenly on two levels, shown with two 12-inch pizzas, requiring no rotation.

With 2-level even cooking, you can prepare multiple dishes simultaneously without the need for rotation, flipping, or shaking. The 90-second oven preheat time and up to 30% faster cooking compared to a full-size convection oven make quick family meals a reality.

---

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your oven. Always unplug the unit and allow it to cool completely before cleaning.

Daily Cleaning:

- Wipe the interior walls with a damp cloth after each use.
- Remove and empty the removable crumb tray. Wash it with warm, soapy water or in the dishwasher.

- Clean the exterior with a soft, damp cloth.

Deep Cleaning:

- For stubborn stains, use a non-abrasive cleaner designed for stainless steel surfaces.
- All removable accessories are dishwasher safe.
- Do not use abrasive cleaners or scouring pads on any part of the oven.

---

7. Troubleshooting

If you encounter any issues with your Ninja Prestige Smart XL Oven, refer to the following common troubleshooting tips:

- **Oven not turning on:** Ensure the power cord is securely plugged into a working outlet.
- **Food not cooking evenly:** Ensure proper rack placement as indicated by the selected function. Avoid overcrowding the oven.
- **Excessive smoke:** Ensure the crumb tray is clean and that the roast tray is used for greasy foods to prevent smoke.
- **Temperature not reaching desired level:** Allow sufficient preheat time. Ensure the oven door is fully closed.

For further assistance, please contact Ninja customer support.

---

8. Specifications

- **Model Name:** Ninja DT551
- **Product Dimensions:** 17.09"D x 20.22"W x 13.34"H
- **Item Weight:** 33.8 pounds
- **Power Source:** AC adapter (1800 Watts)
- **Material:** Stainless Steel
- **Control Type:** Button Control
- **Number of Shelves:** 2

---

9. Warranty and Support

Your Ninja Prestige Smart XL Air Fry Digital Countertop Convection Toaster Oven comes with a limited manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions. For product support, replacement parts, or warranty claims, please visit the official Ninja website or contact their customer service line.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question