



Manuals.plus /

› **Euphro /**

› User Manual for Euphro 15.6" Canvas Plus Digital Picture Frame

Euphro WF1561-U

User Manual for Euphro 15.6" Canvas Plus Digital Picture Frame

Model: WF1561-U | Brand: Euphro

PRODUCT OVERVIEW

The Euphro 15.6" Canvas Plus Digital Picture Frame is designed to display photos and videos with a 1920x1080 IPS touch screen. It features 32GB of internal storage and supports external Micro SD cards for expanded capacity. Content can be shared instantly via the "Uhale" mobile application, available for both Android and iOS devices. The frame supports both horizontal and vertical display orientations and offers various customization options for media presentation.



Image: The Euphro 15.6-inch Digital Picture Frame, showcasing its display capabilities and the associated mobile application interface.

KEY FEATURES

- **15.6-inch IPS Touch Screen:** Features a 1920x1080 resolution IPS touch screen for clear and vibrant image display. Supports horizontal and vertical placement.
- **32GB Internal Storage:** Provides 32GB of built-in storage, capable of holding approximately 60,000 photos (300KB/pc). Storage can be expanded via Micro SD card.
- **Wireless Instant Sharing:** Connects to a WiFi network (2.4GHz) and allows for instant sharing of photos and videos through the "Uhaul" mobile application.
- **Customization Settings:** Offers various display options including adjusting display order, image scaling, hiding images, and changing transition effects.
- **Multi-User Support:** The WiFi frame supports multiple users for connecting and sharing content.

Stunning Visual Display

15.6 inch 1920*1080 FHD IPS Touchscreen



Image: Visual representation of the frame's dimensions and screen specifications.

SETUP GUIDE

1. Unboxing and Initial Placement

Carefully remove the digital picture frame and all accessories from the packaging. Place the frame on a stable surface or mount it securely if using a wall mount. Ensure it is near a power outlet.

2. Powering On

1. Connect the power adapter to the frame's power input port.
2. Plug the power adapter into a wall outlet.
3. The frame will automatically power on. Follow the on-screen prompts for initial setup.

3. Connecting to Wi-Fi

1. On the frame's touch screen, navigate to the Wi-Fi settings.
2. Select your 2.4GHz Wi-Fi network from the list of available networks.
3. Enter your Wi-Fi password and confirm the connection.

4. App Installation and Pairing

1. Download the "Uhale" app from the App Store (iOS) or Google Play Store (Android).
2. Open the "Uhale" app and create an account or log in.
3. Follow the in-app instructions to pair your mobile device with the digital picture frame. This typically involves scanning a QR code displayed on the frame or entering a unique device ID.



Image: The "Uhale" app facilitates wireless sharing of content to the frame.

OPERATING INSTRUCTIONS

1. Navigating the Touch Screen

The frame features an intuitive touch screen interface. Swipe left or right to browse through photos and videos. Tap on an item to view it in full screen. Access settings by tapping the gear icon, usually located in a corner of the screen.

2. Adding and Managing Content

- **Via Uhale App:** Open the "Uhale" app on your smartphone, select the photos or videos you wish to share, and send them directly to your paired frame.
- **Via Micro SD Card:** Insert a Micro SD card (up to 32GB) containing your media files into the designated slot on the frame. The frame will automatically detect the card, allowing you to import or display content.
- **Via USB Drive:** Connect a USB drive with your media files to the USB port on the frame. Similar to Micro SD, you can then access and manage the content.

32GB Built-in Memory

Supports micro SD card, Unlimited User Connections



Image: The frame's gallery view, demonstrating its capacity for numerous photos and videos.

3. Customizing Display Settings

Access the settings menu on the frame to adjust various display preferences:

- **Display Order:** Choose sequential, random, or other specific orders for your media.
- **Image Scaling:** Adjust how images fit the screen (e.g., fit to screen, fill screen).
- **Hide Images:** Select specific images to hide from the slideshow.
- **Transition Effects:** Select different visual transitions between photos.
- **Sleep Mode:** Configure automatic on/off times to conserve energy.

Auto-Rotate & Photo Adjust

Find the desired fit and decorate your space the way you like



Image: The frame's auto-rotate feature and various customization options.

MAINTENANCE

1. Cleaning the Screen

To clean the touch screen, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid abrasive materials or harsh chemicals.

2. General Care

- Keep the frame away from direct sunlight, excessive heat, or moisture.
- Ensure proper ventilation around the device to prevent overheating.
- Avoid dropping or subjecting the frame to strong impacts.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|------------------------------|--|--|
| Frame does not power on. | Power adapter not connected or faulty outlet. | Ensure power adapter is securely connected to the frame and a working power outlet. Try a different outlet. |
| Cannot connect to Wi-Fi. | Incorrect password, weak signal, or 5GHz network. | Verify Wi-Fi password. Move frame closer to router. Ensure you are connecting to a 2.4GHz network. Restart router and frame. |
| Photos/Videos not appearing. | Incorrect file format, app not synced, or storage issue. | Check supported file formats. Ensure app is properly synced and content is sent. Verify Micro SD/USB is inserted correctly and contains valid files. |
| Touch screen unresponsive. | Temporary software glitch or dirty screen. | Restart the frame. Clean the screen with a soft, lint-free cloth. |

SPECIFICATIONS

Screen Size: 15.6 Inches

Resolution: 1920x1080 (Full HD)

Display Type: IPS Touch Screen

Internal Storage: 32GB

Expandable Storage: Supports Micro SD Card

Connectivity: Wi-Fi (2.4GHz)

Compatible Devices: Smartphone (via Uhale App)

Product Dimensions: 15.55 x 9.84 x 0.99 inches

Item Weight: 3.61 pounds

Model Number: WF1561-U

Manufacturer: Euphro

Country of Origin: China

WARRANTY AND SUPPORT

The Euphro 15.6" Canvas Plus Digital Picture Frame comes with a **One-Year Warranty**. This warranty covers manufacturing defects and provides lifetime technical support.

For any inquiries or technical assistance, please contact Euphro customer support. All queries are typically handled within 24 hours.

After-Sales Service: 24-Hour response time

Technical Support: Lifetime support

Please refer to the official Euphro website or your purchase documentation for specific contact details and full warranty terms.