



[Manuals.plus](#) /

› [SYNCWIRE](#) /

› Syncwire Bluetooth 5.4 Car AUX Adapter SW1023 User Manual

SYNCWIRE SW1023

Syncwire Bluetooth 5.4 Car AUX Adapter SW1023 User Manual

Model: SW1023

INTRODUCTION

Thank you for choosing the Syncwire Bluetooth 5.4 Car AUX Adapter. This device allows you to stream audio wirelessly from your Bluetooth-enabled devices to your car's stereo system via the 3.5mm AUX input. It also supports hands-free calling for a safer driving experience. Please read this manual carefully before use to ensure proper operation and to maximize your enjoyment of the product.



Image: Syncwire Bluetooth 5.4 Car AUX Adapter, showing its compact design and coiled cable.

PRODUCT FEATURES

- **Bluetooth 5.4 Technology:** Ensures a stable, fast, and reliable wireless connection with low latency.
- **Hi-Fi Stereo Sound:** Delivers high-fidelity audio quality for an immersive listening experience.
- **Deep Bass Boost:** Enhance bass with a dedicated button for powerful sound.
- **Hands-Free Calling:** Integrated microphone with CVC (Clear Voice Capture) noise cancellation for clear calls.
- **Coiled Cable Design:** Flexible cable extends up to 1.5 meters (5 feet) for convenient placement and organization, featuring gold-plated connectors for durability and stable connection.
- **Colorful Light Switch:** Adds a visual element and indicates device status.
- **Plug and Play:** Easy installation with USB power and 3.5mm AUX audio output.

Tell Jay I'll be OK

Hey sweet , I'm almost home .

Stable Hands-Free Calling with CVC Noise Cancellation

- Answer - Short press
- Hang up - Short press
- Redial last number - Short press twice

15:32 baby 00:04

mute keypad speaker

add call FaceTime contacts

Image: Diagram illustrating the advanced Bluetooth 5.4 chip for fast and stable connections.

Robust Deep Bass & Hi-Fi Stereo



Image: Visual representation of the adapter's robust deep bass and Hi-Fi stereo audio capabilities.

Larger Mics System



Image: Close-up view of the adapter's larger microphone system, designed for clearer calls.

PACKAGE CONTENTS

Please check the package for the following items:

- Syncwire Bluetooth 5.4 Car AUX Adapter (Model SW1023)
- User Manual
- Alcohol Cleaning Wipes (x2)
- Spare Adhesive Pad (x1)

SETUP INSTRUCTIONS

Follow these steps to set up your Syncwire Bluetooth Car AUX Adapter:

1. **Connect Power:** Plug the USB-A connector of the adapter into a powered USB port in your car. This can be a car charger, a dedicated USB port, or a power bank. The adapter requires 5V DC power.
2. **Connect Audio:** Plug the 3.5mm AUX jack into your car's 3.5mm AUX input port. Ensure the AUX input on your car stereo is selected as the audio source.

3. **Placement:** Use the coiled cable to position the adapter conveniently within your car. The cable extends up to 1.5 meters (5 feet). You may use the included adhesive pad to secure the adapter if desired.
4. **Power On:** The adapter will automatically power on when connected to a power source. The LED indicator will begin to flash, indicating it is in pairing mode.



Image: The stretchable coiled cable and gold-plated connectors, highlighting the cable's flexibility and durability.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the adapter is powered on and the LED indicator is flashing, signifying it is ready for pairing.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "SW-BR998" (or similar name) from the list of found devices to connect.
4. Once connected, the LED indicator on the adapter will become solid, indicating a successful connection. The adapter will automatically reconnect to the last paired device when powered on.

Music Playback

- **Play/Pause:** Press the central button (Play/Pause icon) once.

- **Next Track:** Press the "Next Track" button (right arrow icon).
- **Previous Track:** Press the "Previous Track" button (left arrow icon).
- **Volume Up:** Press the "VOL+" button.
- **Volume Down:** Press the "VOL-" button.
- **Deep Bass Boost:** Press the "b" button on the side of the adapter to activate or deactivate the deep bass enhancement.

Hands-Free Calling

- **Answer Call:** Short press the central button (Play/Pause icon) when an incoming call rings.
- **End Call:** Short press the central button (Play/Pause icon) during a call.
- **Redial Last Number:** Double-press the central button (Play/Pause icon).



Image: The adapter's control panel, illustrating buttons for answering calls, hanging up, and redialing the last number.

Colorful Light Switch

- **Turn On/Off:** Long press the dedicated light switch button to toggle the colorful LED lights on or off.

Colorful Light Switch



Image: The adapter demonstrating the colorful light switch in both on and off states.

MAINTENANCE

- Keep the device dry. Moisture can damage the internal circuits.
- Do not expose the device to extreme temperatures. High temperatures can shorten the life of electronic devices and warp plastic parts.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Use a soft, dry cloth or the provided alcohol wipes for cleaning.
- Avoid dropping or subjecting the device to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power/LED off	USB power source is off or faulty; cable not properly connected.	Ensure the car's ignition is on (if USB port is ignition-dependent). Check USB connection and try a different USB port or power source.

Problem	Possible Cause	Solution
Cannot pair with device	Bluetooth not enabled on phone; adapter not in pairing mode; too many devices connected.	Ensure Bluetooth is enabled on your phone. Restart the adapter by unplugging and replugging it. Forget previous Bluetooth connections on your phone and try pairing again. Ensure the adapter's LED is flashing.
No sound or poor sound quality	Car stereo AUX input not selected; volume too low; 3.5mm jack not fully inserted; interference.	Select AUX input on your car stereo. Increase volume on both your phone and car stereo. Ensure the 3.5mm jack is fully inserted. Avoid placing the adapter near strong electromagnetic sources.
Poor call quality	Microphone obstructed; excessive background noise; weak Bluetooth connection.	Ensure the microphone is not covered. Position the adapter closer to you if possible. Check Bluetooth connection stability. CVC noise cancellation helps, but extreme noise may still affect quality.

SPECIFICATIONS

- **Model Number:** SW1023
- **Brand:** SYNCWIRE
- **Bluetooth Version:** 5.4
- **Power Source:** Electric Cable (USB Type A)
- **Input Voltage:** 5V DC
- **Material:** Plastic
- **Color:** Silver
- **Audio Input:** 3.5mm Jack
- **Audio Output Mode:** Surround (2 Channels)
- **Compatible Media Types:** MP3, WAV, AAC, FLAC
- **Special Features:** Hands-free calling, Integrated microphone, Noise suppression, Deep Bass Boost, Colorful LED Light
- **Installation Type:** Plug and Play
- **Control Method:** Buttons, Touch
- **Cable Length (Coiled):** Extends up to 1.5 meters (5 feet)

WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the official Syncwire website or the contact information provided on your product packaging. Keep your purchase receipt for warranty claims.

Note: Product specifications and features are subject to change without prior notice.