

[Manuals.plus](#) /

› [BlitzRock](#) /

› BlitzRock CT3 Open Ear Headphones User Manual

BlitzRock CT3

BlitzRock CT3 Open Ear Headphones User Manual

Model: CT3

1. PRODUCT OVERVIEW

The BlitzRock CT3 Open Ear Headphones are designed for comfort and situational awareness, featuring an open-ear design, Bluetooth 5.4 connectivity, and clear call technology. This manual provides instructions for proper use and maintenance.



Image: BlitzRock CT3 Open Ear Headphones and their charging case, displayed in a peach color.

Package Contents:

- BlitzRock CT3 Open Ear Headphones (Left and Right)
- Charging Case
- USB-C Charging Cable

2. SETUP

2.1 Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter). The indicator lights on the case will show charging status.

- **Charging Case:** Indicator lights illuminate to show battery level.
- **Earbuds:** Lights on earbuds indicate charging when placed in the case.

2.2 Pairing with Your Device

The BlitzRock CT3 headphones automatically enter pairing mode when removed from the charging case for the first time.

1. Ensure the headphones are charged.
2. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "BlitzRock CT3" from the list.
5. Once connected, a voice prompt will confirm successful pairing.





Image: A smartphone screen displaying the Bluetooth settings, with "BlitzRock CT3" highlighted as a connected device, illustrating the pairing process.

2.3 How to Wear

The CT3 headphones feature an open-ear design with earhooks for a secure and comfortable fit.

1. Identify the Left (L) and Right (R) earbuds.
2. Place the earhook over the top of your ear.
3. Gently rotate the earbud backward along the auricle until it sits comfortably and securely in position, with the speaker facing your ear canal.



How to Wear?

1. Place it above the ear
2. Rotate backward along the auricle to the proper position

Image: A two-panel diagram illustrating the correct way to wear the BlitzRock CT3 headphones. The first panel shows placing the earhook over the ear, and the second shows rotating it into the proper, secure position.

3. OPERATING INSTRUCTIONS

3.1 Touch Controls

The BlitzRock CT3 headphones feature intuitive touch controls on each earbud.




Image: A visual guide to the touch controls on the BlitzRock CT3 headphones, showing various tap and hold gestures for functions like play/pause, track skipping, call management, voice assistant, and volume control.

Action	Function (L/R Earbud)
Single Tap	Play/Pause, Answer/End Call
Double Tap (Left)	Previous Song
Double Tap (Right)	Next Song
Triple Tap	Activate Voice Assistant

Action	Function (L/R Earbud)
Long Press (Left)	Volume Decrease
Long Press (Right)	Volume Increase
Quadruple Tap	Game Mode On/Off

3.2 BlitzRock App Control

Enhance your experience by downloading the BlitzRock App. The app allows for sound customization (EQ settings) and personalized touch control settings.

Customizing Sound by BlitzRock App

With BlitzRock App you shape your private listening journey. There are 3 pre-set modes you can choose according to your preference. OR you can customize EQ settings suit your taste and style.




Image: Screenshots of the BlitzRock mobile application, showing options for customizing sound equalization (EQ) and remapping touch controls for the headphones.

3.3 Key Features in Use

Open-Ear Design for Situational Awareness

Open-Ear Enjoy

Enjoy the comfort of air conduction that adapts without intrusion, ensuring your ears stay pressure-free for extended comfort.



Image: Two individuals outdoors, one wearing the open-ear headphones, demonstrating the ability to enjoy audio while remaining aware of their surroundings.

The open-ear design allows you to listen to audio while still hearing ambient sounds, enhancing safety during outdoor activities and enabling engagement in conversations.

Enhanced Call Clarity with 4-Mic ENC

Seamless Sync, Clear Calls



Bluetooth 5.4



ENC 4 mics noise reduction



Low latency



Image: A man wearing BlitzRock CT3 headphones, appearing to be engaged in a phone call in an outdoor setting, illustrating clear call functionality.

Equipped with 4-microphone Environmental Noise Cancellation (ENC) technology, the CT3 ensures your voice is clear during calls by reducing background noise.

IPX5 Sweat-Resistant Design

Stay Focused on Sports

IPX5 Waterproof, Sweatproof, Stay Secure



Image: A man with sweat on his forehead, wearing BlitzRock CT3 headphones, indicating their suitability for workouts and resistance to sweat.

The IPX5 rating ensures the headphones are resistant to sweat and light splashes, making them suitable for workouts and outdoor activities.

Comfortable and Secure Fit

Skin-Soft for All-Day Comfort




Image: A woman gently touching her ear while wearing BlitzRock CT3 headphones, emphasizing their skin-soft material and all-day comfort.

Designed with ultra-comfort earhooks and skin-soft materials, the CT3 provides a stable and comfortable fit for extended wear and various activities.

4. MAINTENANCE

4.1 Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Keep charging contacts clean and dry.

4.2 Storage

- Store the headphones in their charging case when not in use to protect them and keep them charged.

- Avoid storing in extreme temperatures (hot or cold) or in highly humid environments.

5. TROUBLESHOOTING

Problem	Possible Solution
Headphones not turning on	Ensure earbuds and charging case are fully charged.
Cannot pair with device	Ensure Bluetooth is enabled on your device. Turn off and on Bluetooth. Forget "BlitzRock CT3" from your device's Bluetooth list and re-pair. Ensure earbuds are in pairing mode (lights flashing).
No sound or low volume	Check device volume and headphone volume. Ensure headphones are properly connected. Try playing different audio.
Intermittent connection	Move closer to your device. Avoid strong electromagnetic interference. Ensure no physical obstructions between headphones and device.
Microphone not working	Ensure headphones are selected as the audio input device on your phone/computer. Check for any obstructions on the microphone ports.

6. SPECIFICATIONS

Feature	Detail
Model Number	CT3
Connectivity Technology	Wireless (Bluetooth 5.4)
Ear Placement	Open Ear
Earpiece Shape	Ear Hooks
Water Resistance Level	IPX5 (Water Resistant)
Control Type	Media Control, App Control
Audio Driver Type	Dynamic Driver
Frequency Range	20 Hz to 20,000 Hz
Item Weight	7 ounces
Batteries	1 12V battery (included)

7. WARRANTY AND SUPPORT

BlitzRock products are designed and manufactured to the highest quality standards. For warranty information and

customer support, please refer to the warranty card included in your product packaging or visit the official BlitzRock website. Keep your proof of purchase for any warranty claims.

© 2024 BlitzRock. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question