

Zulay Kitchen Super Automatic Coffee Machine

Zulay Magia Fully Automatic Espresso Machine

USER MANUAL

1. Introduction

Thank you for choosing the Zulay Magia Fully Automatic Espresso Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new coffee machine. Please read it thoroughly before first use and keep it for future reference.

The Zulay Magia is designed to offer a wide range of customizable coffee beverages, from rich espressos to creamy lattes and cappuccinos, all at the touch of a button. Its intuitive touchscreen interface and automatic cleaning features ensure a convenient and enjoyable coffee experience.

2. Safety Instructions

- Always ensure the machine is placed on a stable, level surface.
- Do not immerse the machine, cord, or plug in water or any other liquid.
- Unplug the machine from the power outlet when not in use and before cleaning.
- Keep hands and fingers away from hot surfaces and steam nozzles during operation.
- Use only cold, fresh water in the water tank.
- Do not operate the machine with a damaged cord or plug.

3. Setup

Before first use, unpack all components and remove any packaging materials. Place the machine on a clean, dry, and stable countertop.



Figure 3.1: Zulay Magia Fully Automatic Espresso Machine, Midnight Silver.

3.1 Component Overview




Figure 3.2: Key components of the Zulay Magia Espresso Machine.

- **Water Tank:** Fill with fresh, cold water. Ensure it is properly seated.
- **Coffee Bean Container:** Add whole coffee beans. The integrated conical burr grinder will process them as needed.
- **Pre-ground Coffee Funnel:** For using pre-ground coffee, open the designated funnel and add the desired amount.
- **Drip Tray:** Ensure the drip tray is correctly inserted. The machine will indicate if it is missing or full.
- **Waste Bin:** This collects used coffee grounds. Ensure it is empty before starting.

3.2 Initial Cleaning Cycle

Upon first power-on, the machine will prompt you to perform an initial cleaning cycle. Follow the on-screen instructions to flush the system with hot water. This prepares the machine for brewing and ensures optimal taste.

Video 3.1: Overview of the Magia Super Automatic Coffee Machine, demonstrating its features and ease of use. This video provides a general introduction to the machine's capabilities and operation.

4. Operating Instructions

The Zulay Magia features an intuitive 7-inch touchscreen for easy navigation and drink selection.

4.1 Selecting a Drink

From the main menu, you can choose from 19 pre-programmed coffee recipes, including Espresso, Latte, Cappuccino, Americano, Macchiato, and more. Simply tap on your desired drink icon.



Figure 4.1: The touchscreen interface displaying 19 specialty drink options.

4.2 Customizing Your Drink

Each of the 19 recipes is fully adjustable. After selecting a drink, you can modify parameters such as:

- **Coffee Strength:** Adjust the amount of coffee powder used.
- **Volume:** Control the liquid volume of coffee, milk, and froth.
- **Temperature:** Set your preferred beverage temperature.
- **Milk and Froth:** Customize the amount of hot milk and milk foam.

You can save up to 10 user profiles with personalized settings for quick access to your favorite beverages.

FULLY CUSTOMIZABLE

✓ Coffee strength

✓ Coffee volume

✓ Temperature control

✓ Hot milk volume

✓ Milk froth volume



PRE-SET FOR THE IDEAL DRINKING TEMPERATURE

Figure 4.2: Customization screen for adjusting drink parameters.

4.3 Grinding Adjustment

The integrated stainless steel conical burr grinder allows you to tailor the grind fineness from ultra-fine to coarse. Adjust the fineness knob located near the coffee bean container to achieve your desired grind for optimal flavor extraction.

**SWITCH FROM
PRE-GROUND COFFEE TO WHOLE BEANS
AT THE TOUCH OF A BUTTON**

**FINENESS ADJUSTMENT KNOB
ULTRA FINE TO COURSE GRINDINGS AT YOUR PREFERENCE**

Figure 4.3: Fineness adjustment knob for the coffee grinder.

4.4 Adjustable Coffee Drip System

The coffee drip system is adjustable to accommodate various mug sizes, preventing spills and ensuring a clean brewing process.



Figure 4.4: Adjustable coffee drip system for different cup sizes.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Zulay Magia Espresso Machine.

5.1 Auto-Cleaning Function

The machine features an auto-cleaning function that simplifies daily upkeep. The system automatically flushes itself upon startup and shutdown. For milk-based drinks, ensure the milk system is cleaned regularly to prevent blockages.

ADJUSTABLE COFFEE DRIP NO SPILLS



Figure 5.1: Auto-cleaning function display.

5.2 Removable Components

The drip tray, water tank, and coffee waste bin are all removable and dishwasher safe for easy cleaning. Regularly empty and clean these components to prevent buildup and maintain hygiene.

5.3 Descaling

The machine will prompt you when descaling is required. Follow the on-screen instructions for the descaling process, which typically involves using a descaling solution to remove mineral buildup from the internal components. This is crucial for maintaining brewing quality and machine lifespan.

6. Troubleshooting

This section addresses common issues you might encounter with your Zulay Magia Espresso Machine.

- **Machine Not Operating:** Ensure the drip tray is correctly inserted. The machine will display a "Drip tray missing" message if it is not.
- **"No Beans" Indication Despite Beans Present:** Check if coffee beans are properly flowing into the grinder. Sometimes, moist coffee powder can cause blockages. Clean the coffee bean chamber and grinder area if necessary.
- **Weak Coffee/Clear Water Flow:** This can indicate a blockage in the brewing unit or grinder. Perform a thorough cleaning of the brewing unit and ensure the grinder is clear of any obstructions.
- **Milk System Issues:** If milk is not frothing correctly or dispensing, ensure the milk tube is clean and free of blockages. Regular cleaning of the milk system is essential.
- **Error Messages:** Refer to the on-screen error codes for specific instructions. If an error persists, contact customer support.

7. Specifications

Feature	Detail
Brand	Zulay Kitchen
Model Name	Super Automatic Coffee Machine
Color	Midnight Silver
Product Dimensions	22.04"D x 12.79"W x 13.66"H
Item Weight	28.6 pounds
Special Feature	Programmable
Coffee Maker Type	Espresso Machine
Filter Type	Reusable
Operation Mode	Fully Automatic
Coffee Input Type	Beans and Grounds
Human Interface Input	Touchscreen, Buttons
UPC	195702023478

8. Warranty and Support

The Zulay Magia Fully Automatic Espresso Machine comes with a one-year warranty. For any issues or assistance, please contact Zulay Kitchen customer support. Our team is dedicated to providing comprehensive support and will assist you every step of the way.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question