XDMTWLKJ B0D4Y8KMTX

XDMTWLKJ Baby Playpen 79"x79" Instruction Manual

Model: B0D4Y8KMTX

1. Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your XDMTWLKJ Baby Playpen. Please read all instructions carefully before use and retain this manual for future reference.
The XDMTWLKJ Baby Playpen is designed to provide a secure and spacious environment for babies and toddlers to play. It features a large area, transparent mesh sides for visibility, dual zipper doors for access, and integrated storage pockets.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always ensure the playpen is fully assembled and all connections are secure before placing a child inside.
- Never leave a child unattended in the playpen. Constant supervision is required.
- Do not modify the playpen or use accessories not approved by the manufacturer.
- Discontinue use if any part of the playpen is damaged, broken, or missing. Contact customer support for replacement parts.
- Keep the playpen away from open flames, heaters, and other heat sources.
- Ensure the playpen is placed on a flat, stable surface.
- Remove any large toys or objects that a child could use to climb out of the playpen.
- The playpen is not intended for sleeping.
- The inner dimensions at the bottom of the playpen are approximately 74.8 x 74.8 inches. If purchasing a mat, ensure its dimensions are less than or equal to these inner measurements to prevent gaps.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Fabric Playpen Enclosure (with mesh sides, dual zipper doors, and storage pockets)

- Steel Tubing Frame Components (various lengths for sides, top, and bottom)
- Connectors (for assembling the frame)
- Suction Cups (pre-attached to base connectors or separate)
- Instruction Manual

4. Setup and Assembly

The playpen features an intuitive interlocking frame designed for tool-free assembly. It can be set up or collapsed in minutes.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Base Frame:** Connect the bottom steel tubes using the provided connectors to form the base square. Ensure all connections are firm.
3. **Attach Vertical Supports:** Insert the vertical steel tubes into the base frame connectors.
4. **Install Top Frame:** Connect the top steel tubes to the vertical supports using the remaining connectors, forming the upper square. Ensure all poles are screwed together tightly.
5. **Secure Fabric Enclosure:** Drape the fabric enclosure over the assembled frame. Ensure the mesh sides are properly aligned with the frame and the padded top edges fit snugly over the upper tubes.
6. **Check Stability:** Gently push and pull on the assembled playpen to ensure all connections are secure and the structure is stable. The heavy-duty base-mounted suction cups should provide additional stability on smooth surfaces.



Figure 4.1: Assembly of the playpen frame. Ensure all poles are securely connected for stability.

Your browser does not support the video tag.

Video 4.1: Official assembly guide for the XDMTWLKJ Baby Playpen. This video demonstrates the step-by-step process of setting up the playpen, highlighting the tool-free interlocking frame and securing the fabric enclosure.

5. Operating Instructions

5.1 Dual Zipper Doors

The playpen is equipped with two opposite mesh panels featuring wide zipper doors. These doors allow for easy entry and exit for both children and adults. To open, simply unzip the door. To close, ensure the zippers are fully engaged to secure the opening.



Figure 5.1: Illustration of the dual zipper door feature, providing convenient access to the playpen.

5.2 360° Full Mesh Visibility and Ventilation

All four sides and both zippered doors are constructed from high-quality, tear-resistant mesh. This design allows for unobstructed views of your child from any angle, promoting constant supervision. The mesh also ensures optimal airflow, creating a comfortable and well-ventilated play environment.



Figure 5.2: The transparent mesh sides offer full visibility and ventilation.

5.3 Built-In Storage Pockets

The interior walls of the playpen include two mesh pockets (one large, one small). These pockets are designed for organizing small items such as toys, pacifiers, or snacks, keeping them within reach while maintaining a tidy play area.



Figure 5.3: Integrated mesh storage pockets for convenience.

6. Maintenance

- **Cleaning:** The fabric components, including the padded top edges, can be wiped clean with a damp cloth and mild soap. Do not use abrasive cleaners or bleach. Allow to air dry completely before folding or storing.
- **Frame Care:** The steel tubing can be wiped clean with a damp cloth. Ensure all metal parts are dry to prevent rust.
- **Regular Inspection:** Periodically check all connections, zippers, and mesh for signs of wear, damage, or loose parts. Tighten any loose connections.
- **Storage:** When not in use, the playpen can be disassembled and stored in a dry, cool place away from direct sunlight.

7. Troubleshooting

Problem: Playpen feels unstable or wobbly.

Solution: Ensure all steel tubes are fully inserted into their connectors and securely tightened. Verify that the playpen is placed on a flat, level surface. Check if the base suction cups are properly engaged with the floor.

Problem: Difficulty assembling the frame.
Solution: Refer to the "Setup and Assembly" section and the provided video. Ensure you are connecting the correct tube lengths to the appropriate connectors. Starting with the corner connections first can often simplify the process. Do not force parts together; if they don't fit, re-check the orientation and part selection.

Problem: Zippers are stuck or difficult to operate.
Solution: Check for any fabric caught in the zipper teeth. Gently pull the fabric away and try again. Avoid excessive force, which can damage the zipper. Ensure the fabric is not overly taut around the zipper area.

8. Specifications

Feature	Detail
Brand	XDMTWLKJ
Model	B0D4Y8KMTX
Age Range	Toddler
Outer Dimensions	79 x 79 x 27 inches (Length x Width x Height)
Inner Dimensions (Bottom)	74.8 x 74.8 inches
Floor Area	43 Square Feet
Material Type	Fabric (with mesh panels and steel tubing frame)
Color	Grey
Special Features	360° Full Mesh Visibility, Dual Zipper Doors, Dual Storage Mesh Pockets, Ultra-Soft Top Edges, Heavy-Duty Base-Mounted Suction Cups

9. Warranty and Support

For warranty information, replacement parts, or technical support, please contact XDMTWLKJ customer service. Refer to the product packaging or the manufacturer's website for specific contact details.
Please retain your proof of purchase for warranty claims.

© 2026 XDMTWLKJ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question