

[Manuals.plus](#) /

› [PawHut](#) /

› PawHut Dog Crate Furniture Instruction Manual

PawHut D02-192V71GY

PawHut Dog Crate Furniture Instruction Manual

Model: D02-192V71GY

1. INTRODUCTION

Thank you for choosing the PawHut Dog Crate Furniture. This product is designed to serve as both a comfortable and secure indoor space for your large-sized dog and a functional end table for your home. Its thoughtful design includes a large tabletop, a soft washable cushion, a lockable front door, and wire mesh for ventilation. Please read this manual thoroughly before assembly and use to ensure proper setup and safe operation.



Image 1.1: Front view of the PawHut Dog Crate Furniture.




Image 1.2: The dog crate functions as a multi-functional end table, providing a surface for household items.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before allowing your pet to use the crate.
- Do not exceed the maximum weight capacity of the tabletop (20kg).
- Regularly inspect the crate for any loose parts, damage, or wear. Discontinue use if any damage is found.
- Keep small children away from the crate during assembly and ensure they do not play inside or on the crate.
- This product is designed for indoor use only.
- Ensure the crate is placed on a stable, level surface. Use the adjustable feet to achieve stability.

3. COMPONENTS OVERVIEW

Before beginning assembly, verify that all components are present and undamaged. Refer to the included parts list in your packaging for detailed identification.

- Wooden panels (top, bottom, sides)
- Metal wire mesh panels (front doors, side panels)
- Lockable door latches and hinges
- Soft washable cushion
- Adjustable feet
- Assembly hardware (screws, bolts, etc.)



SOFT CUSHION



Washable

Image 3.1: The soft, washable cushion provides comfort for your pet.



Image 3.2: Detail of the elevated bottom and the secure door lock.



Image 3.3: Detail of the robust door hinge.

4. SETUP AND ASSEMBLY

Assembly of the PawHut Dog Crate Furniture is required. Please follow the step-by-step instructions provided in the separate assembly manual included with your product. General steps include:

1. Unpack all components and verify against the parts list.
2. Assemble the main wooden frame according to the diagrams.
3. Attach the wire mesh panels and doors, ensuring hinges and locks are correctly installed.
4. Securely fasten all screws and connectors.
5. Install the adjustable feet on the bottom of the crate.
6. Place the washable cushion inside the assembled crate.

Once assembled, adjust the feet to ensure the crate is stable and level on your floor.



Image 4.1: Visual representation of the product dimensions to aid in placement and assembly.

5. OPERATING INSTRUCTIONS

5.1 Using as a Dog Crate

- Guide your pet gently into the crate. The soft cushion provides a comfortable resting area.
- Close the front door and engage the lockable latch to secure your pet inside when needed.
- The wire mesh on three sides ensures proper ventilation, keeping your pet cool and comfortable.

5.2 Using as an End Table

- The large tabletop can be used to display decorative items, lamps, or other household necessities.
- Ensure that items placed on the tabletop do not exceed the maximum load of 20kg.
- Avoid placing hot items directly on the surface without protection.



Image 5.1: A dog resting inside the crate, demonstrating its dual functionality in a living space.

6. MAINTENANCE AND CARE

- **Crate Structure:** The engineered wood and alloy steel frame can be easily cleaned by wiping with a damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cushion:** The plush cushion is washable. Refer to the cushion's care label for specific washing instructions to maintain its softness and shape.
- **General:** Keep the product indoors to protect it from weather elements and prolong its lifespan.



Image 6.1: The surface is easy to clean with a simple wipe.

7. TROUBLESHOOTING

7.1 Instability

If the crate feels wobbly or unstable:

- Ensure all assembly screws and bolts are tightened securely.
- Adjust the individual feet at the bottom of the crate to compensate for uneven flooring.

7.2 Door Not Latching Properly

If the door does not close or latch smoothly:

- Check that the crate is assembled squarely and not warped.
- Inspect the hinges and latch mechanism for any obstructions or damage.

- Ensure the door is aligned correctly within its frame.

8. SPECIFICATIONS

Feature	Detail
Model Number	D02-192V71GY
Overall Dimensions (L x W x H)	100 cm x 60 cm x 73.5 cm
Item Weight	23.4 kg
Top Maximum Load	20 kg
Bar Spacing	4.7 cm
Suitable Pet Size	Large dogs and below, up to 30kg and 60cm body length
Material	Alloy Steel, Engineered Wood
Colour	Grey
Care Instructions	Keep Indoors

SUITABLE FOR LARGE DOGS



Siberian
Husky



Samoyed



Chinese
Sharpei



Dalmatian



Golden
Retriever



Labrador
Retriever



NOTE:

Please measure the body length
of your pet before purchasing.

Body length < 60cm



Suitable for dogs up to **30kg**

Image 8.1: Guide for suitable dog sizes and how to measure your pet's body length.

9. WARRANTY AND SUPPORT

For any questions regarding assembly, operation, or maintenance of your PawHut Dog Crate Furniture, please refer to the contact information provided with your purchase or visit the official PawHut website for customer support.

Please retain your proof of purchase for any warranty claims.

You can visit the PawHut Store for more information: [PawHut Store on Amazon.co.uk](#)