

NIRSUN SW015

NIRSUN Black Battery Operated Wall Sconce Set of 2 User Manual

Model: SW015

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using your NIRSUN Wall Sconces. Keep this manual for future reference.

- **Charging Safety:** Only use certified 5V1A or 5V2A adapters for charging the rechargeable bulbs.
- **Charging Duration:** Charge the bulbs for 5-6 hours for a full charge.
- **Environment:** Keep the light bulb away from moisture, excessive heat, and direct sunlight while charging.
- **Storage:** For long-term non-use, store the bulbs in a cool, dry place.
- **Indoor Use Only:** These wall sconces are designed for indoor use only. Do not expose them to water or outdoor elements.
- **Disassembly:** Do not attempt to disassemble or modify the product. This may void the warranty and pose a safety risk.



Image: Charging precautions for the rechargeable bulbs, showing to avoid damp places, heat sources, and direct sunlight.

2. WHAT'S IN THE BOX

Carefully unpack the box and ensure all items are present:

- 2 x Rechargeable Bulbs
- 1 x Remote Control
- 2 x Metal Lamp Holders
- 2 x White Fabric Lampshades
- 2 Sets of Screws for Installation




Image: The NIORSUN Black Battery Operated Wall Sconce Set of 2, showcasing the complete product.

3. SETUP AND INSTALLATION

3.1 Charging the Bulbs

Before first use, fully charge both rechargeable bulbs.

1. Locate the USB-C charging port on each bulb.

2. Connect the bulbs to a 5V1A or 5V2A certified USB adapter (not included) using a USB-C cable (not included).
3. Charge for approximately 5-6 hours until the charging indicator light on the bulb shows it is fully charged.


WHY CHOOSE US



NIORSUN

Wider lighting range

- Upgrade to 50H 
- 9 Colors 



OTHERS

- Only 10H
- 3 Colors

Image: A detailed view of the rechargeable bulb, highlighting its USB-C charging port and dimensions.

3.2 Mounting the Sconces

These sconces require minimal effort for secure mounting.

1. Choose your desired location on the wall.
2. Mark the positions for the two small holes required for each lamp holder.
3. Drill the two small holes and insert any necessary wall anchors (if applicable for your wall type).
4. Securely attach the metal lamp holders to the wall using the provided screws.

3.3 Assembling the Sconces

1. Attach the white fabric lampshades to the metal lamp holders.
2. Screw the fully charged bulbs into the E26 base of each lamp holder.

Your browser does not support the video tag.

Video: Official NIORSUN guide demonstrating the safety and charging process for the rechargeable bulbs, as well as bulb installation into the sconce.

4. OPERATING INSTRUCTIONS

Your NIORSUN Wall Sconces are controlled by the included remote control.



Image: NIORSUN wall sconces installed in a bedroom, with a hand holding the remote control, illustrating ease of use.

4.1 Remote Control Functions

- **ON/OFF:** Power the lights on or off.
- **Brightness Adjustment (+/-):** Increase or decrease brightness (5 levels: 20%-100%).
- **Color Temperature (3000K/4500K/6500K):** Cycle through Warm White (3000K), Neutral White (4500K), and Cool White (6500K).
- **RGB Colors (M1 Button):** Access 7 different RGB color options.

- **Timer (1H/2H/4H/8H):** Set the lights to automatically turn off after 1, 2, 4, or 8 hours.

4.2 Adjusting Brightness

Press the '+' or '-' buttons on the remote to cycle through 5 levels of brightness, from 20% to 100%.




Image: Visual representation of the 5 brightness levels (20% to 100%) available for the NIORSUN wall sconces.

4.3 Changing Color Temperature

Press the 3000K, 4500K, or 6500K buttons to select your desired white light temperature:

- **3000K (Warm White):** Ideal for bedrooms and cozy environments.
- **4500K (Neutral White):** Suitable for living rooms and general illumination.
- **6500K (Cool White):** Best for stairwells, doorways, or task lighting.




Image: Examples of the 3 color temperatures (3000K, 4500K, 6500K) used in different home settings like bedrooms, living rooms, and stairwells.

4.4 Selecting RGB Colors

Press the 'M1' button on the remote to cycle through 7 vibrant RGB color options, allowing you to customize the ambiance of your space.

RGB modes

► Define your style



RGB COLOR SETTING

- Change the ambiance at will,
- creating a vibrant home lighting
- experience.

Image: A person using the remote to select RGB colors for the wall sconce, illustrating the customizable lighting options.

4.5 Timer Function

Use the 1H, 2H, 4H, or 8H buttons to set a timer for the lights to automatically turn off, conserving battery life and providing convenience.

RECHARGEABLE WALL LIGHTS



Image: A child sleeping peacefully with the wall sconce set to a timer, highlighting the safety and energy-saving benefits of the timer function.

4.6 Memory Function

The wall sconces will remember your last color and brightness settings when powered off and on again, eliminating the need for reconfiguration.

5. MAINTENANCE

5.1 Cleaning

To clean the wall sconces, ensure they are turned off. Gently wipe the metal parts and fabric lampshades with a soft, dry cloth. Do not use abrasive cleaners or solvents.

5.2 Battery Care

To prolong battery life, fully charge the bulbs when the light output diminishes. If storing the sconces for an extended period, ensure the bulbs are partially charged (around 50%) and recharge them every few months to prevent deep

discharge.

6. TROUBLESHOOTING

- **Light not turning on:**
 - Ensure the bulb is fully charged.
 - Check if the bulb is screwed in properly.
 - Verify the remote control has working batteries and is pointed directly at the sconce.
- **Remote control not responding:**
 - Replace the batteries in the remote control.
 - Ensure there are no obstructions between the remote and the sconce.
- **Short battery life:**
 - Ensure the bulbs are charged for the full 5-6 hours.
 - Higher brightness settings and continuous use of RGB colors will consume battery faster.

7. SPECIFICATIONS

Brand	NIORSUN
Model Number	SW015
Color	Black
Material	Metal (Fixture), Fabric (Shade)
Power Source	Battery Powered
Light Source Type	LED
Bulb Base	E26
Brightness	300 Lumens
Color Temperature	3000K, 4500K, 6500K (Adjustable)
Special Features	Dimmable (20%-100%), 7 RGB Colors, Memory Function, Timer (1-8H), Wireless, Remote Control
Control Method	Remote Control
Voltage	3.7 Volts
Wattage	2.5 Watts
Item Dimensions (L x W x H)	4.7"L x 5.5"W x 27"H
Item Weight	2.01 kg

8. WARRANTY AND SUPPORT

NIORSUN proudly stands behind its products. Your wall sconces come with a comprehensive **6-year service warranty**. This warranty covers any defects or malfunctions that may occur within this period.

For any questions, concerns, or warranty claims, please contact NIORSUN customer support through your purchase platform or the official NIORSUN website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D4YKTNYP>

More documents and user manuals: <https://manuals.plus/>