

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [AECOJOY](#) /

> [AECOJOY 3 Pcs Outdoor Swivel Bar Set Instruction Manual](#)

AECOJOY 16222BK

AECOJOY 3 Pcs Outdoor Swivel Bar Set Instruction Manual

Model: 16222BK | Brand: AECOJOY

PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your AECOJOY 3 Pcs Outdoor Swivel Bar Set. This set includes a high-top table and two swivel bar stools, designed for outdoor use in various settings such as lawns, backyards, gardens, and porches. The components are constructed from durable, all-weather metal, ensuring longevity and resistance to outdoor elements.



Image: The AECOJOY 3 Pcs Outdoor Swivel Bar Set, featuring a square high-top table and two swivel bar stools with cream cushions, placed on a patio.

SAFETY INFORMATION

Always assemble the product according to the provided instructions to ensure stability. Keep the product on a flat, stable surface to prevent tip-overs. Do not allow children to play on or near the product. Inspect the product regularly for any signs of wear or damage, and discontinue use if necessary. Do not expose the product to extreme heat or direct sunlight for extended periods.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x High-Top Bar Table
- 2 x Swivel Bar Stools
- All necessary assembly hardware (bolts, nuts, washers)

- Assembly tools (e.g., Allen wrench)



Image: A detailed view of the bar stool and table components, highlighting the sofa fabric cushion, solid metal legs, 360-degree swivel mechanism, and printed backrest.

ASSEMBLY INSTRUCTIONS

Assembly of the AECOJOY bar set is designed to be straightforward, typically requiring two adults and approximately 30 minutes. Follow the included instructions carefully. It is recommended to loosely fasten all bolts during initial assembly and tighten them fully only after all components are correctly aligned.

Key Assembly Tips:

- **Chair Foot Ring:** Some users have found it easier to attach the chair foot ring before fully securing the legs to the seat. Ensure proper alignment before tightening.
- **Swivel Mechanism:** The swivel bucket must be securely attached to the fixed connection from the holes in the bottom flange. Verify the correct orientation and secure all bolts.
- **Table Assembly:** The table assembly is generally simpler. Ensure the wooden fireproof board is correctly seated on the

metal frame.



Image: A close-up view of the table, showing its wooden fireproof board top, stable metal frame, and anti-slip rubber feet.

Your browser does not support the video tag.

Video: An overview of the AECOJOY Outdoor Bar Set, showcasing its design and suitability for outdoor leisure. This video provides a visual representation of the assembled product in use.

OPERATING INSTRUCTIONS

360° Swivel Functionality:

The bar stools are equipped with a 360-degree swivel mechanism, allowing for easy rotation and movement. To operate, simply apply gentle pressure to rotate the seat in any desired direction. Ensure the swivel mechanism is free from obstructions and regularly check for smooth operation.

360°

SWIVEL OUTDOOR BAR STOOL



Swivel Spin

Image: A visual representation demonstrating the 360-degree swivel capability of the outdoor bar stool, highlighting its smooth rotation.

MAINTENANCE

To ensure the longevity and appearance of your AECOJOY Outdoor Swivel Bar Set, follow these maintenance guidelines:

- **Cleaning:** Wipe the metal frame and wooden tabletop with a dry cloth to remove dust and debris. For more stubborn dirt, use a damp cloth with mild soap and water, then dry thoroughly.
- **Cushions:** The cushions are made of padded textilene, which is water-resistant. For best results, store cushions indoors during prolonged periods of rain or harsh weather. Clean cushions with a mild soap solution and allow them to air dry completely.
- **Weather Protection:** While the set is designed for all-weather conditions with a powder-coated steel frame, covering the furniture during extreme weather (heavy rain, snow, strong winds) or prolonged periods of non-use will help preserve its condition.
- **Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten as necessary to maintain stability and safety.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Set feels wobbly or unstable	Loose bolts or uneven surface.	Ensure all bolts are fully tightened. Place the set on a flat, level surface.
Difficulty assembling chair foot ring	Incorrect assembly sequence.	Try attaching the foot ring to the legs before fully securing the legs to the chair seat. Do not fully tighten bolts until all parts are aligned.
Swivel mechanism is stiff or noisy	Lack of lubrication or debris.	Clean the swivel mechanism and apply a silicone-based lubricant if necessary.
Missing or damaged parts	Shipping damage or packaging error.	Contact AECOJOY customer support immediately for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	AECOJOY
Model Number	16222BK
Material	Metal (Powder-coated steel frame), Wooden Fireproof Board (tabletop), Padded Textilene (cushions)
Color	Cream (cushions), Black/Dark Metal (frame)
Product Dimensions (Table)	27.75" (L) x 27.75" (W) x 36.4" (H) (Approximate, based on image)
Product Dimensions (Chair)	26.77" (L) x 27.95" (W) x 44.09" (H) (Approximate, based on image)
Item Weight	Approximately 65 pounds (total set)
Special Features	360° Swivel Functionality, All-Weather Conditions, Padded Cushions, Anti-slip feet
Weight Capacity (Chair)	Up to 350 lbs (based on image)

PARAMETERS



Image: A diagram illustrating the key dimensions of both the high-top bar table and the swivel bar stool, including height, width, and depth measurements, and the chair's weight capacity.

WARRANTY AND SUPPORT

AECOJOY provides a 1-year manufacturer warranty against defective workmanship or missing parts. For any problems, questions, or concerns regarding your product, please do not hesitate to contact our customer support team. Please have your model number (16222BK) and purchase information ready when contacting support.

Contact Information:

- Refer to your purchase documentation for specific contact details or visit the AECOJOY official website.

