Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pretty moment JY35

Pretty moment JY35 Garment Steamer Instruction Manual

MODEL: JY35

Brand: Pretty moment

1. Safety Instructions

Please read all instructions carefully before using the appliance and retain them for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury.

- **Power Supply:** Ensure the appliance is connected to a grounded power outlet with the correct voltage.
- **Water Usage:** Use distilled or demineralized water to prevent mineral buildup and extend product life. Do not overfill the water tank.
- **Hot Surfaces:** The soleplate and steam nozzle become very hot during operation. Avoid direct contact with skin. Use the provided heat-protective glove when handling hot surfaces or adjusting garments.
- **Automatic Shut-off:** The steamer features an auto-off function after 15 minutes in dry iron mode for safety.
- **High-Temperature Check:** The device includes an intelligent system to maintain constant temperature and prevent overheating.
- **Water Shortage Reminder:** An indicator will alert you when the water level is low.
- **Storage:** Always unplug and allow the steamer to cool completely before storing. Store in a dry, safe place.

2. Product Overview

The Pretty moment JY35 Garment Steamer is a versatile 2-in-1 device designed for efficient wrinkle removal and fabric care. It combines the functions of a steamer and a dry iron, offering convenience and professional results.



The Pretty moment JY35 Garment Steamer features a sleek white design with elegant rose gold accents, showcasing its compact form factor.

Key Features:

- **Powerful 1500W:** Ensures rapid heat-up in 20 seconds for quick steaming.
- **Versatile Ironing Modes:** Supports hang ironing, dry ironing, and steam ironing.
- **Adjustable Temperature Levels:** Three settings (Low, Medium, High) for various fabric types.
- **Large Detachable Water Tank:** 400ml capacity provides up to 25 minutes of continuous steam.
- **Extra-Large Ironing Teflon Top:** Features 5 steam spray holes for efficient wrinkle removal over a wide area.
- **Retractable Storage Hook:** For convenient hanging and space-saving storage.
- **Long Power Cord:** 6ft cord for flexible use.



This image highlights the steamer's retractable hook for convenient storage and its compact dimensions, making it easy to store in small spaces.

3. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:** Detach the 400ml water tank from the main unit. Open the rubber stopper and fill the tank with distilled or demineralized water. Close the stopper securely and reattach the tank to the steamer until it clicks into place.



The steamer features a large 400ml detachable water tank, designed for easy refilling and providing extended steaming time.

3. **Position the Steamer:** Use the retractable hook to hang the steamer on a clothes rail or a secure hook. Ensure the steamer is in a stable position.
4. **Connect Power:** Plug the 6ft power cord into a suitable grounded electrical outlet.

4. Operating Instructions

Power On and Preheating:

1. Press and hold the power button for 3 seconds to turn on the steamer. The indicator lights will illuminate.
2. The steamer will begin to preheat, which takes approximately 20 seconds. The indicator light will stop flashing when it's ready for use.

Selecting Steam Levels:

Press the power button repeatedly to cycle through the three steam levels:

- **Low:** For delicate fabrics like silk and synthetics.
- **Medium:** For general fabrics like cotton and blends.
- **High:** For heavy fabrics like denim and wool.



Choose from three adjustable steam levels to suit various fabric types, from delicate silks to sturdy denim, ensuring optimal wrinkle removal.

Steaming Techniques:

- **Hang Ironing:** Hang the garment on a hanger. Hold the steamer head close to the fabric and move it in a downward motion. Use the heat-protective glove to hold the bottom of the garment taut for best results.
- **Dry Ironing:** For a crisp finish, use the steamer in its flat position on an ironing board. The soleplate maintains a constant temperature.
- **Steam Ironing:** Combine the flat ironing technique with steam for stubborn wrinkles.



The versatile design allows for both vertical steaming of hanging garments and horizontal flat ironing on a surface, adapting to your needs.



Beyond clothing, the steamer can be used to refresh and sanitize household items like pillows and upholstery.

Official Product Video:

Watch the official product video to see the Pretty moment JY35 Portable Clothes Steamer in action, highlighting its quick heat-up, versatile ironing modes, and compact design.

5. Maintenance

- **Cleaning the Soleplate:** After the steamer has cooled, wipe the Teflon soleplate with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Cleaning the Water Tank:** Periodically rinse the water tank with clean water to remove any residue.
- **Descaling:** If you notice reduced steam output or mineral buildup, mix equal parts white vinegar and distilled water

in the tank. Heat the steamer and allow it to steam for a few minutes. Then, unplug and let it cool before emptying and rinsing thoroughly. Repeat if necessary.

- **Storage:** Ensure the water tank is empty and the steamer is completely cool before storing. Use the retractable hook for convenient storage.

6. Troubleshooting

If you encounter issues with your Pretty moment JY35 Garment Steamer, please refer to the following common solutions:

- **No Steam Output:**
  - Check if the water tank is filled and correctly installed.
  - Ensure the steamer has fully preheated (indicator light is steady).
  - Check for mineral buildup in the soleplate holes; perform descaling if necessary.
- **Water Leaking:**
  - Ensure the water tank stopper is securely closed.
  - Verify the water tank is properly seated in the main unit.
  - Avoid tilting the steamer excessively during use, especially when steaming horizontally.
- **Steamer Not Turning On:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the power button is pressed and held for 3 seconds to activate.

If problems persist, please contact Pretty moment customer support.

7. Specifications

Feature	Specification
Model Number	JY35
Power	1500W
Heat-up Time	20 Seconds
Water Tank Capacity	400ml
Continuous Steam Time	Up to 25 minutes
Ironing Modes	Hang Ironing, Dry Ironing, Steam Ironing
Temperature Levels	3 (Low, Medium, High)
Soleplate Material	Teflon

Power Cord Length	6ft
Item Weight	4.31 Pounds

8. Warranty & Support

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official Pretty moment website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Pretty moment. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4Z356T4

More documents and user manuals: **https://manuals.plus/**