**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### aoluiwlis AD065G2Uz

# User Manual for Chicony A21-200P2B 200W AC Adapter

Model: AD065G2Uz

Brand: aoluiwlis (Compatible with MSI Laptops)

## Introduction

This user manual provides essential information for the safe and effective use of your Genuine Chicony A21-200P2B 200W AC Adapter. This adapter is designed to provide reliable power to compatible MSI laptops and other devices requiring a 20V, 10A power supply with a 4.5x3.0mm barrel connector. Please read this manual thoroughly before using the product.

## Safety Information

To ensure safe operation and prevent damage to the adapter or your device, please observe the following safety precautions:

- Use the adapter only with devices that match its voltage (20V) and current (10A) specifications.
- Do not expose the adapter to water, moisture, or high humidity.
- Avoid dropping or subjecting the adapter to severe impacts.
- Do not attempt to open, modify, or repair the adapter. Refer servicing to qualified personnel.
- Ensure proper ventilation around the adapter during use to prevent overheating. Do not cover it.
- Disconnect the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.
- Use only the power cord supplied with the adapter or a compatible replacement.

## Product Overview

The Chicony A21-200P2B AC Adapter is a compact and powerful solution for your laptop's charging needs. It features a robust design and a standard barrel connector for wide compatibility.



Figure 1: Top view of the Chicony A21-200P2B 200W AC Adapter. This image displays the rectangular adapter unit with its input and output cables neatly coiled, highlighting its compact form factor.



Figure 2: Bottom view of the Chicony A21-200P2B 200W AC Adapter. This image shows the underside of the adapter, where various regulatory labels, model numbers, and electrical specifications are printed.




Figure 3: Close-up of the 4.5x3.0mm barrel connector. This detailed view highlights the specific size and design of the adapter's output plug, including the central pin, ensuring compatibility with specific laptop models.

## Setup Instructions

1. **Unpack the Adapter:** Carefully remove the AC adapter and any included power cords from its packaging.
2. **Connect the Power Cord:** If the power cord is detachable, connect one end of the AC power cord to the adapter's input port and the other end to a standard wall outlet (100-240V, 50-60Hz).
3. **Connect to Device:** Insert the 4.5x3.0mm barrel connector of the adapter's output cable firmly into the power input port of your compatible laptop or device. Ensure the connection is secure.
4. **Verify Connection:** Most laptops will indicate charging with an LED light or an on-screen icon. Verify that your device is receiving power.

*Note:* Always ensure the power outlet is easily accessible so you can quickly disconnect the adapter if needed.

## Operating Instructions

Once properly set up, the Chicony A21-200P2B adapter operates automatically to provide power to your device. It is designed for continuous use within its specified operating parameters.

- **Charging:** When connected to a compatible laptop, the adapter will automatically begin charging the laptop's battery and/or powering the laptop directly.
- **Temperature:** It is normal for the adapter to become warm during operation. However, if it becomes excessively hot, disconnect it immediately and check for proper ventilation or potential issues.
- **Travel Feature:** The compact design and universal input voltage (100-240V) make this adapter suitable for travel. Ensure you have the correct plug type (EU/US/UK/AU) for your region.

## Maintenance

Proper maintenance can extend the lifespan of your AC adapter:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Cable Care:** Avoid sharp bends or kinks in the cables. Do not place heavy objects on the cables.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Coil the cables loosely.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires, cracked casing, or bent pins on the connector. Discontinue use if damage is found.

## Troubleshooting

If you encounter issues with your adapter, try the following steps:

| Problem | Possible Cause | Solution |
|---|---|---|
| Adapter not powering device. | Loose connection, faulty outlet, incompatible device, damaged adapter. | • Ensure all cables are securely connected.<br>• Try a different wall outlet.<br>• Verify your device's power requirements match the adapter's specifications.<br>• Inspect the adapter and cables for visible damage. |
| Adapter is overheating. | Poor ventilation, excessive load, internal fault. | • Ensure the adapter is in an open area with good airflow.<br>• Do not cover the adapter.<br>• Disconnect and allow to cool. If overheating persists, discontinue use. |
| Device not charging fully or slowly. | Adapter not providing sufficient power, battery issue, background processes. | • Confirm the adapter's wattage (200W) is sufficient for your device.<br>• Check your device's battery health.<br>• Close unnecessary applications on your device. |

If the problem persists after trying these solutions, please contact customer support.

## Specifications

| | |
|---|---|
| **Model Number** | AD065G2Uz (Part Number: A21-200P2B) |
| **Input Voltage** | 100-240V ~ 50-60Hz |
| **Output Voltage** | 20.0V |
| **Output Current** | 10.0A |
| **Power Output** | 200.0W |
| **Connector Type** | 4.5x3.0mm Barrel Connector with central pin |

| | |
|---|---|
| **Compatible Devices** | Laptops (specifically compatible with MSI laptops) |
| **Color** | Black |
| **Special Feature** | Travel-friendly design |
| **Included Components** | 1 adapter |

## Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for warranty claims.
**Seller:** ouljie-us
For further assistance, you may visit the product page on Amazon:amazon.com/dp/B0D4Z3C86B

© 2024 aoluiwlis. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0D4Z3C86B**

More documents and user manuals: **https://manuals.plus/**