Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CTTINKT HLPM08VNM

Instruction Manual

Side Discharge Chute for Hart 40V Lawn Mower Models HLPM08 & HLPM08VNM

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your CTTINKT Side Discharge Chute. Designed as a direct replacement for OEM parts, this chute is compatible with Hart 40V Lawn Mower models HLPM08 and HLPM08VNM. Please read this manual thoroughly before use to ensure safe and efficient operation.

2. Product Overview

The CTTINKT Side Discharge Chute is a crucial component for your Hart 40V lawn mower, designed to direct grass clippings away from the mower deck during operation. This accessory helps maintain a cleaner cutting path and can be particularly useful when mulching is not desired or when dealing with taller grass.



Figure 2.1: CTTINKT Side Discharge Chute. This image shows the black plastic side discharge chute, designed to fit specific Hart 40V lawn mower models. The chute features a smooth, curved exterior and internal structural ribs for durability and proper airflow.

Key Features:

- OEM replacement for Hart 40V lawnmower models HLPM08 and HLPM08VNM.
- Durable construction for effective grass clipping discharge.
- Easy to install and remove.

3. Setup and Installation

Before installing the side discharge chute, ensure your lawn mower is turned off and the battery is removed to prevent accidental startup. Always wear appropriate safety gloves during installation.

1. **Prepare the Mower:** Locate the side discharge opening on your Hart 40V lawn mower (models HLPM08 or HLPM08VNM). If a mulching plug is installed, remove it.
2. **Position the Chute:** Align the CTTINKT Side Discharge Chute with the opening on the mower deck. The chute is designed to fit securely into the designated slots or hinges.
3. **Secure the Chute:** Gently push the chute into place until it clicks or locks securely. Ensure that the chute is firmly attached and does not wobble. Verify that the discharge opening is fully covered by the chute.
4. **Final Check:** Once installed, give the chute a gentle tug to confirm it is properly seated and will not dislodge during operation.

Note: Refer to your lawn mower's original instruction manual for specific details regarding its side discharge mechanism.

4. Operating Instructions

The side discharge chute is an accessory that modifies the way your lawn mower handles clippings. Its operation is integrated with the mower's normal use.

- **Mowing Direction:** When using the side discharge chute, it is generally recommended to mow with the discharge opening facing away from obstacles, flowerbeds, or areas where clippings are not desired.
- **Clipping Distribution:** The chute will direct clippings in a concentrated stream to the side. Adjust your mowing pattern to distribute clippings evenly or to deposit them in a specific area for collection.
- **Safety:** Always ensure no one is standing in the path of the discharge chute while the mower is operating. Keep hands and feet clear of the discharge opening.

5. Maintenance

Regular maintenance of your side discharge chute will ensure its longevity and proper function.

- **Cleaning:** After each use, or as needed, clean any accumulated grass clippings from the inside and outside of the chute. A stiff brush or a damp cloth can be used. Ensure the chute is dry before storage.
- **Inspection:** Periodically inspect the chute for any signs of wear, cracks, or damage. Check the attachment points for integrity. If the chute is damaged, replace it to ensure safe and effective operation.
- **Storage:** Store the chute in a clean, dry place when not in use.

6. Troubleshooting

Most issues related to the side discharge chute are minor and can be resolved with simple checks.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Chute not staying in place	Improper installation; damaged attachment points on chute or mower.	Re-install the chute, ensuring it clicks securely. Inspect chute and mower for damage; replace if necessary.
Poor grass discharge	Chute clogged with clippings; wet or excessively long grass.	Clear any blockages from the chute and mower deck (with mower off and battery removed). Mow when grass is dry and at an appropriate height.

7. Specifications

Attribute	Detail
Product Name	Side Discharge Chute
Brand	CTTINKT
Model Compatibility	Hart 40V Lawn Mower models HLPM08, HLPM08VNM
Color	Black
Part Number	635401072532
Item Model Number	HLPM08VNM
Package Dimensions	1 x 1 x 1 inches (approximate)

8. Warranty and Support

This CTTINKT Side Discharge Chute comes with a**one-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For Warranty Claims or Technical Support:

Please contact the seller or retailer from whom you purchased the product. For purchases made via Amazon, you may contact the seller "NHU Y SHOP HÂH" through your Amazon order history for assistance.
Please retain your proof of purchase for warranty validation.

© 2024 CTTINKT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4Z4NL8T

More documents and user manuals: **https://manuals.plus/**