

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GOVO](#) /

› [GOVO GoSurround 990 Dolby Digital 5.1 Channel Home Theatre Soundbar User Manual](#)

GOVO GoSurround 990

GOVO GoSurround 990 Dolby Digital 5.1 Channel Home Theatre Soundbar User Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your GOVO GoSurround 990 Dolby Digital 5.1 Channel Home Theatre Soundbar. Please read this manual thoroughly before use to ensure optimal performance and safety.

PACKAGE CONTENTS

The following items are included in your GOVO GoSurround 990 package:

- 1 x Soundbar
- 1 x Wireless Subwoofer
- 2 x Satellite Speakers
- 1 x Remote Control
- Power Cables
- HDMI ARC Cable
- Wall Mounting Kit

IMPORTANT SAFETY INFORMATION

- Read these instructions carefully before operating the device.
- Keep these instructions for future reference.
- Heed all warnings on the product and in the operating instructions.
- Follow all instructions for use and maintenance.
- Do not use this apparatus near water or moisture.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and

the point where they exit from the apparatus.

- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

PRODUCT OVERVIEW

The GOVO GoSurround 990 is a 5.1 channel home theatre soundbar system designed to deliver immersive audio. It features a main soundbar, a wireless subwoofer, and two satellite speakers for a complete surround sound experience.



An overview of the GOVO GoSurround 990 system, showcasing the main soundbar unit, the wireless subwoofer, and the two compact satellite speakers, all in black.

Main Components:

- **Soundbar:** The central unit housing multiple speakers and controls.
- **Wireless Subwoofer:** Provides deep bass frequencies, connecting wirelessly to the soundbar.


- **Satellite Speakers:** Two compact speakers for rear surround sound effects.
- **Remote Control:** For convenient operation and settings adjustment.



A visual representation of the soundbar's internal 5.1 channel configuration, highlighting how sound is projected from its multiple drivers to create a wide and dynamic soundstage.

Soundbar Rear Panel and Connections:

The rear panel of the soundbar features various ports for connecting your audio sources.



Mega Bass

With Wireless Subwoofer

Detail of the soundbar's rear panel, highlighting the various input ports including USB, SD card slot, AUX In, HDMI ARC, Optical, and DC power input for connecting different audio sources.

SETUP GUIDE

1. Placement

Optimal placement is crucial for the best audio experience.

- **Soundbar:** Place the soundbar centrally below your TV. It can be placed on a tabletop or wall-mounted.
- **Subwoofer:** Position the wireless subwoofer on the floor, ideally in the front of the room, near the soundbar. Experiment with placement for optimal bass response.
- **Satellite Speakers:** Place the satellite speakers behind your primary listening position, separated by approximately 10 feet, at ear level when seated. This creates an immersive surround sound field.



An illustration demonstrating the recommended arrangement for the GoSurround 990 system: the soundbar positioned below the television, the wireless subwoofer to the side, and the two satellite speakers placed behind the listening area to create an immersive 5.1 channel audio experience.

2. Connections

Ensure all components are powered off before making connections.

Power Connection:

Connect the power cables to the soundbar, subwoofer, and satellite speakers, then plug them into a power outlet.

Subwoofer Pairing:

The wireless subwoofer should automatically pair with the soundbar upon power-up. If not, refer to the troubleshooting section for manual pairing instructions.

Audio Connections:

Choose one of the following methods to connect your audio source:

- **HDMI ARC (Recommended):** Connect an HDMI cable from the HDMI ARC port on your soundbar to the HDMI ARC port on your TV. This allows your TV remote to control the soundbar volume.
- **Optical (OPT):** Connect an optical cable from the OPT port on your soundbar to the optical output on your TV or audio source.
- **AUX:** Connect a 3.5mm audio cable from the AUX port on your soundbar to the headphone jack or audio output on your device.
- **USB:** Insert a USB drive into the USB port for direct audio playback.
- **Bluetooth:** Pair your mobile device wirelessly. (See Operating Instructions for details).

OPERATING INSTRUCTIONS

Power On/Off

Press the Power button on the soundbar or remote control to turn the system on or off.

Input Source Selection

Press the "Input" button on the remote control or the soundbar to cycle through available input sources (HDMI ARC, Optical, AUX, USB, Bluetooth). The LED display will indicate the selected source.

Volume Control

Use the "VOL+" and "VOL-" buttons on the remote control or soundbar to adjust the master volume.

Equalizer Modes

The soundbar features 3 Equalizer Modes for optimized audio:

- **Movie Mode:** Enhances dialogue and cinematic effects.
- **News Mode:** Optimizes vocal clarity.
- **Music Mode:** Provides a balanced sound profile for music playback.

Press the "EQ" button on the remote to switch between these modes.

Bass and Treble Adjustment

Use the "BASS+" / "BASS-" and "TRE+" / "TRE-" buttons on the remote control to fine-tune the bass and treble levels.

Bluetooth Pairing

1. Select Bluetooth input mode on the soundbar.
2. On your mobile device, enable Bluetooth and search for "GOVO GoSurround 990".
3. Select the soundbar from the list to pair. A confirmation sound will indicate successful pairing.
4. Once paired, your device will automatically connect in the future when Bluetooth mode is selected.



5.1 Channel Dolby Audio Soundbar

Explosive drivers

The included remote control for the GoSurround 990, featuring dedicated buttons for power, volume, source selection, three equalizer modes (Movie, News, Music), and independent controls for bass and treble.

MAINTENANCE AND CARE

- Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofer, and satellite speakers. Do not use liquid cleaners or aerosols.
- Ventilation:** Ensure that the ventilation openings are not blocked to prevent overheating.
- Storage:** If storing the unit for an extended period, unplug it from the power outlet and store it in a cool, dry place.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active.	Check power connections; Try a different power outlet.

Problem	Possible Cause	Solution
No sound	Incorrect input source selected; Volume too low; Mute activated; Cables not connected properly.	Select correct input source; Increase volume; Deactivate mute; Reconnect audio cables securely.
Subwoofer not producing sound	Subwoofer not paired; Subwoofer power off.	Ensure subwoofer is powered on. If not paired, press the PAIR button on the back of the subwoofer and then on the soundbar (refer to specific pairing instructions if available in a full manual).
Bluetooth connection issues	Device too far; Interference; Soundbar not in pairing mode.	Ensure device is within 10 meters; Move away from other wireless devices; Ensure soundbar is in Bluetooth pairing mode.
Remote control not working	Batteries drained; Obstruction between remote and soundbar.	Replace batteries; Ensure clear line of sight to the soundbar's IR receiver.

SPECIFICATIONS

Feature	Detail
Model Name	GOVO GoSurround 990
Speaker Type	Soundbar with Wireless Subwoofer and Satellite Speakers
Surround Sound Channel Configuration	5.1
Total Output Power	525 Watts
Special Feature	Dolby Digital Enabled, Digital Signal Processing (DSP)
Connectivity Technology	Bluetooth v5.3, HDMI (ARC), Optical (OPT), AUX, USB
Bluetooth Range	10 Metres
Subwoofer Connectivity	Wireless
Woofer Diameter	6.5 Inches
Product Dimensions (Soundbar)	84W x 23.4D x 35.3H Centimeters (Approximate)
Item Weight	8.2 kg
Mounting Type	Tabletop or Wall Mount
Control Method	Remote
Power Source	Corded Electric
Colour	Black

WARRANTY AND SUPPORT

Warranty Information

Your GOVO GoSurround 990 comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact GOVO customer support. Contact details can typically be found on the GOVO official website or on the product packaging.