

20 SECOND SOAP Replacement Hose (15 Foot)

20 SECOND SOAP Replacement Hose Instruction Manual

Model: Replacement Hose (15 Foot) | Brand: 20 SECOND SOAP

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your 20 SECOND SOAP 15-foot replacement hose. This hose is designed for compatibility with various Shop Vac, Craftsman, and Ridgid wet/dry vacuums, including the Craftsman 16-gallon model 113.177000. Please read these instructions carefully before use to ensure safe and effective operation.

SETUP

Before connecting the replacement hose, ensure your wet/dry vacuum is unplugged from the power source to prevent accidental startup.

- Inspect the Hose:** Carefully uncoil the new 15-foot replacement hose. Check for any signs of damage, kinks, or obstructions.
- Remove Old Hose (if applicable):** If replacing an existing hose, disconnect it from the vacuum's inlet port. This usually involves twisting or pressing a release button, depending on your vacuum model.
- Connect New Hose:** Align the cuff of the new replacement hose with the vacuum's inlet port. Push firmly and twist clockwise until it locks securely into place. Ensure a snug fit to maintain proper suction.
- Attach Accessories:** Connect any desired vacuum attachments (e.g., nozzles, brushes) to the free end of the hose. Ensure these are also securely attached.



Image: The 15-foot replacement hose, ready for connection to a wet/dry vacuum. This image illustrates the hose's flexible design and connection cuff.

OPERATING

Once the hose is securely attached and the vacuum is plugged in, you can begin operation. Always refer to your specific wet/dry vacuum's instruction manual for detailed operating procedures.

- **Power On:** Turn on your wet/dry vacuum.
- **Vacuuming:** Use the hose and attached accessories to clean the desired area. The 15-foot length provides extended reach, reducing the need to frequently move the vacuum unit.
- **Wet vs. Dry Use:** Ensure your vacuum is configured correctly for wet or dry pickup (e.g., filter type) before use. The hose is suitable for both applications.
- **Avoid Obstructions:** Do not attempt to vacuum large, sharp, or hot objects that could damage the hose or vacuum.
- **Power Off:** After use, turn off the vacuum and unplug it from the power source.

MAINTENANCE

Regular maintenance helps prolong the life of your replacement hose and ensures optimal performance.

- **Cleaning:** After each use, especially after wet pickup, rinse the inside and outside of the hose with water to remove debris and prevent odors. Allow it to air dry completely before storage.
- **Storage:** Store the hose coiled neatly in a dry, cool place, away from direct sunlight and extreme temperatures. Avoid kinking or crushing the hose during storage.
- **Inspection:** Periodically inspect the hose for cracks, tears, or blockages. Clear any obstructions promptly to maintain suction.

TROUBLESHOOTING

If you encounter issues with your replacement hose, consider the following common solutions:

- **Loss of Suction:**
 - Check all connections: Ensure the hose is securely attached to the vacuum and all accessories are firmly in place.
 - Inspect for blockages: Disconnect the hose and check for any debris obstructing the airflow.
 - Examine the vacuum: Ensure the vacuum's filter is clean and the collection tank is not full.
- **Hose Damage:**
 - If the hose has visible cracks or tears, it may need to be replaced to restore full functionality.

SPECIFICATIONS

Feature	Detail
Brand	20 SECOND SOAP
Material	Aluminum (referring to connection points/reinforcement, main hose material is typically durable plastic/rubber composite)
Color	Multicolor
Item Length	15 Feet
UPC	748939708979
Compatibility	Shop Vac, Craftsman, Ridgid Wet & Dry Vacuums (e.g., Craftsman 16-gallon model 113.177000)

WARRANTY AND SUPPORT

For information regarding product warranty or technical support, please refer to the original purchase documentation or contact the seller directly. The manufacturer, 20 SECOND SOAP, stands behind the quality of its products.

Seller: SHEVTSOVAgo

For further assistance, please visit the product page on Amazon or contact Amazon customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D4ZKFQXH>

More documents and user manuals: **<https://manuals.plus/>**