EarFun SP500B

EarFun UBOOM X Portable Bluetooth Speaker User Manual

Model: SP500B | Brand: EarFun

INTRODUCTION

Thank you for choosing the EarFun UBOOM X Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. The UBOOM X delivers powerful 80W stereo sound with JumboBass technology, features IP67 waterproof and dustproof protection, offers up to 30 hours of playtime, and includes customizable RGB lights and EQ settings via the EarFun Audio App. Enjoy immersive audio experiences with TWS stereo pairing and Party Mode.

The EarFun UBOOM X speaker, showcasing its sleek design and vibrant RGB lighting.

What's in the Box

Please check the package contents to ensure all items are present:

- 1 × EarFun UBOOM X Bluetooth Speaker
- 1 × Type C Charging Cable
- 1 × Carrying Strap
- 1 × User manual

Setup

1. Charging the Speaker

Before first use, fully charge your EarFun UBOOM X speaker. Connect the provided Type-C charging cable to the

speaker's charging port and a compatible USB power adapter (not included). A full charge takes approximately 4 hours, providing up to 30 hours of playtime. A 10-minute quick charge can provide up to 3 hours of music.

The UBOOM X offers extended playtime, ideal for long listening sessions.

2. Bluetooth Pairing

1. Power on the EarFun UBOOM X speaker.
2. The Bluetooth indicator light will flash, indicating it's in pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "EarFun UBOOM X" in the list of available devices.
4. Select "EarFun UBOOM X" to connect. Once connected, the Bluetooth indicator will remain solid.

Bluetooth 5.3 Connection

The latest Bluetooth 5.3 for faster connections and smooth, uninterrupted playback.

The speaker utilizes Bluetooth 5.3 for stable and fast connections.

3. EarFun Audio App

Download the EarFun Audio App from your device's app store to unlock full customization features, including EQ settings and RGB light control.

* Waterproof and Dustproof is effective only when the cap on the back is closed. Not guaranteed for all situations.

Customize your sound and lighting effects using the EarFun Audio App.

OPERATING INSTRUCTIONS

Controls Overview

The control buttons are located on the top panel of the speaker:

- **Power Button:** Press and hold to power on/off.
- **Bluetooth Button:** Press to enter pairing mode.
- **Volume Buttons (+/-):** Adjust volume levels.
- **Multi-function Button:** Play/pause, answer/end calls.
- **Light Control Button:** Cycle through RGB light modes.
- **Party Mode Button:** Activate Party Mode for multi-speaker connection.

Front and back views of the EarFun UBOOM X, highlighting its control panel and ports.

TWS Stereo Surround & Party Mode

Enhance your audio experience by connecting multiple UBOOM X speakers:

- **TWS Stereo:** Pair two UBOOM X speakers for a true wireless stereo sound experience.
- **Party Mode:** Sync up to 50 EarFun UBOOM X speakers for an immersive, room-filling sound. Refer to the EarFun Audio App for detailed instructions on setting up Party Mode.

Party Mode

Easily connect up to 50 EarFun UBOOM X speakers for an explosive, wall-shaking sound that will dominate the party and immerse everyone in powerful sound.

UP TO 50

Connect up to 50 UBOOM X speakers for an expansive Party Mode experience.

Customizable EQ & RGB Lights

Use the EarFun Audio App to personalize your listening experience:

- **EQ Settings:** Choose from 30 preset EQ options or create your own custom sound profile.
- **RGB Lighting:** Adjust the dynamic RGB lighting to match your mood or music genre. Select from multiple light modes.

Power Bank Function

The UBOOM X features a built-in power bank function, allowing you to charge your mobile devices via the USB-C output port. This is ideal for outdoor emergencies.

30H Nonstop Playtime with Quick Charge

10 min charge for up to 3 hours of music

☀ 30 Std. ☽

* Fast charge test conducted with a 30W charger, 50% volume, and all other functions off.
* Actual performance vaires from settings, usage and enviormental conditions.

Utilize the speaker's power bank function to charge your devices on the go.

Hands-Free Carry Strap

The included detachable carrying strap provides convenient portability, making it easy to transport your speaker for outdoor activities.

The detachable strap enhances portability for outdoor adventures.

Crystal Calls via HD Built-in MIC

The integrated microphone ensures clear audio for hands-free calls and online meetings when connected to your smartphone.

Enjoy clear communication with the built-in HD microphone.

150ms Video Mode

Activate Video Mode via the EarFun Audio App to reduce audio latency to 150ms, ensuring synchronized audio for videos and gaming.

Experience low-latency audio for videos and games with Video Mode.

MAINTENANCE

IP67 Waterproof & Dustproof

The UBOOM X speaker is designed with IP67 rating, making it resistant to water and dust. This protection is effective only when the charging port cover on the back is securely closed. After exposure to water, ensure the speaker is completely dry before charging.

Unleash 80W Thunderous Deep Bass

Near-Zero Distortion Punchy Bass and Crisp Treble

reddot winner

JumboBass™ Technology

80W

2 x 30W 4" Subwoofers
with Vibrant LED Lights

2 x 10W 20mm Silk Tweeters

2 x Passive Bass Radiators

The IP67 rating ensures durability against water and dust for outdoor use.

TROUBLESHOOTING

If you encounter issues with your EarFun UBOOM X speaker, please try the following common troubleshooting steps:

- **No Power:** Ensure the speaker is fully charged. Connect it to a power source and check the charging indicator.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired via Bluetooth.
- **Bluetooth Connection Issues:** Turn off and on Bluetooth on your device and the speaker. Try unpairing and re-pairing the speaker. Ensure no other devices are interfering with the Bluetooth signal.
- **Distortion/Poor Sound Quality:** Reduce the volume. Ensure the audio source is of good quality. Adjust EQ settings via the EarFun Audio App.
- **App Not Connecting:** Ensure the speaker is powered on and Bluetooth is enabled on your device. Update the EarFun Audio App to the latest version.

For more detailed troubleshooting or persistent issues, please refer to the official EarFun support resources or contact customer service.

SPECIFICATIONS

Feature	Detail
Model Name	EarFun UBOOM X
Speaker Type	Subwoofer
Speaker Maximum Output Power	80 Watts
Connectivity Technology	Bluetooth 5.3
Battery Life	Up to 30 Hours
Water Resistance Level	IP67 Waterproof & Dustproof
Product Dimensions	5.9"D x 15.74"W x 8.5"H
Item Weight	9.15 Pounds
Special Features	TWS Stereo Surround & Party Mode, Customizable EQ & RGB Lights, Power Bank Function
Maximum Range	15 Meters
Audio Output Mode	Stereo

WARRANTY AND SUPPORT

EarFun products come with a standard warranty. For specific warranty terms and conditions, please refer to the official EarFun website or the warranty card included with your product.

For further assistance, product registration, or to access the latest user guides and FAQs, please visit the official EarFun store or contact their customer support:

Visit the EarFun Store on Amazon

Download User Manual (PDF)

**Related Documents - SP500B**

[EarFun Free Wireless Earbuds: FAQs and Troubleshooting Guide](#)
Find answers to common questions about EarFun Free wireless earbuds, including pairing, reset procedures, waterproofing, and connectivity. Get support for your Bluetooth headphones.

[EarFun Free 2S True Wireless Earbuds User Manual](#)
Comprehensive user manual for EarFun Free 2S True Wireless Earbuds, covering setup, features, functions, troubleshooting, and specifications. Learn how to pair, use the EarFun Audio app, and maintain your earbuds.

[EarFun UBOOM X Portable Bluetooth Speaker User Manual](#)
Comprehensive user manual for the EarFun UBOOM X portable Bluetooth speaker, covering setup, functions, specifications, and compliance information. Learn how to pair, charge, and use advanced features like True Wireless Stereo and Party Mode.

[EarFun UBOOM L - Manuel d'utilisation et spécifications](#)
Découvrez le manuel d'utilisation complet pour l'enceinte Bluetooth portable EarFun UBOOM L (modèle SP300). Apprenez à utiliser ses fonctions, à le connecter et à le configurer.

[EarFun UBOOM X Bluetooth Vezeték Nélküli Hangszóró Használati Utasítás](#)
Részletes használati útmutató az EarFun UBOOM X Bluetooth vezeték nélküli hangszóróhoz. Ismerje meg a termék funkcióit, párosítását, töltését, karbantartását és jótállási feltételeit.

[EarFun UBOOM L Přenosný Bluetooth Reproduktor - Návod k Použití](#)
Podrobný návod k použití pro přenosný Bluetooth reproduktor EarFun UBOOM L. Obsahuje informace o součástkách, nabíjení, technických údajích, párování Bluetooth, TWS, funkcích a postupech pro resetování. Optimalizováno pro vyhledávače.