

Focket FL-17L

Focket FL-17L 7-Head Foldable Multi Guitar Stand Instruction Manual

This manual provides detailed instructions for the Focket FL-17L 7-Head Foldable Multi Guitar Stand, covering assembly, operation, maintenance, and specifications. Designed for acoustic, electric, and bass guitars, this stand features wheels for easy mobility and protective foam for instrument safety.

PRODUCT OVERVIEW

The Focket FL-17L is a versatile, foldable multi-guitar stand designed to securely hold up to seven acoustic, electric, or bass guitars. Constructed from thickened iron pipe, it offers robust support and durability. Equipped with rotatable wheels and a brake function, this stand provides smooth mobility and stable positioning. The intimate sponge head protectors and anti-friction foam ensure your instruments are safeguarded against scratches and bumps.



The Focket FL-17L stand is designed to securely hold multiple guitars, suitable for various types including acoustic, electric, and bass.



Whole body thickened iron pipe

No need to worry about weight bearing

Intimate sponge head protector

Prevent guitar from rubbing against frame

This multi-function guitar display rack is universally compatible with acoustic, electric, and bass guitars, featuring rotatable wheels for easy movement.

SAFETY INFORMATION

- Ensure all parts are securely fastened before placing instruments.
- Do not overload the stand beyond its stated capacity (up to 7 guitars for FL-17L).
- Engage wheel brakes when the stand is in its desired position to prevent accidental movement.
- Place the stand on a flat, stable surface to avoid tipping.
- Keep out of reach of small children and pets.

PACKAGE CONTENTS

Please verify that all the following components are included in your package:

- 7 x Bracket Rods (for FL-17L model)
- 4 x Wheels

- 1 x Accessories Package (contains screws, nuts, and tools for assembly)
- Main Frame Components (base bars, vertical supports)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Focket FL-17L Guitar Stand:



The stand arrives in a compact, folded configuration, making initial setup and storage convenient.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the package contents list.
2. **Attach Wheels:** Securely attach the four wheels to the base frame components using the provided screws and tools. Ensure the wheels with brakes are positioned for easy access.



Attach the rotatable wheels to the base frame. Ensure the wheels with brake functionality are accessible for locking the stand in place.

3. **Assemble Base Frame:** Connect the horizontal base bars to the vertical support posts. Ensure all connections are tight and stable.



The robust metal rod core and sturdy non-slip base provide stability, while the folding mechanism allows for compact storage.

4. **Install Bracket Rods:** Insert the 7 bracket rods into the designated slots on the upper horizontal bar. These rods are covered with protective foam.
5. **Final Check:** Once assembled, gently shake the stand to ensure all connections are firm and the stand is stable. Engage the wheel brakes.

OPERATING THE GUITAR STAND

Proper use of your guitar stand ensures instrument safety and ease of access:

- **Positioning:** Roll the stand to your desired location. Engage the wheel brakes by pressing down on the lever on each braked wheel to secure the stand in place.
- **Placing Guitars:** Carefully place your acoustic, electric, or bass guitars into the individual slots. Ensure the neck rests against the protective foam rod at the top and the body rests on the foam-covered base bars.

Universal for guitar and bass

Multi-function guitar display rack

Rotatable wheels and thick bearings

Smooth and easy movement
with brake function



The stand's whole body is constructed from thickened iron pipe, ensuring high weight-bearing capacity and long-term durability for your instruments.

- **Capacity:** The FL-17L model is designed to hold up to 7 guitars. Distribute the weight evenly for optimal stability.



Intimate sponge head protectors and soft, tough anti-friction foam surround the core, preventing scratches and damage to your guitar's headstock and body.

- **Moving the Stand:** To move the stand, disengage the wheel brakes. Gently push or pull the stand to its new location. Re-engage the brakes once positioned.

MAINTENANCE

Regular maintenance will prolong the life of your guitar stand:

- **Cleaning:** Wipe the stand with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Foam Protection:** Inspect the protective foam on the bracket rods and base bars for wear or damage. Replace if significantly worn to prevent instrument damage.
- **Wheel Functionality:** Ensure wheels rotate freely and brakes engage effectively. Lubricate wheel axles if movement becomes stiff.

TROUBLESHOOTING

Issue	Possible Cause / Solution
Stand is wobbly	Check all screws and connections; tighten as needed. Ensure the stand is on a flat, level surface.
Wheels not rolling smoothly	Check for debris caught in the wheels. Ensure wheel brakes are disengaged. Lubricate wheel axles if necessary.
Guitars not fitting securely	Ensure guitars are placed correctly in the slots. Verify the protective foam is intact and properly positioned.
Brakes not holding	Ensure the brake levers are fully engaged. Inspect brake mechanisms for damage or wear.

SPECIFICATIONS

Brand: Focket

Model: FL-17L (7-head capacity)

Material: Thickened Iron Pipe

Capacity: Up to 7 acoustic, electric, or bass guitars (FL-17L)

Dimensions (FL-17L):

- Length: Approx. 81.5 cm (32.1 in)
- Width: Approx. 48 cm (18.9 in)
- Height: Approx. 71 cm (28 in)

Features: Foldable design, Rotatable wheels with brake function, Sponge head protectors, Anti-friction foam, Sturdy non-slip base.

Country of Origin: China



Detailed dimensions of the FL-17L model: approximately 71cm (28in) height, 48cm (18.9in) width, and 81.5cm (32.1in) length.

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty details, support, or replacement parts, please refer to the documentation included with your purchase or contact Focket customer service through their official website or your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question