Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

oneisall RFC-676

oneisall Dog Clippers

INSTRUCTION MANUAL

1. Safety Information

Please read all safety and operating instructions carefully before using the oneisall Dog Clippers. Keep this manual for future reference.

- **Caution:** Sharp blades. Handle with care. Keep away from children.
- Do not use on humans.
- **Electrical Safety:** Ensure that the voltage indicated on the rating label matches your electrical outlet. Do not immerse the appliance in water or any other liquids to avoid electric shock.
- **WARNING:** Keep the appliance dry during charging.
- **Supervision:** This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Regular Checks:** Periodically check the clippers for damage. If the appliance or power cord shows any sign of damage, do not use it. Contact the service center for repair or replacement.
- While waterproof, avoid prolonged submersion.
- Always follow proper cleaning and maintenance instructions.



GPSR Produkt-Informationen

EC REP
Name : Apex CE Specialists GmbH
Add : Grafenberger Allee 277-287,40237 Düsseldorf,DE
Contact Person: Wells Yan
Tel: +353212066339
E-mail: Info@apex-ce.de

UK REP
Name: APEX CE SPECIALISTS LIMITED
Add: 6f East Union Street, Manchester, England, M16 9AE
Contact: Wells
Tel : +441616371080
E-Mail: Info@apex-ce.com

GPSR-Manufacturer Info:
Business Name: chuzhouguanyidianzishangwuyouxiangongsi
Manufacturer Address: CN, 239200, anhui, chuzhoushi, laianxian, xinanzhenqingliuxilu, taixinxiangzhangyuan1dong1danyuan2403shi
Telefonnummer: +86 130 4980 3796
E-Mail: oneisallofficial@hotmail.com

Image: Important safety guidelines for the clippers.

2. Product Overview

The oneisall Dog Clippers are designed for efficient and quiet grooming of pets with thick and heavy coats. Featuring stainless steel blades and a cordless, waterproof design, these clippers offer a comfortable and effective grooming experience for both pet and owner.

Key Features:

- **Stainless Steel Blades:** Specifically designed for thick and matted hair, providing a firmer, easier, and faster grooming experience compared to ceramic blades.
- **Low Noise & Vibration:** Operates at less than 55dB, ensuring a calm grooming environment for your pet.
- **Long Battery Life:** 2000mA high-capacity battery provides up to 240 minutes of continuous use on a 2-hour charge via USB.
- **Cordless Design:** Offers flexibility for indoor and outdoor use, with a special locking function for safe transport.
- **IPX7 Waterproof:** The entire body is washable for thorough and easy cleaning.
- **Detachable Combs:** Includes 10 different sizes (3mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm) for versatile styling.



Image: The oneisall Dog Clippers with its full set of comb attachments, alongside two well-groomed dogs.



Image: The clippers in action, demonstrating their ability to easily cut through matted dog fur.



Image: A visual representation of the clippers' low noise and vibration, comparing it to common sounds.




Image: The clipper's smart digital LCD display, indicating battery percentage, oil drip reminder, and security lock status.



Image: Demonstrating the clippers' effectiveness in trimming thick pet coats, suitable for various breeds.



Image: Detailed dimensions and key specifications of the oneisall Dog Clippers, including model number and charging information.

3. Setup

Charging the Clippers:

Before first use, fully charge the clippers. Connect the USB charging cable to the clipper's charging port and a 5V/1A USB power adapter (not included), computer, or power bank. The LCD display will show the charging progress. A full charge takes approximately 2 hours and provides up to 240 minutes of operating time.



Image: The battery display and various USB charging options for the clippers.

Attaching Guide Combs:

Select the desired guide comb size (from 3mm to 25mm) based on the desired hair length. Align the comb with the clipper blade and snap it securely into place. Ensure the comb is firmly attached before beginning grooming.



Image: A close-up of the clipper blade and the various guide comb sizes available for different grooming lengths.

4. Operating Instructions

Preparing Your Pet:

Before grooming, ensure your pet's coat is clean, dry, and free of tangles or mats. Brushing your pet thoroughly beforehand will help the clippers glide smoothly and prevent pulling.

Grooming Process:

1. Turn on the clippers by pressing the power button.
2. Hold the clippers firmly and at a slight angle against your pet's coat.
3. Move the clippers slowly and steadily in the direction of hair growth.
4. For best results, use short, overlapping strokes.
5. The low noise and vibration design helps keep pets calm during grooming.



Image: The clippers in action, demonstrating their ability to easily cut through matted dog fur.

Safety Lock Function:

To prevent accidental activation, the clippers feature a safety lock. Long press the power button to activate or deactivate the lock. A lock icon will appear on the LCD display when the security lock is engaged.



Image: Illustration of the safety lock function on the clippers to prevent miscontact.

Product Video:

Video: Watch a demonstration of the oneisall dog clippers in use for grooming various breeds. This video showcases the clippers' performance and ease of handling during a grooming session.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your oneisall Dog Clippers.

Cleaning the Clippers:

The IPX7 waterproof design allows for easy cleaning. Disconnect the clippers from the power source before cleaning.

1. Use the included cleaning brush to remove any hair from the blades.
2. Rinse the entire body of the clippers under running water.
3. Wipe the clippers dry with a clean cloth.

Oiling the Blades:

Regular oiling is crucial for maintaining blade sharpness and smooth operation. The LCD display will show an oil drip reminder when needed.

1. Apply a few drops of lubricating oil (included) to the blades.
2. Turn on the clippers for a few seconds to distribute the oil evenly.

Note: The stainless steel blade cannot be disassembled. Do not attempt to remove the blade.




Image: A step-by-step guide on how to clean and oil the clipper blades for proper maintenance.

6. Troubleshooting

If you encounter issues with your oneisall Dog Clippers, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Clippers not cutting effectively / pulling hair	Blades are dull, dirty, or not oiled. Hair is matted or tangled.	Clean the blades thoroughly and apply lubricating oil. Ensure pet's coat is clean, dry, and detangled before grooming. If issues persist, contact customer service.
Clippers not turning on	Battery is low or depleted. Safety lock is engaged.	Charge the clippers fully. Deactivate the safety lock by long-pressing the power button.
Unusual noise or vibration	Hair caught in blades, or blades require oiling.	Clean the blades and apply oil. If the problem persists, discontinue use and contact customer service.

If troubleshooting steps do not resolve the issue, please contact oneisall customer service for further assistance.

7. Specifications

Specification	Detail
Model Number	RFC-676
Item Weight	311 Grams (11 ounces)
Dimensions (LxWxH)	7.2 x 2.2 x 1.6 inches
Blade Material	Stainless Steel
Battery Type	1 Lithium Polymer (included)
Battery Capacity	2000mA
Charging Time	2 hours
Operating Time	Up to 240 minutes
Noise Level	Below 55dB
Waterproof Rating	IPX7
Included Guide Combs	3mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm (10 sizes)

8. Warranty and Support

Your oneisall Dog Clippers come with a**24-month product protection plan** from the date of purchase. This warranty covers manufacturing defects and ensures your product performs as expected.

Customer Service:

For any questions, concerns, or warranty claims, please contact oneisall customer service. We are committed to providing 24-hour customer service to ensure your satisfaction.

Email: oneisallofficial@hotmail.com



Image: oneisall's commitment to customer satisfaction, highlighting 24-hour customer service and a 2-year warranty.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D541RBCN

More documents and user manuals: **https://manuals.plus/**