GOBOULT Airbass Earbuds

Boult Klarity 1 TWS Earbuds Instruction Manual

Model: Airbass Earbuds (Skyline Grey)

1. INTRODUCTION

Welcome to your new Boult Klarity 1 TWS Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as extended playtime, dual device pairing, environmental noise cancellation, and low-latency gaming mode. This manual will guide you through the setup, operation, and maintenance of your device.

2. WHAT'S IN THE BOX

Please ensure all items are present in the package:

- Boult Klarity 1 TWS Earbuds (Skyline Grey)
- Wireless Charging Case
- Extra Pair of Eartips
- Type-C Fast Charging Cable
- User Manual
- Warranty Card

Image: Boult Klarity 1 TWS Earbuds and charging case, highlighting key features and available colors.

3. PRODUCT FEATURES

3.1 Design and Comfort

- **Liquid Metal Procranium Body:** Features a sleek and durable liquid metal procranium body for enhanced durability and a premium look.
- **Ergonomic Fit:** Designed for comfortable wear with a breathable open-fit design, plush tailored ear-fit, and balanced weight distribution for maximum ergonomic comfort. The curved stem design helps prevent ear fatigue.
- **IPX5 Water Resistance:** Built to withstand sweat and rain, making them suitable for workouts and outdoor activities.

Image: Overview of Boult Klarity 1 design and sound quality.

Image: Detailed view of the ergonomic design for comfort.

3.2 Audio Quality

- **13mm Rich Bass Drivers:** Experience powerful, deep bass and immersive sound with large 13mm BoomX™ drivers.
- **Klarity™ Signature Sound:** Provides high-resolution audio for superb clarity.

Image: Internal structure highlighting the 13mm bass drivers.

3.3 Connectivity

- **Bluetooth 5.4:** Ensures stable and efficient wireless connection.
- **Dual Device Pairing (Multipoint Connectivity):** Connect to two devices simultaneously and seamlessly switch between them (e.g., phone and laptop).
- **Blink & Pair™:** For swift and easy pairing.

Image: Illustration of dual device pairing capability.

3.4 Battery and Charging

- **80 Hours Total Playtime:** Extended battery life for marathon listening sessions.
- **Type-C Fast Charging (Lightning Boult™):** 10 minutes of charge provides up to 180 minutes (3 hours) of playback.

Image: Charging case illustrating battery life and fast charging feature.

3.5 Calling and Gaming

- **4 Clear Calling ENC Mics (Zen™ Quad Mic ENC):** Equipped with four Environmental Noise Cancellation microphones for crystal-clear calls even in noisy environments, providing accurate voice isolation.
- **45ms Low Latency Gaming Mode (Combat™ Gaming Mode):** Provides near-instant audio sync for an enhanced gaming performance.

Image: Features for voice assistant, water resistance, and ENC microphones.

Image: Earbuds demonstrating low latency gaming mode.

4. SETUP GUIDE

4.1 Initial Charging

1. Open the charging case and place both earbuds inside.
2. Connect the provided Type-C charging cable to the charging port on the case and a power source.
3. The indicator light on the case will show charging status. Ensure the earbuds and case are fully charged before first use (approximately 100 minutes for a full charge).

4.2 Pairing with a Device

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode (Blink & Pair™).
3. On your device (smartphone, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "Boult Klarity 1" from the list of found devices to connect.
5. Once connected, a confirmation sound or indicator will be visible.

4.3 Dual Device Pairing

1. Pair the earbuds with your first device as described in Section 4.2.
2. Disable Bluetooth on the first device. The earbuds will re-enter pairing mode.
3. Pair the earbuds with your second device.
4. Re-enable Bluetooth on the first device. The earbuds should now be connected to both devices simultaneously, allowing for seamless switching.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The Boult Klarity 1 earbuds feature intuitive touch controls. Specific functions may vary, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press on either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud (Google Assistant, Siri).

- **Volume Control:** Long press on the right earbud for volume up, long press on the left earbud for volume down.
- **Gaming Mode:** Specific gesture (refer to the included User Manual for exact details).

5.2 Voice Assistant

Activate your device's voice assistant (Google Assistant, Siri) with a triple tap on either earbud. You can then use voice commands for various functions.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Remove and clean the eartips periodically. Ensure they are completely dry before reattaching.
- **Charging Contacts:** Keep the charging contacts on both the earbuds and inside the case clean and dry to ensure proper charging.
- **Water Resistance:** While IPX5 rated (water resistant), avoid submerging the earbuds in water. Dry them thoroughly if they get wet from sweat or rain.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged.

7. TROUBLESHOOTING

If you encounter issues with your Boult Klarity 1 earbuds, try the following solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place earbuds back in the case, close, then open the lid to re-enter pairing mode. Disable and re-enable Bluetooth on your device. Forget/remove "Boult Klarity 1" from your device's Bluetooth list and try pairing again.
No sound or low volume	Check device volume and earbud volume. Ensure earbuds are properly seated in your ears. Clean eartips and earbud grilles. Reconnect the earbuds to your device.
Charging issues	Ensure the charging cable is securely connected. Check if the power source is working. Clean the charging contacts on both earbuds and case. Try a different Type-C cable or power adapter.
Call quality issues	Ensure earbuds are fully charged. Move to a quieter environment if experiencing excessive background noise. Ensure microphones are not obstructed.

8. SPECIFICATIONS

Feature	Detail
Model Name	Airbass Earbuds
Connectivity Technology	Bluetooth 5.4, Wireless
Audio Driver Size	13 Millimetres
Audio Driver Type	Dynamic Driver
Battery Life	80 Hours (Total Playtime)
Charging Time	100 Minutes (Full Charge)
Fast Charging	10 minutes charge for 180 minutes playback
Audio Latency	45 Milliseconds (Gaming Mode)
Noise Control	Passive Noise Cancellation, Sound Isolation, 4 Clear Calling ENC Mics
Water Resistance Level	IPX5 Water Resistant
Control Type	Call Control, Touch Control, Volume Control, Voice Assistant (Google Assistant, Siri)
Material	Plastic (Liquid Metal Procranium Body)
Item Weight	43.2 g (Earbuds + Case)
Product Dimensions	57.3 x 29.6 x 52.4 cm
Included Components	Extra Pair of Eartips, Type-C Fast Charging Cable, User Manual, Warranty Card, Wireless Charging Case

9. WARRANTY AND SUPPORT

Your Boult Klarity 1 TWS Earbuds come with a standard brand warranty. Please refer to the included Warranty Card for specific terms and conditions.

For further assistance, replacement options, or detailed information regarding EMI options, please visit the product detail page on Amazon.in or contact GOBOULT customer support.

Manufacturer: Boult, B-67 Wazirpur Industrial Area, New Delhi 110052