Walker Edison FRAB4CMO-2PK

User Manual: Mid-Century Modern 1-Drawer Nightstand (Set of 2)

Brand: **Walker Edison** | Model: **FRAB4CMO-2PK**

Introduction

Thank you for choosing the Walker Edison Mid-Century Modern 1-Drawer Nightstand. This manual provides essential information for the proper assembly, operation, maintenance, and care of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Figure 1: Walker Edison Mid-Century Modern 1-Drawer Nightstand (Set of 2)

Safety Information

This product is designed for residential use. Please observe the following safety guidelines:

- Always follow assembly instructions carefully. Incorrect assembly can lead to instability and injury.
- Do not exceed the maximum weight recommendation of 50 pounds for the nightstand.
- Keep small parts and hardware away from children during assembly to prevent choking hazards.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- Place the nightstand on a level surface to prevent tipping.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm (Proposition 65 warning).

Package Contents

Before beginning assembly, verify that all components and hardware are present and undamaged. If any parts are missing or damaged, please contact customer support.
The package includes:

- 2 x Nightstand Units (disassembled)
- Assembly Guide
- Installation Tool (likely an Allen wrench or similar)
- All necessary hardware (screws, dowels, drawer glides, etc.)

Tools Recommended For Assembly: Screw Driver.

Assembly Instructions

Assembly is required for this product. It is recommended that 2 people assemble this unit. Please refer to the included Assembly Guide for detailed, step-by-step instructions and diagrams. Pay close attention to the orientation of parts, especially drawer sliders and side panels, as noted in customer feedback.

Key Assembly Points:

1. **Unpack and Organize:** Lay out all parts on a clean, soft surface (like a blanket or carpet) to prevent scratches. Group similar hardware together.
2. **Assemble the Frame:** Follow the guide to connect the main panels of the nightstand body. Ensure all cam locks and screws are tightened securely.
3. **Install Drawer Glides:** Carefully attach the smooth metal drawer glides to the nightstand frame and the drawer box. Ensure the movable part of the drawer slider is positioned towards the front of the unit.
4. **Assemble the Drawer:** Construct the drawer box and attach the minimalist metal hardware knob.
5. **Attach Legs:** Secure the sturdy X-shaped legs to the base of the nightstand. Ensure they are firmly attached and stable.
6. **Insert Drawer:** Carefully slide the assembled drawer into the installed glides.




Figure 2: Detail of Smooth Metal Drawer Glides



Figure 3: Sturdy X-Shaped Legs

Operation

The Walker Edison Nightstand is designed for convenient storage and display. It features one drawer and an open cubby.

- **Drawer Use:** Gently pull the knob to open the drawer. Push to close. Avoid forcing the drawer, as this can damage the glides.
- **Open Cubby:** Use the open cubby for displaying decorative items, books, or for easy access storage.
- **Weight Capacity:** Do not place items heavier than 50 pounds on the nightstand's top surface or inside the drawer/cubby. Distribute weight evenly.



Figure 4: Simple & Sleek Storage Space

Maintenance and Care

Proper care will extend the life and appearance of your nightstand:

- **Cleaning:** Wipe with a dry cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the durable laminate finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent staining or warping.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Do not place hot items directly on the surface. Use coasters or protective pads. Avoid excessive moisture.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary.

Troubleshooting

Problem	Possible Cause	Solution
Nightstand is wobbly/unstable.	Uneven floor; loose fasteners; incorrect leg assembly.	Ensure nightstand is on a level surface. Check and tighten all assembly screws. Verify legs are attached correctly according to the assembly guide.
Drawer does not slide smoothly or gets stuck.	Drawer glides misaligned or damaged; incorrect installation of glides.	Check that drawer glides are properly aligned and securely fastened to both the drawer and the nightstand frame. Ensure the movable part of the glide is facing the front. Refer to assembly instructions for correct glide orientation.
Visible gaps between panels.	Fasteners not fully tightened; panels misaligned during assembly.	Ensure all cam locks and screws are fully tightened. Disassemble and reassemble the affected section, ensuring panels are flush before tightening.

Specifications

Feature	Detail
Brand	Walker Edison
Model Name	Mid-Century
Model Number	FRAB4CMO-2PK
Product Dimensions (D x W x H)	11.88"D x 18.88"W x 21.88"H
Item Weight	18 Pounds (per unit)
Maximum Weight Recommendation	50 Pounds
Color	Mocha
Material Type	Engineered Wood, Metal (hardware)
Number of Drawers	1 (per unit)
Assembly Required	Yes
Recommended Number of People for Assembly	2



Figure 5: Product Dimensions

Warranty and Support

Manufacturer Warranty: This product comes with a 90-day limited manufacturer warranty. Please refer to the warranty details provided with your purchase for specific terms and conditions.
User Guide (PDF): A detailed user guide in PDF format is available for download. This document provides comprehensive assembly instructions and additional product information. You can access it via this link: Walker Edison Nightstand User Guide PDF
For further assistance, missing parts, or warranty claims, please contact Walker Edison customer support through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question