

Keter 259805

Keter Ashwood 100 Gallon Resin Deck Box User Manual

Model: 259805

PRODUCT OVERVIEW

The Keter Ashwood 100 Gallon Resin Deck Box is designed for outdoor storage, offering a blend of aesthetics and durability. It features innovative DecoCoat technology, providing the look and feel of natural wood without the associated maintenance. This deck box is suitable for storing patio cushions, throw pillows, garden tools, and pool toys, helping to keep your outdoor space organized.

Key features include:

- Made with innovative DecoCoat technology that prevents real wood problems, with less upkeep.
- Premium construction in stunning wood-look finishes, delivers style and beauty your outdoor storage.
- The Signature collection stunning finishes are built to last a lifetime. No maintenance. No fading. No hassle.
- Easy lift and soft close mechanism pulls the top completely open and shut slowly with minimal effort - easy for kids to use and not smashed fingers.
- With its stylish design this deck box is meant to be seen in your backyard and not hidden.



Figure 1: Keter Ashwood 100 Gallon Resin Deck Box, showcasing its wood-look finish and overall design.

SETUP AND ASSEMBLY

The Keter Ashwood Deck Box is designed for relatively easy assembly. While detailed step-by-step instructions are typically provided within the product packaging, the general process involves interlocking panels and securing components. It is recommended to assemble the unit on a flat, stable surface.

Ensure all parts are present before beginning assembly. Refer to the included instruction manual for specific diagrams and fastening procedures. Proper assembly ensures the structural integrity and weather resistance of the deck box.

Double Wall Construction

Extra Strength without Extra Weight



Figure 2: Illustration of the double-wall construction, highlighting the robust design for durability.

OPERATION

The deck box features an easy-lift lid with hydraulic pistons for smooth and safe operation. To open, gently lift the lid. The hydraulic pistons will assist in raising and holding the lid open. To close, gently pull the lid down; the soft-close mechanism will ensure it shuts slowly and securely.

The deck box is designed for versatile storage of various outdoor items, including:

- Patio Cushions
- Sports Equipment
- Garden Tools
- Pool Supplies


For added security, the deck box is lockable. A padlock (not included) can be used with the integrated latch mechanism.




Figure 3: Detail of the hydraulic piston mechanism, which provides easy lift and soft close functionality for the lid.

ASHWOOD 100G

Versatile Storage



Patio
Cushions



Sports
Equipment



Garden
Tools



Pool
Supplies



Figure 4: The deck box with its lid open, demonstrating its capacity for storing patio cushions and other outdoor essentials.

MAINTENANCE AND CARE

The Keter Ashwood Deck Box is constructed from durable resin material with DecoCoat technology, designed for minimal

maintenance. It is UV-resistant and water-resistant, ensuring it stands up to various weather conditions without fading, splintering, rotting, or rusting.

To clean the deck box, simply wipe it down with a damp cloth and mild soap. For more thorough cleaning, it can withstand pressure washing. Avoid using abrasive cleaners or harsh chemicals, as these may damage the surface finish.



Figure 5: The deck box is designed to withstand all weather conditions, being both UV-resistant and water-resistant.



Figure 6: The lid of the deck box showing its water-resistant properties, with water beading on the surface.

TROUBLESHOOTING

Most issues with the Keter Ashwood Deck Box can be resolved with simple checks. If you encounter any problems, please review the following common scenarios:

- **Lid not closing properly:** Ensure no items are obstructing the lid's path or the hydraulic pistons. Check for any debris along the edges of the box.
- **Water accumulation inside:** Verify that the lid is fully closed and sealed. Ensure the deck box is placed on a level surface to prevent water pooling around the base. While water-resistant, extreme conditions or improper closure can lead to moisture.
- **Difficulty during assembly:** Re-check the instruction manual for the specific step you are on. Ensure all parts are correctly oriented and aligned before applying force. Do not force parts together if they do not fit easily.
- **Fading or discoloration:** The DecoCoat technology is designed to prevent fading. If you notice any unusual discoloration, ensure the box is not exposed to unusually harsh chemicals or extreme, prolonged direct sunlight beyond typical outdoor conditions.

For issues not covered here, please contact Keter customer support.

SPECIFICATIONS

Attribute	Detail
Brand	Keter
Model Number	259805
Color	Ashwood
Material	Resin
Capacity	100 Gallons
Product Dimensions (L x W x H)	24"L x 48.4"W x 27.8"H
Item Weight	41.3 Pounds
Special Feature	Lockable
Water Resistance Level	Water Resistant
Opening Mechanism	Hinge (with hydraulic pistons)
UPC	731161061219



100 Gallon



Weight Capacity




Figure 7: Product dimensions and 100 Gallon capacity with 660 lbs weight capacity.

WARRANTY AND SUPPORT

Keter is committed to providing high-quality outdoor storage solutions. While specific warranty details may vary, Keter products are generally known for their durability and long-lasting performance, backed by over 75 years of experience in the industry.

For any questions, concerns, or support needs regarding your Keter Ashwood Deck Box, please contact Keter customer service. Support is based in the USA to assist you promptly.

You can find more information and contact details by visiting the official Keter website or the Keter Store on Amazon: [Keter Amazon Store](#).



Number One
Deck Box Brand



76 Years of
Excellence



Customer Service
Based in the US

Figure 8: Keter's commitment to quality and customer support, highlighting their long-standing excellence and US-based service.