

[Manuals.plus](#) /

› [AdamPark](#) /

› AdamPark 6-in-1 Air Styling & Drying System Instruction Manual

AdamPark B0D5678YKC

AdamPark 6-in-1 Air Styling & Drying System

Model: B0D5678YKC

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Hot Surfaces:** Attachments can become very hot during and after use. Always use the provided heat protection glove when changing or handling attachments to avoid burns. Do not touch hot surfaces with bare hands.
- **Initial Use Odor:** A slight odor may be present during the first few uses due to the new motor. This is normal and will dissipate quickly.
- **Power Disconnection:** Always unplug the appliance from the power outlet when not in use, before cleaning, or before performing any maintenance.
- **Water and Moisture:** Do not use this appliance near water, in a bathroom, or in any damp environment. Do not immerse the appliance in water or any other liquid.
- **Children:** Keep this appliance out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Power Cord:** Do not operate the appliance with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- **Overheating Protection:** The appliance is equipped with overheating protection. If it overheats, it will automatically shut off. Unplug the unit and allow it to cool down before resuming use.
- **ALCI & UL Safety Plug:** This appliance features an Appliance Leakage Current Interrupter (ALCI) and is UL safety certified for your protection. Test the ALCI plug before each use as instructed.

PRODUCT OVERVIEW

The AdamPark 6-in-1 Air Styling & Drying System is a versatile hair tool designed for various styling needs. It includes a main unit and multiple interchangeable attachments.

Package Contents:

- 1 x Main Styling Unit
- 1 x High-Speed Hair Dryer Attachment
- 2 x 32mm Auto Wrap Curling Iron Attachments (Left & Right)
- 1 x Round Volumizing Brush Attachment

- 1 x Hair Straightener Brush Attachment
- 1 x Soft Smoothing Brush Attachment
- 1 x Heat Protection Glove
- Hair Clips (quantity may vary)
- Cleaning Brush (for filter)
- Storage Bag



Image: The main styling unit and its six interchangeable attachments.

6 IN 1 MULTIFUNCTIONAL HAIR DRYER STYLER



Straightening Brush



High Speed Hair Dry



Volumizing Brush



Left/Right Curling Iron



Smoothing Brush

Image: All components of the AdamPark 6-in-1 system, including the main unit, various styling attachments, hair clips, and a heat protection glove.

SETUP AND ASSEMBLY

Attaching and Detaching Heads:

1. **Installation:** Align the card slot of the desired brush head with the handle. Rotate the head left until it clicks securely into place.
2. **Disassembly:** Rotate the brush head right to unlock it. Gently pull the brush head away from the main unit. Always ensure the unit is cool or use the heat protection glove when detaching hot attachments.



Image: Visual guide demonstrating the correct method for installing and disassembling the styling attachments on the main unit.

OPERATING INSTRUCTIONS

General Operation:

- **Power On/Off:** Press the power button once to turn on the device. Press and hold for 3 seconds to turn it off.
- **Airflow Speed:** Use the 'Speed' button to cycle through 3 wind speed adjustments: Low, Mid, and High.
- **Temperature Settings:** Use the 'Hot' button to select from 3 temperature modes: Natural (environment), Warm (120°F), and Hot (210°F). Double-click the 'Hot' button for cool air.

HIGH SPEED HAIR DRYER

Powerful Airflow Quickly
Rough-Dries Hair In Preparation
For Styling



Image: Close-up of the main unit's control panel, highlighting the power button, airflow speed switch, and air temperature switch.

Using the Attachments:

Ensure hair is towel-dried before styling with most attachments for optimal results and reduced drying time.

1. High-Speed Hair Dryer Attachment

Use this attachment for fast drying and to prepare your hair for styling. It provides powerful airflow to quickly rough-dry hair without excessive heat.

UPGRADE DUAL BRISTLES TYPES

Dual Bristles And Powerful Airflow Smooth And Defrizz,
While Adding Volume And Bounce



Image: A woman using the high-speed hair dryer attachment to quickly dry her hair.

2. Auto Wrap Curling Iron Attachments (Left & Right)

These attachments utilize Coanda technology to automatically wrap and curl hair. Use the 'Left' curler for curls rotating counter-clockwise and the 'Right' curler for curls rotating clockwise.

1. Ensure hair is damp, not wet, for best results.
2. Take a small section of hair and hold the curler near the ends.
3. The airflow will automatically wrap the hair around the barrel. Hold until dry.
4. For a lasting curl, finish with a cool shot (double-click 'Hot' button) before releasing.

LEFT & RIGHT AIR AUTO WRAP CURLERS

Automatically Wraps,Curls,And Sets,For
Hassle-Free Curls In Seconds.





Image: Illustration detailing how the left and right auto-wrap curlers guide hair for different curl directions.

WRAPS,CURLS,SETS,AUTOMATICALLY

With Coanda Technology To Create Styles Without Extreme Heat.



Image: A woman demonstrating the use of the auto-wrap curler, showing hair being automatically wrapped around the barrel.

3. Hair Straightener Brush Attachment

This brush is designed to smooth and straighten hair with powerful airflow, reducing frizz and flyaways without direct heat plates.

1. Ensure hair is damp or dry.
2. Section your hair.
3. Slowly brush through each section from root to tip, allowing the airflow to straighten and smooth.



Image: A woman using the hair straightener brush, with a split image showing the transformation from wavy to smooth, straight hair.

4. Round Volumizing Brush Attachment

This brush features dual bristles and powerful airflow to add volume and bounce to your hair while smoothing and defrizzing.

1. Use on damp, towel-dried hair.
2. Section your hair.
3. Place the brush near the roots and lift upwards while drying to create volume. Roll the brush through the ends for shape.

ULTRA-FAST DRYING NO HEAT DAMAGE

For fast drying and smooth styling, no heat damage, won't harm your hair texture



Image: A woman using the round volumizing brush to add body and shape to her hair.

5. Soft Smoothing Brush Attachment

This attachment is designed for smoothing and creating a sleek finish, reducing frizz and enhancing shine.

1. Use on damp or dry hair.
2. Brush through sections of hair from root to tip.
3. The gentle bristles and airflow will help to smooth the hair cuticle for a polished look.

MAINTENANCE

Cleaning the Appliance:

- Always unplug the appliance before cleaning.
- Allow all attachments to cool completely before handling.
- Use the provided cleaning brush to remove any hair or debris from the air intake filter at the bottom of the main unit. Regular cleaning of the filter is crucial for maintaining optimal performance.
- Wipe the main unit and attachments with a soft, damp cloth. Do not use abrasive cleaners or immerse any part of the appliance in water.

Storage:

Store the appliance and its attachments in the provided storage bag in a cool, dry place. Ensure the cord is not wrapped tightly around the appliance, as this can cause damage over time.



Image: The AdamPark Air Styling System components, including the storage bag, packed neatly in a suitcase, illustrating its portability.

TROUBLESHOOTING

- **Appliance not turning on:**

- Check if the power cord is securely plugged into a working outlet.
- Ensure the ALCI safety plug has been reset if it has tripped.
- Verify that the power button has been pressed correctly (single press for on, long press for off).

- **Low airflow or reduced performance:**

- Check the air intake filter at the bottom of the main unit for blockages (e.g., hair, dust). Clean the filter regularly.
- Ensure the selected speed setting is appropriate.

- **Attachments not staying in place:**

- Ensure the attachment is correctly aligned with the main unit and rotated until it clicks securely into place.

- **Appliance suddenly stops during use:**

- The overheating protection may have activated. Unplug the appliance and allow it to cool down for at least 15-20 minutes before attempting to use it again.

- **Hair not curling or straightening effectively:**

- Ensure hair is damp (not soaking wet) for optimal styling with curling and volumizing attachments.
- Take smaller sections of hair.
- Adjust temperature and speed settings as needed for your hair type.

SPECIFICATIONS

Product Dimensions	11.8 x 5.9 x 1.9 inches
Weight	2.2 Pounds
Manufacturer	AdamPark
ASIN	B0D5678YKC

Color	Dark Grey
Material	Metal, Plastic
Wattage	1200 watts
Power Source	Corded Electric

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact AdamPark customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Contact Information: Please visit the official AdamPark website or refer to the contact details provided in your product packaging for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0D5678YKC>

More documents and user manuals: <https://manuals.plus/>