



Manuals.plus /

› Uakinat /

› Uakinat Bluetooth Wireless Speaker User Manual

Uakinat Q2

Uakinat Bluetooth Wireless Speaker User Manual

Model: Q2

**Introduction
Operating
Instructions**

**Safety Information
Maintenance**

**Package
Contents
Troubleshooting**

**Product
Overview
Specifications**

**Setup
Warranty &
Support**

1. INTRODUCTION

Thank you for choosing the Uakinat Bluetooth Wireless Speaker. This portable speaker delivers powerful and immersive sound with extra bass, making it ideal for home, outdoor, and travel use. Its compact design and long battery life ensure reliable audio support wherever you go. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Front view of the Uakinat Bluetooth Wireless Speaker, showcasing its compact design and control knobs.

2. SAFETY INFORMATION

Please read and follow these safety guidelines to prevent damage to the device or injury to yourself:

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Keep the speaker away from water and moisture. While it is water-resistant (IPX5), it is not designed for submersion.
- Do not disassemble, repair, or modify the device. Refer all servicing to qualified personnel.
- Use only the provided charging cable and a compatible power adapter (not included) to charge the speaker.
- Avoid dropping or subjecting the speaker to strong impacts.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure proper ventilation when operating the speaker.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Uakinat Bluetooth Wireless Speaker
- USB Charging Cable
- AUX Cable
- Quick Start Guide

4. PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Detailed view of the speaker's control panel and ports.

Control Panel:

- **Top Knob (1):**
 - Clockwise rotation: Next song/track.
 - Counter-clockwise rotation: Previous song/track.
- **Bottom Knob (2):**
 - Clockwise rotation: Increase volume (+).
 - Counter-clockwise rotation: Decrease volume (-).

- Briefly press the button: Switch between playing/pausing music.

Rear Ports:

- **ON/OFF Switch:** Power the speaker on or off.
- **AUX Input:** 3.5mm audio jack for wired connection to devices.
- **USB Port:** For USB disk playback and emergency charging of other USB devices.
- **Micro SD Card Slot:** For playing music directly from a Micro SD card.
- **Charging Port:** For connecting the USB charging cable.



Illustration highlighting the dual 5W drivers and bass boost technology for superior sound quality.

5. SETUP

5.1 Charging the Speaker

Before first use, fully charge the speaker. A full charge provides up to 10-18 hours of playback, depending on volume and

content.

1. Connect the small end of the USB charging cable to the charging port on the back of the speaker.
2. Connect the large end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.

KEY DIAGRAM

Knob ① key, clockwise rotation is the next song switching, counterclockwise rotation is the previous song switching.

Briefly press the button ② to switch between playing. rotate the button ② clockwise to volume+, and rotate the button ② counterclockwise to volume-



Visual representation of the speaker's extended battery life, indicating 12-18 hours of playback.

5.2 Powering On/Off

- To power on, slide the ON/OFF switch on the back of the speaker to the "ON" position.
- To power off, slide the ON/OFF switch to the "OFF" position.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

The speaker supports wireless Bluetooth connectivity for seamless audio streaming.

1. Ensure the speaker is powered on and within 10 meters (33 feet) of your Bluetooth-enabled device.
2. The speaker will automatically enter pairing mode, indicated by a flashing blue LED light.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.

4. Select "Uakinat Q2" (or similar name) from the list of found devices.
5. Once paired, the LED light will become solid blue, and you will hear a confirmation tone.
6. You can now play audio from your device through the speaker.

Wireless Stereo Pairing Ultra-Wide Soundstage



The Uakinat speaker seamlessly connected via Bluetooth, providing an ultra-wide soundstage for an immersive audio experience.

6.2 AUX Mode


For wired connections, use the provided AUX cable.

1. Connect one end of the 3.5mm AUX cable to the AUX input port on the speaker.
2. Connect the other end to the headphone jack or audio output of your device.
3. The speaker will automatically switch to AUX mode.
4. Adjust volume using the speaker's volume knob or your connected device.

6.3 USB Disk / Micro SD Card Playback

Play music directly from a USB flash drive or Micro SD card.

1. Insert a USB flash drive into the USB port or a Micro SD card into the Micro SD card slot on the back of the speaker.
2. The speaker will automatically detect the storage device and begin playing compatible audio files.
3. Use the top knob to navigate between tracks and the bottom knob for volume control and play/pause.



Visual representation of the speaker's versatile connectivity options: Bluetooth, TF (Micro SD) card, AUX, and USB.

6.4 Emergency Charging (Power Bank Function)

The built-in USB port can provide emergency power to your mobile phone or other USB devices.

- Connect your device's charging cable to the USB port on the speaker.
- The speaker will begin charging your device. Note that this will consume the speaker's battery.

7. MAINTENANCE

7.1 Cleaning

To maintain the appearance and functionality of your speaker:

- Wipe the exterior with a soft, dry, lint-free cloth.
- Do not use liquid cleaners, aerosols, or solvents.

7.2 Storage

When not in use for extended periods:

- Store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- Charge the battery periodically (e.g., every 3 months) to prolong its lifespan.

8. TROUBLESHOOTING

If you encounter issues with your Uakinat Bluetooth Wireless Speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker fully using the provided USB cable.
No sound from the speaker.	Volume is too low; Device not paired; Incorrect input mode.	Increase speaker and device volume; Re-pair Bluetooth; Ensure correct mode (Bluetooth, AUX, USB/SD).
Bluetooth pairing fails.	Speaker is too far from device; Speaker already connected to another device; Bluetooth not enabled on device.	Move speaker closer to device; Disconnect from other devices; Enable Bluetooth on your device and try again.
Sound distortion or crackling.	Volume too high; Low battery; Interference.	Reduce volume; Charge speaker; Move speaker away from other electronic devices.
Cannot play from USB disk/Micro SD card.	Unsupported file format; Corrupted files; Improperly inserted card/drive.	Ensure files are in compatible formats (e.g., MP3); Check card/drive for errors; Reinsert card/drive correctly.

If the problem persists after trying these solutions, please contact Uakinat customer support for assistance.

9. SPECIFICATIONS

Detailed technical specifications for the Uakinat Bluetooth Wireless Speaker (Model: Q2):

Model Name: Q2

Brand: Uakinat

Speaker Type: Surround Sound

Speaker Maximum Output Power: 10 Watts (2*5W double drive)

Connectivity Technology: Bluetooth, AUX, USB Disk, Micro SD (TF Card)

Wireless Communication Technology: Bluetooth

Bluetooth Range: Up to 10 meters (33 feet)

Power Source: Battery Powered

Battery Life: Up to 10-18 hours (actual playback time may vary)

Number of Batteries: 2 Lithium Ion batteries (included)

Product Dimensions: 8.54"D x 5"W x 3.66"H

Item Weight: 2.29 pounds

Color: Black

Water Resistance Level: IPX5 (Water Resistant)

Compatible Devices: Smartphone, Tablet, MP3 Player, Laptop

UPC: 717203476913

Product Size



Diagram illustrating the dimensions of the Uakinat Bluetooth Wireless Speaker: 8.54 inches (length), 5 inches (width), and 3.66 inches (height).

10. WARRANTY AND SUPPORT

Uakinat is committed to providing high-quality products and excellent customer service.

- **Warranty:** All Uakinat Bluetooth outdoor speakers come with a 12-month hassle-free purchase experience.
- **Customer Service:** We offer lifetime customer services and 24-hour online support.
- **Contact Us:** If you have any questions, concerns, or require assistance, please do not hesitate to contact us. Refer to the product packaging or the Uakinat store page on Amazon for contact details.