Bellemave TH-00239-D

Bellemave Full XL over Queen Bunk Bed Instruction Manual

Model: TH-00239-D | Brand: Bellemave

Introduction

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your Bellemave Full XL over Queen Bunk Bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Bellemave Full XL over Queen Bunk Bed is designed to maximize space, offering a Full XL sleeping area on the top bunk and a Queen sleeping area on the bottom. Its detachable design allows for conversion into two separate platform beds, providing versatility for various room configurations.

Safety Information

Always follow the assembly instructions carefully to ensure the bed frame's stability. Do not exceed the maximum weight recommendation of 250 pounds for the upper bunk. Keep the area around the bed clear of obstacles to prevent trips and falls. Always supervise children when they are using the bed to prevent injuries from falls or entrapment between the guardrails and the bed.

Important Safety Warnings:

- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as needed.
- The top bunk is not suitable for children under 6 years of age.
- Use only mattresses that are 6 inches thick or less for the top bunk to ensure adequate guardrail height.
- Do not attach or hang items on any part of the bunk bed that are not designed for use with the bed.
- Always use the ladder for access to the upper bunk. Do not jump on or off the bed.

Setup and Assembly

The Bellemave Full XL over Queen Bunk Bed requires assembly. Detailed assembly instructions and all necessary accessories are included in the product package. The product is shipped in two separate boxes, which may arrive at different times.

Assembly Tips:

- Clear a spacious area for assembly.
- Identify all parts using the alphabet labeling provided in the instructions.
- A powered screwdriver can significantly reduce assembly time.
- Ensure all slats are properly aligned and secured to prevent bowing or instability.
- Inspect all wooden components for splinters before assembly and handle with care.



Image: The bed frame structure with solid slats for both upper and lower bunks, designed for stability.




Image: Detailed dimensions of the bunk bed, including overall length, width, height, and internal bed measurements.

Your browser does not support the video tag.

Video: An overview of the Bellemave Solid Wood Bunk Bed, showcasing its design and features relevant to assembly and use.

Operating Instructions

Your Bellemave bunk bed offers flexible usage options:

Standard Bunk Bed Configuration

In its standard configuration, the bed provides a Full XL sleeping area on the upper bunk and a Queen sleeping area on the lower bunk. The inclined ladder allows for easy and safe access to the top bunk. The low floor design of the bottom bunk enhances safety for younger users.



Image: The Bellemave Full XL over Queen Bunk Bed in its assembled bunk configuration, featuring the Walnut finish and inclined ladder.

Detachable Bed Configuration

The bunk bed can be easily detached and converted into two separate platform beds: one raised Full XL bed and one floor-level Queen bed. This feature provides adaptability for changing room layouts or individual preferences.



Image: The Bellemave bunk bed shown in its detached configuration, with the upper bunk converted to a raised bed and the lower bunk as a floor-level bed.

Mattress Requirements

- **Upper Bunk (Full XL):** Requires a Full XL mattress. For safety, the mattress thickness should not exceed 6 inches to ensure the guardrails function effectively.
- **Lower Bunk (Queen):** Requires a Queen size mattress. Standard Queen mattresses up to 12 inches thick are generally compatible.

Maintenance

To maintain the appearance and longevity of your Bellemave bunk bed, follow these simple care instructions:

- **Cleaning:** Wipe surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Hardware:** Periodically check all bolts, screws, and connections to ensure they remain tight. Re-tighten as necessary to maintain structural integrity and prevent wobbling.
- **Slats:** Inspect bed slats regularly for any signs of damage or weakness. Replace any damaged slats immediately.

Troubleshooting

If you encounter any issues with your bunk bed, consider the following:

- **Wobbling or Instability:** This is most commonly caused by loose hardware. Re-check and tighten all bolts and screws. Ensure the bed is placed on a level surface.
- **Squeaking Noises:** Squeaking can result from loose connections or friction between wood parts. Tighten all hardware. Applying a small amount of furniture wax or silicone spray to contact points (not on slats where mattress rests) can sometimes help.
- **Damaged or Uneven Slats:** If slats appear bowed, splintered, or do not fit correctly, they may need to be replaced. Contact customer support for replacement parts.
- **Ladder Instability:** Ensure the ladder is securely attached to the bunk bed frame as per assembly instructions. Check for any loose rungs or connections.

Specifications

Brand	Bellemave
Model Number	TH-00239-D
Color	Walnut
Size	Full XL over Queen
Product Dimensions	84.7"L x 63.7"W x 58.3"H
Special Feature	Detachable
Finish Type	Painted
Included Components	Guardrails, Slats
Compatible Mattress Size	Full XL (Upper), Queen (Lower)
Furniture Finish	Walnut
Assembly Required	Yes
Headboard Material	Pine Wood
Item Weight	70 pounds
UPC	733805198909

Warranty Information

Specific warranty details for the Bellemave Full XL over Queen Bunk Bed are typically provided with your purchase documentation. Please refer to the warranty card or contact Bellemave customer support for information regarding coverage and terms.

Support and Contact

For any questions, concerns, or assistance with your Bellemave Full XL over Queen Bunk Bed, please contact our customer support team:

- **Email:** US-VC@bellemavehome.com

When contacting support, please have your model number (TH-00239-D) and purchase information readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question