

HYSEYY HY-1314

HYSEYY Portable Clothing Garment Rack (Model HY-1314) Instruction Manual

Model: HY-1314

1. INTRODUCTION

Thank you for choosing the HYSEYY Portable Clothing Garment Rack, Model HY-1314. This rack is designed to provide a sturdy and versatile solution for organizing your clothes, featuring a durable metal construction, a 46.5-inch hanging rod, and a convenient bottom shelf. Its wheeled design allows for easy mobility and flexible placement in various environments. Please read this manual carefully before assembly and use to ensure proper setup and safe operation.



Image 1.1: The HYSEYY Portable Clothing Garment Rack in a typical home environment.

2. SAFETY INFORMATION

To prevent injury or damage to the product, please observe the following safety guidelines:

- **Weight Capacity:** Do not exceed the maximum load capacity of 100 pounds (approximately 45 kg) for the hanging rod. Overloading can cause the rack to bend, collapse, or become unstable.
- **Even Distribution:** Distribute weight evenly across the hanging rod and bottom shelf. Uneven loading can lead to tipping.
- **Stable Surface:** Always place the garment rack on a flat, level, and stable surface.
- **Lock Wheels:** When the rack is in its desired position, engage the locks on the wheels to prevent unintended movement.
- **Children and Pets:** Keep children and pets away from the rack during assembly and ensure it is stable before leaving them unsupervised near it.
- **Assembly:** Follow all assembly instructions carefully. Ensure all connections are secure before use.
- **Moving the Rack:** When moving the rack, ensure the path is clear and move it slowly to prevent items from falling or the

rack from tipping.

Larger Loading Capacity

your daily storage helper

100 LBS
Load weight

1000+
Load-bearing test

0%
Rack Bending



Image 2.1: The rack demonstrating its load capacity with evenly distributed weight.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Top Hanging Rod (1)
- Vertical Support Poles (2)
- Bottom Frame Bars (2)
- Bottom Shelf (1)
- Wheels (4, with 2 lockable)
- Assembly Hardware (screws, connectors, wrench)
- Instruction Manual (1)

4. ASSEMBLY INSTRUCTIONS

Assembly of the HYSEYY Portable Clothing Garment Rack is designed to be straightforward and can typically be completed within 10 minutes. No specialized tools are required beyond what is provided.

1. **Attach Wheels to Bottom Frame:** Carefully insert the four wheels into the designated holes at the ends of the bottom frame bars. Ensure two lockable wheels are positioned on one side for easy access. Tighten any securing mechanisms if present.
2. **Connect Vertical Support Poles:** Attach the vertical support poles to the bottom frame bars. Ensure they are firmly seated and aligned.
3. **Install Bottom Shelf:** Place the bottom shelf onto the lower supports of the vertical poles. Secure it in place using the provided hardware.
4. **Attach Top Hanging Rod:** Connect the top hanging rod to the upper ends of the vertical support poles. Ensure the connections are secure and stable. The design features a simple, sturdy connection mechanism for quick assembly.

Simple & Sturdy Design

the whole assemble just 10 minutes



10 Min



more **fast**



more **sturdy**




Image 4.1: Illustration of the simple and sturdy pipe connection for assembly.

An assembly video may be available from the manufacturer's website or product page for visual guidance.

5. OPERATING INSTRUCTIONS

Your HYSEYY Portable Clothing Garment Rack is designed for convenient clothing storage and organization.

- **Hanging Clothes:** Use the 46.5-inch top rod to hang shirts, dresses, coats, and other garments. Ensure clothes are distributed to prevent excessive weight on one side. The rod is designed to hold over 40 pieces of clothing, depending on their bulk.
- **Bottom Storage:** Utilize the stable bottom shelf for storing shoes, storage boxes, bags, or other accessories.
- **Mobility:** The rack features 360° swiveling wheels for easy movement. To move the rack, unlock the two lockable wheels.
- **Stability:** Once the rack is in its desired location, engage the locks on the two lockable wheels to secure it in place and prevent accidental movement.

Multifunctional Clothes Rack

Extendable Clothes Rod

46.5" rod can hold
40+ pcs of clothing



Stable Bottom Shelf

extra space to put your
shoes, luggage etc.



Image 5.1: The garment rack showcasing its hanging capacity and bottom shelf storage.



Image 5.2: Detail of the 360° flexible and lockable wheel mechanism.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your garment rack.

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all connections and hardware to ensure they remain tight and secure. Retighten as necessary.
- **Wheel Care:** Keep the wheels free of dust and debris to ensure smooth movement. If wheels become stiff, a small amount of silicone lubricant can be applied to the axle.

7. TROUBLESHOOTING

If you encounter any issues with your garment rack, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rack is unstable or wobbles.	Loose connections; uneven weight distribution; uneven floor.	Ensure all screws and connections are tightened. Redistribute clothes evenly. Move the rack to a level surface.
Rack bends or sags.	Overloaded beyond 100 lbs capacity.	Reduce the amount of clothing or items on the rack to stay within the specified weight limit.
Wheels do not roll smoothly or lock.	Debris in wheels; lock mechanism obstructed.	Clean any hair or debris from the wheel axles. Ensure the lock lever is fully engaged or disengaged.
Missing parts upon arrival.	Packaging error or transit damage.	Contact HYSEYY customer support immediately with your purchase details.

8. SPECIFICATIONS

Key specifications for the HYSEYY Portable Clothing Garment Rack, Model HY-1314:

- **Brand:** HYSEYY
- **Model Number:** HY-1314
- **Color:** White
- **Material:** Metal (Premium Stainless Steel with Thickened Coating, Paint Anti-Rust Layer, Extra Protective Layer)
- **Product Dimensions (D x W x H):** 15.75" x 46.45" x 56.49" (40cm x 118cm x 143.5cm)
- **Hanging Rod Length:** 46.5 inches
- **Maximum Load Capacity:** 100 lbs (45 kg)
- **Item Weight:** Approximately 5 lbs (2.27 kg)
- **Installation Type:** Free Standing
- **Assembly Required:** Yes (Easy and quick)
- **Included Components:** Clothes rack, manual

say goodbye to
your wrinkled
clothes

11.81"

3.93"



Image 8.1: Dimensional overview of the garment rack.

Advanced Three-layer Structure

built for the rustproof ability and more stable




Image 8.2: Illustration of the advanced three-layer pipe structure for durability.

9. WARRANTY AND CUSTOMER SUPPORT

HYSEYY is committed to providing high-quality products and excellent customer service.

- **Customer Support:** Our dedicated after-sales team is available to assist you with any inquiries or technical support you may need.
- **Contact:** If you have any issues before or after your purchase, please contact us via the Amazon Message Center.
- **Satisfaction Guarantee:** Your satisfaction is our goal. We strive to resolve any concerns promptly and effectively.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question