

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Reemix](#) /

› [Reemix Belgian Waffle Maker \(Model REEMIX--8005\) Instruction Manual](#)

Reemix REEMIX--8005

Reemix Belgian Waffle Maker Instruction Manual

Model: REEMIX--8005

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Reemix 4-slice Belgian Waffle Maker. Please read all instructions carefully before first use and retain for future reference.



The Reemix Belgian Waffle Maker, shown open with freshly made waffles, is designed for ease of use and quick preparation.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been

damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, remove plug from wall outlet.
- Do not use appliance for other than intended use.

SETUP AND FIRST USE

1. **Unpack:** Carefully remove the waffle maker and all packaging materials. Ensure all components are present and undamaged.
2. **Initial Cleaning:** Wipe the nonstick cooking plates with a damp cloth or sponge. Dry thoroughly.
3. **Preheating:** Plug the waffle maker into a 120V AC electrical outlet. The red indicator light will illuminate, signaling that the unit is powered on. Turn the browning knob to your desired setting (LOW to HIGH). The green indicator light will illuminate when the waffle maker has reached the set temperature and is ready for use.
4. **Seasoning (First Use Only):** For the first use, it is recommended to lightly brush or spray the nonstick cooking plates with a small amount of cooking oil. This helps to condition the plates and ensure optimal nonstick performance.

OPERATING INSTRUCTIONS

1. **Prepare Batter:** Prepare your favorite waffle batter. Ensure the batter consistency is appropriate for waffle making.
2. **Preheat:** Plug in the waffle maker and allow it to preheat until the green indicator light illuminates.
3. **Add Batter:** Open the lid. Pour approximately 4 tablespoons of batter into each of the four waffle sections. Do not overfill, as excess batter may overflow. The anti-overflow channel is designed to catch minor spills.
4. **Close and Cook:** Carefully close the lid. The waffle maker features a cool-touch handle for safe operation.
5. **Flip (Optional):** For even cooking and browning, you may gently flip the waffle maker 180 degrees during the cooking process. This ensures both sides of the waffles cook uniformly.
6. **Monitor Browning:** Use the browning knob to select your preferred waffle crispness, from soft to crispy. The green indicator light will turn off during cooking and re-illuminate when the waffles are ready.
7. **Remove Waffles:** Once cooked to your preference (typically around 3 minutes), carefully open the lid. Use a heat-resistant, non-metallic utensil (e.g., wooden or silicone spatula) to remove the waffles. Avoid using metal utensils to prevent damage to the nonstick coating.
8. **Repeat:** Close the lid to allow the waffle maker to reheat for the next batch. The green light will indicate readiness.



The 1200W heating element ensures quick and even heat distribution for perfectly cooked waffles.

Your browser does not support the video tag.

Watch this video for a demonstration on how to prepare and cook four Belgian waffles using the Reemix waffle maker.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your waffle maker.

- Cool Down:** Always unplug the appliance and allow it to cool completely before cleaning.
- Clean Plates:** The nonstick plates are easy to clean. Simply wipe them with a damp cloth or sponge. For stubborn residue, a small amount of mild dish soap can be used, followed by wiping with a clean damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the nonstick coating.
- Clean Exterior:** Wipe the exterior of the waffle maker with a soft, damp cloth. Do not immerse the appliance in water or any other liquid.
- Anti-Overflow Channel:** The wrap-around channel is designed to catch excess batter. Clean this area thoroughly after each use to prevent buildup.



The anti-overflow channel helps contain excess batter, making cleanup easier.

STORAGE

The compact design of your Reemix waffle maker allows for convenient storage.

- Ensure the appliance is completely cool and clean before storing.
- The waffle maker can be stored vertically to save space in cabinets or drawers.

- Utilize the cord organizer at the bottom of the unit for tidy storage.

EASY TO STORE

Square design, very compact

≡



The compact design allows for vertical storage, optimizing kitchen space.

TROUBLESHOOTING

Issue	Cause	Solution
Appliance does not turn on.	No power connection.	Check power cord and wall outlet. Ensure it is securely plugged in.
Waffles stick to plates.	Insufficient oil or seasoning.	Lightly brush or spray cooking oil on plates before each use. Ensure plates are clean.
Waffles are not evenly browned.	Uneven batter distribution or insufficient cooking time.	Ensure batter is spread evenly. Adjust browning knob for desired crispness. Consider flipping the unit during cooking.
Batter overflows.	Too much batter added.	Reduce the amount of batter used per waffle. The anti-overflow channel will catch minor spills.

SPECIFICATIONS

- Model Number:** REEMIX--8005
- Power:** 1200 Watts
- Voltage:** 120 Volts
- Material:** Stainless Steel
- Special Feature:** Non Stick Coating, Anti-Overflow Channel, Browning Knob, Indicator Lights
- Product Dimensions:** 11"D x 5.3"W x 13.1"H
- Item Weight:** 4.8 pounds (2.18 Kilograms)
- Number of Settings:** 5 (Browning Levels)

WARRANTY AND SUPPORT

Your Reemix Belgian Waffle Maker is ETL approved with advanced safety technology for long-lasting durability.

- Warranty:** Manufacturer Warranty (Refer to user manual for specific terms).
- After-Sales Service:** 24 months after-sales service.
- Customer Service:** 24-hour friendly customer service.
- Online Support:** For additional support and information, visit the official Reemix Facebook page: facebook.com/Reemix.Official.

REEMix

WAFFLE MAKER

Model: SLS8005-12



220-240V~, 50-60Hz 1200W



Product packaging displaying the model number and brand information.



Contact information and official Facebook page for support.

Related Documents - REEMiX--8005

	<p><u>Reemix Waffle Maker Instruction Manual - Model SLS8005</u> Comprehensive instruction manual for the Reemix Waffle Maker, Model SLS8005. Features safety guidelines, operating procedures, cleaning advice, and a detailed recipe for Liege Belgian Waffles.</p>
	<p><u>REEMiX GGJ-802 Food Dehydrator User Manual</u> Comprehensive user manual for the REEMiX GGJ-802 Food Dehydrator, covering setup, operation, safety precautions, and troubleshooting for optimal food drying at home.</p>

 <p>REEMIX POWER JUICER Owner's Manual</p> <p>Mode Wash Wash Wash</p>	<p>Reemix KS-500H Power Juicer Owner's Manual</p> <p>Comprehensive owner's manual for the Reemix KS-500H Power Juicer, detailing assembly, operation, disassembly, cleaning, and safety precautions. Learn how to use your juicer effectively and safely.</p>
 <p>Instruções de Montagem REF. Instruções de Montagem VN-8005 Assembly Instructions</p> <p>HECOL Rua Antônio Bechara, 301 - Lote 1 Mun. de Vila Velha CEP: 29170-100 Fone: (02) 3434-9999 Site: www.hecol.com.br</p>	<p>HECOL VN-8005 Wardrobe Assembly Instructions</p> <p>Detailed assembly instructions for the HECOL VN-8005 Wardrobe, including parts list, hardware list, and step-by-step guidance for furniture assembly. This guide helps users assemble their HECOL wardrobe efficiently.</p>