

VCK TF004A

VCK Tower Fan Model TF004A User Manual

Your guide to operating and maintaining your VCK Tower Fan.

Setup

Operating

Maintenance

Troubleshooting

Specifications

Warranty &
Support

1. SETUP

The VCK Tower Fan Model TF004A is designed for ease of use and portability. Follow these steps for initial setup:

- Unpacking:** Carefully remove all components from the packaging. Ensure all parts are present before proceeding.
- Placement:** Place the fan on a stable, flat, and dry surface. Ensure there is adequate space around the fan for optimal airflow and oscillation. The compact design makes it suitable for desks, nightstands, or floor placement.
- Power Connection:** Plug the AC power cord into a standard 120V electrical outlet.
- Portability:** The fan features a built-in handle on the back for easy transportation between rooms.

Portable Design

Easy to move around with the handle

Built-in Handle



Figure 1: VCK Tower Fan showcasing its portable design with a built-in handle.

Bladeless Design

Ensures the safety of you and your family



Figure 2: The bladeless design of the VCK Tower Fan ensures safety, especially around children and pets.

2. OPERATING INSTRUCTIONS

Your VCK Tower Fan offers multiple settings for personalized comfort. Control the fan using either the integrated touch controls on the top panel or the included remote control.

2.1. Control Panel & Remote

The fan features intuitive electronic touch controls on its top surface. A remote control is also included for convenient operation from a distance.

Various Functions



Figure 3: Overview of the VCK Tower Fan's control panel, displaying various functions and settings.

2.2. Power On/Off

- Press the **Power** button (usually indicated by a power symbol) on the control panel or remote to turn the fan on or off.

2.3. Fan Speeds

The fan has 3 adjustable speed settings: Low, Medium, and High.

- Press the **Speed** button (often indicated by fan blades or 'Speed') to cycle through the available speeds.

2.4. Wind Modes

Choose from 4 distinct wind modes: Normal, Natural, Sleep, and AI (Artificial Intelligence).

- Press the **Mode** button (often indicated by 'M' or different wind icons) to select your desired mode.

- **Normal Mode:** Provides a consistent airflow at your selected speed.
- **Natural Mode:** Simulates a natural breeze by varying the fan speed.
- **Sleep Mode:** Operates at a lower, quieter setting for undisturbed rest.
- **AI Mode:** Adjusts fan speed automatically based on ambient conditions.



Figure 4: Illustration of the VCK Tower Fan's 4 wind modes and 3 speed settings.

Quiet & 12H Timer

Noise level below 45dB, hold a deep sleep



Figure 5: The fan operates quietly, making it suitable for bedrooms, and includes a 12-hour timer function.

2.5. Oscillation

The fan features an 80° wide oscillation to distribute airflow across a larger area.

- Press the **Oscillation** button (often indicated by a circular arrow symbol) to start or stop the oscillating movement.

80° Wide Oscillation

Enjoy a wider range of cooling



Figure 6: The VCK Tower Fan provides 80 degrees of wide oscillation for broad air distribution.

2.6. Timer Function

Set the fan to automatically turn off after a specified period, up to 12 hours.

- Press the **Timer** button (often indicated by a clock symbol) repeatedly to select the desired shut-off time in hourly increments.
- The display will show the selected timer duration.

3. MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your VCK Tower Fan.

1. **Always unplug** the fan from the electrical supply before cleaning.
2. **Exterior Cleaning:** Use a soft, damp cloth or sponge with a mild soap solution to wipe down the exterior surfaces.

- 3. **Air Inlet/Outlet Cleaning:** Use a vacuum cleaner with a brush attachment to remove dust and debris from the air inlet and outlet grilles. Do not use water or other liquid inside the motor housing.
- 4. **Avoid harsh chemicals:** Do not use abrasive cleaners, solvents (such as thinners), or harsh chemicals, as these may damage the fan's finish or internal components.
- 5. **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging.

4. TROUBLESHOOTING

If you encounter any issues with your VCK Tower Fan, please refer to the following common problems and solutions:

- **Fan does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the power button has been pressed.
- **Weak or no airflow:**
 - Verify the fan speed setting is not on 'Low'. Increase the speed setting.
 - Check for any obstructions in the air inlet or outlet grilles and clean them if necessary (refer to Maintenance section).
- **Unusual noise during operation:**
 - Ensure the fan is placed on a stable, flat surface to prevent rattling.
 - Check for any loose parts or foreign objects inside the fan. If an object is found, unplug the fan and carefully remove it.
- **Oscillation not working:**
 - Ensure the oscillation function is activated by pressing the oscillation button.
 - Check for any physical obstructions preventing the fan from rotating.

If the problem persists after trying these solutions, please contact VCK customer support for further assistance.

5. SPECIFICATIONS

Feature	Specification
Brand	VCK
Model Name	TF004A
Color	Black
Electric Fan Design	Table Fan
Style	Modern
Special Features	Oscillating, Remote Controlled

Feature	Specification
Recommended Uses	Air Circulation
Noise Level	25 Decibels
Air Flow Capacity	13.55 Cubic Feet Per Minute
Switch Type	Electronic Touch Controls
Included Components	Remote
Indoor/Outdoor Usage	Indoor
Control Method	Remote
Number of Power Levels	3
Main Power Connector Type	AC power cord
Manufacturer	VCK
Product Dimensions	3.1 x 3.2 x 13 inches
Item Weight	3.05 pounds
Date First Available	March 10, 2024

6. WARRANTY & SUPPORT

For warranty information or technical support regarding your VCK Tower Fan Model TF004A, please refer to the documentation included with your purchase or contact VCK customer service directly. Contact details are typically found on the manufacturer's official website or in the product packaging.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D5CB2RCV>

More documents and user manuals: <https://manuals.plus/>