



[Manuals.plus](#) /

› [TIMEURE](#) /

› TIMEURE TU-2401 Women's Step Counter Watch Instruction Manual

TIMEURE TU-2401

TIMEURE TU-2401 Women's Step Counter Watch Instruction Manual

Model: TU-2401

1. PRODUCT OVERVIEW

The TIMEURE TU-2401 is a women's step counter watch designed for tracking daily activity without the need for smartphone applications or frequent charging. It features a stylish stainless steel bracelet and a digital display.



Image: TIMEURE TU-2401 Rose Gold Step Counter Watch.

Key Features:

- Step, calorie, and mileage calculation (Kilometers and miles switchable).
- Time, date, and week display (12/24 hour format switchable).
- Alarm and hourly chime functions.
- Countdown timer and stopwatch.
- 5-second EL bright backlight.
- 30M water resistance.
- Long-lasting CR2032 battery (up to 15 months).
- No app connection required.

THE MAIN FEATURES



Steps



Calories



Mileage

Km / Miles switchable



Historical steps

Check yesterday's steps



Countdown



30m waterproof

Swimming and shower



5-second EL backlight



Image: Visual representation of the watch's main features.

2. SETUP AND ADJUSTMENT

2.1 Initial Power On

The watch comes with a pre-installed CR2032 battery. It is ready for use upon receipt.

2.2 Adjusting the Stainless Steel Bracelet

The watch features an adjustable lightweight breathable steel woven band with a stainless steel folding buckle. The strap length can be freely adjusted to fit wrist sizes between 4.33-7.67 inches (110-195mm).

- The strap is equipped with a switch ear, allowing for easy removal without tools.
- To unlock or buckle, simply press lightly.

Snap buckle design

- ✓ The length of the strap can be freely adjusted according to different wrist sizes, suitable for wrist width 110-195mm/4.3-7.6in
- ✓ Equipped with a switch ear, you can easily remove the strap without tools
- ✓ Just press lightly to easily unlock or buckle



Image: Detailed view of the adjustable snap buckle and strap.

2.3 Setting Time and Date

Refer to the included quick start guide for detailed instructions on setting the time, date, and 12/24 hour format. The watch displays 'PM' after noon in 12-hour mode, which is crucial for correct daily reset of the pedometer and date at midnight.

3. OPERATING INSTRUCTIONS

3.1 Step Counting Function

The watch accurately tracks steps, calories burned, and distance traveled. Mileage can be switched between kilometers and miles.

- To filter out invalid steps from irregular hand movements, all step counts for single continuous movements less than 10 seconds will be disregarded.
- If continuous movement exceeds 10 seconds, previous step counts will automatically be accumulated.



Image: Explanation of the 10-second filter for step counting accuracy.

3.2 Understanding Step Count Errors

Certain activities may affect step count accuracy:

- Irregular walking patterns (e.g., in crowded areas, stopping and starting).
- Pushing a shopping cart or stroller.
- Being in a location with frequent vibrations, or riding a bicycle or car.
- Frequent movement of hands or arms (e.g., clapping, fanning), walking while holding hands, or using a cane/stick, or any movement where hands and legs are not coordinated.
- Non-walking daily activities (e.g., cleaning).

3.3 Backlight Function

The watch features a 5-second EL bright backlight for visibility in low-light conditions. Activate the backlight by pressing the 'LIGHT' button.



NIGHT LIGHT

LUMINOUS DESIGN, NO FEAR OF THE NIGHT, ANYTIME, ANYWHERE

Image: The watch display with its night light activated.

4. MAINTENANCE

4.1 Battery Information

The watch uses one CR2032 battery, which is included. The battery can last up to 15 months without charging. The battery is replaceable.

4.2 Water Resistance

The watch is 30M water resistant. This means it is suitable for daily use, such as washing hands, getting wet in rain, or splashing water. It is not recommended for swimming or showering for extended periods.



Image: Water resistance capabilities of the watch.

4.3 Cleaning

To clean the watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

5. TROUBLESHOOTING

5.1 Inaccurate Step Count

If you experience inaccurate step counts, review the 'Understanding Step Count Errors' section (3.2). Ensure your movements are consistent and sustained for at least 10 seconds for optimal tracking.


5.2 Dim Backlight or Display Issues

A dim backlight or fading display may indicate a low battery. Replace the CR2032 battery as described in section 4.1. The battery compartment can be accessed by removing the four screws on the back of the watch.

6. SPECIFICATIONS

Model Number	TU-2401
Display Type	Digital
Display Size	36 Millimeters
Material	Stainless Steel
Power Source	Battery Powered
Battery Type	1 CR2032 (included)
Battery Life	Up to 15 months
Water Resistance	30M
Item Weight	73 g
Wrist Size Compatibility	4.33-7.67 inches (110-195mm)

PRODUCT SIZE



Suitable for wrist width
110-195mm/4.3-7.6in



12mm/0.47in



Net weight: 73.3g / 2.585oz

NOTE: manual measurement, there may be a little error

Image: Product dimensions and wrist size compatibility.

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The TIMEURE TU-2401 watch comes with a 1-year after-sales service.

7.2 Return Policy

A 30-day no-reason return policy is available for this product.

7.3 Customer Support

TIMEURE offers 12-hour online customer service for any inquiries or assistance you may need.