

[Manuals.plus](#) /

› [Yaheetech](#) /

› Yaheetech 3-Seater Garden Swing with Adjustable Canopy Instruction Manual

Yaheetech B0D5CMKFTC

Yaheetech 3-Seater Garden Swing with Adjustable Canopy Instruction Manual

Model: B0D5CMKFTC | Brand: Yaheetech

INTRODUCTION

Thank you for choosing the Yaheetech 3-Seater Garden Swing with Adjustable Canopy. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new garden swing. Please read all instructions carefully before assembly and use to ensure optimal performance and longevity of the product. Keep this manual for future reference.



Image: The Yaheetech 3-Seater Garden Swing with its adjustable canopy, set in a garden environment.

SAFETY INFORMATION

To ensure safe operation and prevent injury, please observe the following safety guidelines:

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 250 kg (550 lbs). This swing is designed for a maximum of 3 persons.
- **Stable Surface:** Always place the swing on a flat, stable, and level surface to prevent tipping.
- **Regular Inspection:** Periodically check all bolts, nuts, and connections to ensure they are tight and secure. Tighten as necessary.
- **Weather Conditions:** Avoid using the swing during strong winds, heavy rain, or other severe weather conditions. The canopy should be lowered or removed in high winds.
- **Children Supervision:** Children should be supervised at all times when using the swing.
- **Proper Use:** Do not stand on the swing or use it for purposes other than its intended design.
- **Maintenance:** Follow all maintenance instructions to ensure the product remains in good condition.

SETUP AND ASSEMBLY

Assembly of the Yaheetech Garden Swing requires careful attention to detail. Please ensure all parts are present before beginning. It is recommended to have two people for assembly.

Package Contents:

Refer to the included parts list in your packaging to verify all components are present and undamaged.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
 2. **Assemble the Main Frame:** Connect the main support bars according to the diagrams provided in your specific assembly guide. Ensure all bolts are finger-tightened initially.
 3. **Attach the Seat Frame:** Secure the swing seat frame to the main support structure using the provided hardware.
 4. **Install the Canopy Frame:** Assemble the canopy frame and attach it to the top of the main structure.
 5. **Mount the Canopy Fabric:** Slide the canopy fabric onto the canopy frame.
 6. **Secure Cushions:** Place the removable cushions onto the seat and backrest.
 7. **Final Tightening:** Once all components are in place, systematically tighten all bolts and nuts using the provided tools. Do not overtighten.
-




Image: Detailed dimensions of the Yaheetech 3-Seater Garden Swing, including overall height, width, depth, and seat measurements.

CHAISE BALANCE D'EXTÉRIEUR AVEC AUVENT DE HAUTE QUALITÉ



Crochet à Ressort Solide



Matériau Résistant à l'eau



Structure Triangulaire avec
une Excellente Stabilité

Patins Antidérapants pour
une Sécurité Améliorée



Coussin Épais

Image: Close-up views highlighting key features such as the solid spring hook, water-resistant material, thick cushion, triangular structure for stability, and anti-slip feet.



Image: A detailed view of the stable triangular frame structure, emphasizing its robust design for enhanced stability.

OPERATING INSTRUCTIONS

Using the Swing:

The Yaheetech Garden Swing is designed for comfortable outdoor relaxation. Gently push off the ground to initiate a swinging motion. Avoid excessive force or sudden movements.

Adjusting the Canopy:

The adjustable canopy provides shade and protection from the sun. To adjust the angle of the canopy:

1. Locate the adjustment knobs on both sides of the canopy frame.
2. Loosen the knobs by turning them counter-clockwise.
3. Adjust the canopy to your desired angle (up to 90 degrees) to block sunlight.
4. Tighten the knobs by turning them clockwise to secure the canopy in position.

AUVENT RÉGLABLE

Vous protège du soleil brûlant



Protection
contre le soleil



Résistance
à l'eau



Remarques :
Avant d'ajuster la canopée,
veuillez desserrer les boutons.

Image: A close-up of the canopy adjustment mechanism, showing the knob used to loosen and tighten the canopy for angle changes.



Image: An illustration demonstrating the range of motion for the adjustable canopy, indicating how it can be tilted to provide optimal sun protection.

CAPACITÉ DE CHARGE MAXIMALE DE 250 KG POUR 3 PERSONNES



3 Personnes au
maximum



Capacité de Charge



Image: A visual representation showing the swing's capacity for up to 3 persons and its maximum weight limit of 250 kg.

MAINTENANCE

Regular maintenance will extend the life and appearance of your garden swing.

- **Cleaning the Frame:** Wipe the metal frame with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent rust. Avoid abrasive cleaners.
- **Cleaning the Canopy and Cushions:** The polyester canopy and cushions are water-resistant. Clean them with a soft brush, mild soap, and water. Allow them to air dry completely before storage or re-use. Cushions are removable for easier cleaning.
- **Rust Prevention:** The frame has a powder coating for weather resistance. If any scratches or chips occur, touch up with rust-inhibiting paint to prevent corrosion.
- **Winter Storage:** During off-season or prolonged periods of non-use, it is recommended to store the swing in a dry, protected area. Remove cushions and canopy for separate storage.
- **Fastener Check:** Annually, or more frequently if used often, check all nuts, bolts, and screws to ensure they are tight. Loose fasteners can compromise stability and safety.

TROUBLESHOOTING

If you encounter issues with your Yaheetech Garden Swing, refer to the following common problems and solutions:

- **Squeaking Noise:**
 - Check all connection points for tightness.
 - Apply a silicone-based lubricant to moving parts, such as the spring hooks and pivot points.
- **Swing Feels Unstable:**
 - Ensure the swing is placed on a completely flat and level surface.
 - Verify all assembly bolts and nuts are securely tightened.
 - Check the anti-slip feet for proper placement and condition.
- **Canopy Does Not Stay in Position:**
 - Ensure the adjustment knobs on both sides of the canopy frame are fully tightened after positioning.
 - Inspect the canopy frame for any damage or bending.
- **Rust Spots Appearing:**
 - Clean the affected area thoroughly.
 - Apply rust-inhibiting paint to prevent further corrosion.
 - Ensure the swing is dried completely after rain or cleaning.

PRODUCT SPECIFICATIONS

Brand	Yaheetech
Model Number	B0D5CMKFTC
Color	Black
Material	Metal, Polyester
Overall Dimensions (D x W x H)	112.5P x 170I x 162.5H cm (44.3 x 66.9 x 64 inches)
Item Weight	17 Kilograms (37.5 lbs)
Maximum Weight Recommendation	250 Kilograms (550 lbs)
Seating Capacity	3 Persons
Seat Depth	43 cm (16.9 inches)
Finish Type	Powder Coated
Assembly Required	Yes

MULTI-SCÉNARIOS APPLICABLES



Arrière-cour



Jardin



Terrasse



Piscine



Image: The Yaheetech Garden Swing shown in multiple applicable scenarios, including a backyard, garden, terrace, and poolside, demonstrating its versatility.

WARRANTY INFORMATION

Yaheetech products are manufactured to high-quality standards. For specific warranty details regarding your 3-Seater Garden Swing (Model B0D5CMKFTC), please refer to the warranty card included with your purchase or visit the official Yaheetech website. Typically, warranty coverage addresses manufacturing defects under normal use conditions.

Please note: Damage resulting from improper assembly, misuse, neglect, or extreme weather conditions may not be covered under warranty.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact Yaheetech customer support. Have your model number (B0D5CMKFTC) and purchase information ready when contacting support.

- **Online Support:** Visit the official Yaheetech website for FAQs, support articles, and contact forms.

- **Email:** Refer to your product packaging or the Yaheetech website for the most current email contact information.

We are committed to providing excellent service and ensuring your satisfaction with Yaheetech products.

