Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tounee LS16 EXPRO

Tounee LS16 EXPRO Laptop Stand User Manual

Model: LS16 EXPRO | Brand: Tounee

1. Introduction

Thank you for choosing the Tounee LS16 EXPRO 360° Ergonomic Adjustable Laptop Stand. This manual provides essential information for the proper setup, operation, and maintenance of your new laptop stand. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

2. Key Features

- **360-Degree Rotation:** The integrated swivel base allows for effortless rotation, making it ideal for collaborative work and sharing your screen with others.
- **Ergonomic Design:** Adjustable height and angle settings elevate your laptop to eye level, promoting a healthy posture and reducing strain on your neck and back.
- **Robust Stability:** Constructed to support laptops and tablets weighing up to 10 kg (22 lbs). Features non-slip silicone pads to secure your device and prevent wobbling during use.
- **Space-Saving:** Designed to optimize your workspace, allowing you to store a keyboard or other accessories underneath, keeping your desk organized.
- **Wide Compatibility & Portability:** Compatible with all laptops and tablets up to 16 inches. Its fully foldable design makes it easy to carry for travel or business trips.



Image: The Tounee LS16 EXPRO stand securely holding a laptop, illustrating its stability and robust design.

3. Setup Instructions

1. **Unfold the Stand:** Carefully unfold the stand from its compact, folded state. The hinges are designed to be firm for stability, so apply gentle, steady pressure.
2. **Position on Desk:** Place the stand on a stable, flat surface. Ensure the base is fully seated to prevent any instability.
3. **Adjust Height and Angle:** Lift the laptop platform to your desired height. Adjust the angle of the platform for comfortable viewing. The stand offers a wide range of adjustments to suit your ergonomic needs.
4. **Place Your Device:** Carefully place your laptop or tablet onto the silicone-padded platform. Ensure it rests securely against the front stoppers and on the anti-slip pads.



Image: Visual representation of the Tounee LS16 EXPRO stand in its folded state for storage, a drawing position, and a sitting position for ergonomic use.

4. Operating Instructions

4.1 Adjusting Height and Angle

The Tounee LS16 EXPRO stand features multiple articulation points for precise height and angle adjustments. To adjust:

1. Gently hold the base of the stand with one hand.
2. With the other hand, carefully push or pull the laptop platform to achieve your desired height and viewing angle. The hinges are designed to hold their position firmly once set.



Image: The Tounee LS16 EXPRO stand illustrating its adjustable height and angle capabilities, with indicators for 90-120 degree tilt.

4.2 Using the 360° Rotation

The stand's base is equipped with a smooth 360-degree swivel mechanism:

1. Ensure your laptop is securely placed on the stand.

2. Gently rotate the entire stand from its base to share your screen or change your viewing direction without moving the entire setup.



Image: A user demonstrating the 360-degree rotation feature of the Tounee LS16 EXPRO stand, facilitating collaborative work.

4.3 Compatibility

The stand is designed to accommodate a wide range of devices:

- Supports laptops and tablets up to 16 inches.
- Suitable for various uses including laptops, iPads, and even holding books.




Image: The Tounee LS16 EXPRO stand showcasing its versatility by holding a laptop, an iPad, and a book in different scenarios.

5. Maintenance

To ensure your Tounee LS16 EXPRO laptop stand remains in excellent condition:

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish and silicone pads.
- **Silicone Pads:** Periodically check the silicone anti-slip pads for any wear or damage. Ensure they are clean and free of dust to maintain optimal grip.
- **Hinges:** The hinges are designed for durability and do not require lubrication. If you notice any stiffness, ensure no debris is obstructing the mechanism. Do not attempt to disassemble the hinges.




Image: Detailed view of the Tounee LS16 EXPRO stand highlighting its silicone anti-slip features, durable hinges, and mechanical rotating structure, all contributing to its robust design.

6. Troubleshooting

6.1 Stand Feels Unstable

- **Check Surface:** Ensure the stand is placed on a flat, stable, and even surface.
- **Device Placement:** Verify that your laptop or tablet is centered and securely resting on the stand's platform and against the front stoppers.
- **Weight Limit:** Confirm your device's weight does not exceed the stand's maximum capacity of 10 kg (22 lbs).

6.2 Difficulty Adjusting Height/Angle

- **Apply Firm Pressure:** The hinges are designed to be stiff to maintain position. Apply firm, steady pressure when adjusting.
- **Check for Obstructions:** Ensure there is no debris or foreign objects caught in the hinge mechanisms.

6.3 Device Sliding on Stand

- **Clean Pads:** Clean the silicone anti-slip pads on the platform and base with a damp cloth to remove any dust or oils that might reduce grip.
- **Proper Placement:** Ensure your device is correctly positioned against the front stoppers.

7. Specifications

Feature	Detail
Model Number	LS16 EXPRO
Brand	Tounee
Color	Black
Material	Rubber (Silicone Pads)
Item Weight	1.3 Kilograms
Compatible Devices	Laptops, Notebooks, Tablets (up to 16 inches)
Mounting Type	Table Mount
Special Feature	360-Degree Rotation, Adjustable Height & Angle
Recommended Use	Office, Home
Included Components	Laptop Stand
Country of Origin	China



Image: The Tounee LS16 EXPRO stand displaying its dimensions and highlighting its wide compatibility with laptops ranging from 10 to 17 inches.

8. Warranty Information

The Tounee LS16 EXPRO Laptop Stand comes with a**2-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

9. Customer Support

For any questions, concerns, or technical assistance regarding your Tounee LS16 EXPRO Laptop Stand, please contact our customer support team. You can typically find support contact information on the Tounee official website or through your retailer's customer service portal.
When contacting support, please have your product model (LS16 EXPRO) and proof of purchase ready to expedite the process.

© 2023 Tounee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5CS49J7

More documents and user manuals: **https://manuals.plus/**