

esonstyle S13

esonstyle S13 Invisible Sleep Earbuds User Manual

Model: S13

INTRODUCTION

Thank you for choosing the esonstyle S13 Invisible Sleep Earbuds. These earbuds are designed to provide a comfortable and undisturbed listening experience, especially for sleep and relaxation. Their compact, flat design ensures comfort even when sleeping on your side, while passive noise cancellation helps block out external disturbances.

This manual provides essential information on how to set up, operate, maintain, and troubleshoot your esonstyle S13 earbuds. Please read it carefully before use to ensure optimal performance and longevity of your device.



Image: The esonstyle S13 Invisible Sleep Earbuds shown with their compact charging case. One earbud is displayed outside the case, highlighting its small, flat design.

PACKAGE CONTENTS

Ensure all items are present in the package:

- esonstyle S13 Sleep Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual (this document)
- Ear Tips (various sizes)

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The indicator lights on the case will show charging status. A full charge typically takes about 1.5 hours for the case.

Battery Life Up To 24 Hours

The earbuds battery life is 4H and the charging case lasts up to 20H.



Image: An illustration showing the battery life of the earbuds (4 hours playback) and the charging case (up to 24 hours total with case charges).

2. Pairing with a Device (Bluetooth 5.3)

The earbuds use Bluetooth 5.3 for a stable and quick connection.

1. Open the charging case lid. The earbuds will automatically enter pairing mode (or reconnect to the last paired device).
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and ensure Bluetooth is enabled.
3. Search for available devices and select "esonstyle S13" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when the case lid is opened.

One-Step Pairing (By Bluetooth V5.3)

It will automatically connect when the lid is opened after first connection.



Image: A visual representation of the one-step pairing process via Bluetooth 5.3, showing quick connection, low latency, and low power consumption.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The esonstyle S13 earbuds are designed for comfort, especially for side sleepers.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently insert the earbud into your ear canal.
3. Adjust the earbud so it sits flush and comfortably within your ear, minimizing protrusion. This "tuck" method ensures comfort for side sleeping.

How To Wear



Insert



Tuck

Image: A diagram illustrating the two steps for wearing the earbuds: "Insert" into the ear canal and "Tuck" to ensure a flat, comfortable fit.



Mini Sleep Headphones

Designed for Side Sleeping

Image: A woman sleeping comfortably on her side, demonstrating how the mini sleep headphones are designed for side sleeping.

Touch Controls

The earbuds feature intuitive touch controls:

Action	Control
Play/Pause	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold either earbud for 2 seconds
Activate Voice Assistant	Triple tap on either earbud

Note: Volume control is typically managed via your connected device.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

Water Resistance (IPX6)

The esonstyle S13 earbuds are rated IPX6 waterproof and sweatproof, meaning they can withstand powerful water jets. This makes them suitable for workouts and light rain, but they are not designed for submersion in water (e.g., swimming).




Image: An illustration highlighting the IPX6 waterproof and sweatproof rating, and the lightweight design (2g) for comfortable and secure fit.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none">◦ Ensure earbuds are charged.◦ Make sure Bluetooth is enabled on your device.◦ Place earbuds back in the case, close the lid, wait a few seconds, then open to re-enter pairing mode.◦ Forget "esonstyle S13" from your device's Bluetooth list and try pairing again.◦ Ensure no other devices are actively connected to the earbuds.
No sound or low volume	<ul style="list-style-type: none">◦ Check volume levels on both the earbuds (via touch controls if applicable) and your connected device.◦ Ensure earbuds are properly seated in your ears.◦ Reconnect the earbuds to your device.◦ Clean any debris from the earbud speakers.
Earbuds not charging	<ul style="list-style-type: none">◦ Ensure the charging cable is securely connected to both the case and the power source.◦ Try a different USB cable or power adapter.◦ Make sure the charging contacts on the earbuds and inside the case are clean and free of debris.
Intermittent connection/audio drops	<ul style="list-style-type: none">◦ Move closer to your connected device (Bluetooth range is typically up to 10 meters/33 feet).◦ Avoid strong electromagnetic interference.◦ Ensure earbuds are fully charged.

SPECIFICATIONS

Feature	Detail
Model Name	S13
Brand	esonstyle
Connectivity	Bluetooth 5.3 (Wireless)

Feature	Detail
Noise Control	Passive Noise Cancellation
Earbud Playback Time	Up to 4 hours (single charge)
Total Playback Time	Up to 24 hours (with charging case)
Charging Time	Approx. 1.5 hours (for case)
Control Type	Touch Control
Water Resistance	IPX6 (Waterproof & Sweatproof)
Material	Acrylonitrile Butadiene Styrene (ABS)
Ear Placement	In-Ear
Form Factor	In-Ear (Minimalist, Flat for Side Sleeping)
Weight	Approx. 2g per earbud
Compatible Devices	Cell phones, laptops, tablets

WARRANTY AND SUPPORT

esonstyle products come with a manufacturer's warranty. For specific warranty details and duration, please refer to the warranty card included in your product packaging or contact esonstyle customer support directly.

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact esonstyle customer support. We are committed to providing satisfactory solutions.

Contact Information:

- Please refer to the contact details provided on the product packaging or the official esonstyle website.