

[Manuals.plus](#) /

› [MechMaxx](#) /

› MechMaxx PTO Stump Grinder SG24 Teeth and Nut Instruction Manual

MechMaxx 406201

MechMaxx PTO Stump Grinder SG24 Teeth and Nut Instruction Manual

Model: 406201

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of the MechMaxx PTO Stump Grinder SG24 Teeth and Nut set. Please read this manual thoroughly before use to ensure safe and efficient operation and to prolong the lifespan of your components.

This kit includes 34 pieces of teeth and nuts designed specifically for the SG24 PTO stump grinder.

PRODUCT OVERVIEW

The MechMaxx PTO Stump Grinder SG24 Teeth and Nut set is manufactured from high-quality 42CrMo steel for the teeth and YG11 carbide tips, ensuring durability and effective stump grinding performance. The nuts are designed to securely fasten the teeth to the grinder's cutting wheel.



Figure 1: Complete set of 34 teeth and nuts for the SG24 PTO stump grinder. This image displays the individual carbide teeth and their corresponding nuts, packaged together.



Figure 2: Close-up view of multiple individual teeth and nuts. Each tooth features a robust design with a carbide tip for efficient material removal and a threaded shaft for secure attachment with the provided nut.

SAFETY INFORMATION

Always prioritize safety when working with power equipment. Refer to your PTO stump grinder's main instruction manual for comprehensive safety guidelines.

- Ensure the stump grinder is turned off and the PTO is disengaged before performing any installation, maintenance, or inspection.
- Wear appropriate personal protective equipment (PPE), including safety glasses, gloves, and hearing protection.
- Keep hands and loose clothing away from moving parts.
- Inspect teeth and nuts regularly for wear or damage. Replace worn or damaged components immediately.

SETUP AND INSTALLATION

This section outlines the procedure for installing the teeth and nuts onto the SG24 PTO stump grinder's cutting wheel.

1. **Preparation:** Park the stump grinder on a level surface. Turn off the engine and disengage the PTO. Allow the cutting wheel to come to a complete stop.
2. **Access the Cutting Wheel:** Depending on your specific SG24 model, you may need to remove a protective cover to access the cutting wheel and its tooth mounting points.
3. **Remove Old Teeth (if applicable):** If replacing existing teeth, use appropriate tools (e.g., wrench, socket) to loosen and remove the old nuts and teeth. Dispose of old components responsibly.

4. **Install New Teeth:** Insert the threaded shaft of a new tooth into the designated mounting hole on the cutting wheel. Ensure the carbide tip is oriented correctly for cutting.
5. **Secure with Nut:** Place a new nut onto the threaded shaft of the tooth from the opposite side of the cutting wheel. Hand-tighten the nut initially.
6. **Torque Specification:** Using a torque wrench, tighten each nut to the manufacturer's specified torque setting for the SG24 stump grinder. Refer to your stump grinder's main manual for precise torque values. *Overtightening or undertightening can lead to premature wear or component failure.*
7. **Repeat:** Repeat the process for all teeth. Ensure all teeth are securely fastened before proceeding.
8. **Reassemble:** Reattach any protective covers removed during the installation process.

OPERATING CONSIDERATIONS

While this manual focuses on the teeth and nuts, proper operation of the stump grinder is crucial for their longevity and performance.

- Always operate the stump grinder according to the instructions in its primary user manual.
- Avoid striking foreign objects (rocks, metal) with the cutting wheel, as this can damage the teeth and other components.
- Maintain appropriate PTO RPM as recommended by the stump grinder manufacturer for optimal cutting efficiency and reduced wear on teeth.

MAINTENANCE

Regular maintenance of the teeth and nuts is essential for optimal performance and safety.

- **Daily Inspection:** Before each use, visually inspect all teeth for signs of wear, chipping, cracking, or bending. Check that all nuts are tight.
- **Cleaning:** After each use, clean debris from around the teeth and cutting wheel. This prevents buildup that could affect performance or hide damage.
- **Replacement:** Replace teeth that show significant wear or damage. Operating with worn teeth can reduce efficiency, increase strain on the machine, and potentially lead to further damage. It is recommended to replace teeth in sets or rotate them to ensure even wear across the cutting wheel.
- **Storage:** Store spare teeth and nuts in a dry, clean environment to prevent corrosion.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Excessive vibration during operation	Unevenly worn teeth; loose teeth/nuts; damaged cutting wheel.	Inspect and replace worn teeth. Tighten all nuts to specified torque. Inspect cutting wheel for damage.
Poor cutting performance	Worn or dull teeth; incorrect tooth orientation.	Replace worn teeth. Ensure teeth are installed with correct cutting angle.
Teeth loosening or falling off	Nuts not tightened to correct torque; excessive vibration; damaged threads.	Re-tighten nuts to specified torque. Inspect threads on teeth and nuts for damage; replace if necessary. Address source of excessive vibration.

SPECIFICATIONS

- **Product Name:** Teeth and Nut for PTO Stump Grinder SG24
- **Brand:** MechMaxx
- **Model Compatibility:** SG24 PTO Stump Grinder
- **Material:** Teeth: 42CrMo steel with YG11 carbide tips; Nuts: Steel
- **Quantity:** 34 pieces (teeth and nuts)
- **Item Weight:** 8 pounds (total package)
- **Package Dimensions:** 13 x 6 x 5 inches
- **Manufacturer Part Number:** 406201

WARRANTY AND SUPPORT

For warranty information and technical support regarding your MechMaxx products, please refer to the official MechMaxx website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

MechMaxx Customer Service: [Visit the MechMaxx Store on Amazon](#)

© 2024 MechMaxx. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

