GRAEF MT1003

GRAEF MYtiny Folding Kitchen Food Slicer MT1003 User Manual

Model: MT1003

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your GRAEF MYtiny Folding Kitchen Food Slicer MT1003. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- **Read all instructions:** Familiarize yourself with the appliance's operation and safety features before use.
- **Blade Hazard:** The slicing blade is extremely sharp. Always handle with extreme care. Never touch the blade directly with your hands.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- **Cleaning:** Always unplug the appliance from the power outlet before cleaning or when not in use. Do not immerse the motor unit in water or other liquids.
- **Intended Use:** Use the appliance only for its intended household purpose of slicing food. Do not use outdoors.
- **Stability:** Always operate the slicer on a stable, flat, and dry surface.
- **Personal Injury:** Keep hands, hair, clothing, and utensils away from the moving blade during operation to prevent injury. Use the food carriage and food holder for safe operation.

Product Overview

The GRAEF MYtiny Folding Kitchen Food Slicer MT1003 is a compact and versatile appliance designed for precise slicing of various foods such as bread, sausage, and vegetables. Its foldable design allows for convenient storage in small spaces.

Key Features:

- Ultra-compact dimensions and folding function for space-saving storage.
- High-quality metal housing for durability and easy cleaning.
- Continuous cutting thickness adjustment from 0 to 15 mm.
- 170mm wavy sharpening knife for finer cuts.
- Central control unit with ignition fuse and safety lock for stop and switch during transport/storage.
- Integrated cable compartment for tidy storage.



Figure 1: Front view of the GRAEF MYtiny Folding Kitchen Food Slicer MT1003 in its operational, unfolded state. The red housing and the slicing blade are visible, along with the thickness adjustment dial.



Figure 2: The slicer fully unfolded, revealing the stainless steel blade, the food carriage, and the food holder. This view demonstrates the appliance ready for use.

Setup and Assembly

1. **Unpacking:** Carefully remove the slicer and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the slicer on a clean, stable, and level surface. Ensure there is sufficient space around the appliance for safe operation.
3. **Unfolding the Slicer:**
    - Locate the release button for the folding mechanism, typically near the food carriage.
    - Press the release button and gently unfold the food carriage and base until it locks into the operational position.



Figure 3: Demonstrates the process of unfolding the slicer. A hand is shown pressing the release button while the other hand guides the food carriage into position.

4. **Power Connection:** Ensure the slicer is in the OFF position and the thickness adjustment is set to '0' (locked position) before plugging the power cord into a grounded electrical outlet.

Operating Instructions

1. **Adjusting Slicing Thickness:**
    - Rotate the thickness adjustment dial to select the desired slice thickness, ranging from 0 to 15 mm. Ensure the safety lock is disengaged (usually by rotating past '0').




Figure 4: A close-up view of the thickness adjustment dial, indicating settings from 0 to 15 mm. The dial allows for precise control over slice thickness.

2. **Loading Food:**
    - Place the food item (e.g., bread, meat, vegetables) onto the food carriage.
    - Secure the food with the food holder, ensuring your fingers are protected and away from the blade.
3. **Slicing:**
    - Turn the slicer ON using the power switch.
    - Gently push the food carriage towards the rotating blade, applying even pressure.
    - Collect the sliced food from the other side of the blade.
4. **After Slicing:**
    - Turn the slicer OFF.
    - Return the thickness adjustment dial to '0' to engage the safety lock.
    - Unplug the appliance from the power outlet.
5. **Folding for Storage:**
    - Ensure the slicer is clean and unplugged.
    - Press the release button and gently fold the food carriage and base back into the compact storage position.



Figure 5: The GRAEF MYtiny slicer shown in its compact, folded state, ready for storage. This highlights its space-saving design.



Figure 6: The folded GRAEF MYtiny slicer neatly stored inside a kitchen drawer, demonstrating its ultra-compact storage capability.

Care and Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your GRAEF MYtiny Food Slicer.

- **Cleaning:**
  - Always unplug the slicer before cleaning.
  - The manufacturer recommends **Hand Wash Only** for all removable parts. Do not place parts in a dishwasher.
  - Wipe the motor housing with a damp cloth. Never immerse the motor unit in water.
  - Carefully remove the blade (refer to specific instructions if provided for blade removal, otherwise clean in place with extreme caution). Use a brush to remove food particles.
  - Clean the food carriage and food holder with warm, soapy water. Rinse thoroughly and dry completely before reassembly or storage.
- **Blade Care:** The blade is made of stainless steel. To maintain its sharpness and prevent corrosion, clean it immediately after use and dry it thoroughly.

- **Storage:** Ensure the slicer is clean, dry, and folded into its compact position before storing. Store in a dry place, away from direct sunlight and moisture.

Troubleshooting

If you encounter issues with your GRAEF MYtiny Food Slicer, please consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Slicer does not turn on.	Not plugged in. Power switch is OFF. Thickness dial not set past '0' (safety lock engaged).	Ensure the power cord is securely plugged into a working outlet. Turn the power switch to ON. Rotate the thickness adjustment dial to a setting greater than '0'.
Slices are uneven or ragged.	Blade is dull or dirty. Food not properly secured. Incorrect slicing technique.	Clean the blade thoroughly. If dull, consider professional sharpening or replacement. Ensure the food holder firmly secures the food against the food carriage. Apply even, gentle pressure when pushing the food carriage.
Slicer makes unusual noise.	Food obstruction. Loose parts.	Turn off and unplug the slicer. Check for any food particles obstructing the blade or motor. Ensure all removable parts are correctly assembled and secured.

Technical Specifications

- **Model:** MT1003
- **Brand:** GRAEF
- **Product Dimensions (Unfolded):** 13.58" L x 9.21" W x 7.17" H
- **Folded Height:** Approximately 8 cm (3.15 inches)
- **Material:** Metal, Stainless Steel
- **Color:** Red
- **Blade Material:** Stainless Steel
- **Blade Diameter:** 170mm (wavy sharpening knife)
- **Cutting Thickness:** 0 - 15 mm (continuously adjustable)
- **Operation Mode:** Automatic
- **Item Weight:** 3.3 Kilograms (7.26 pounds)
- **Special Features:** Compact, Foldable, Multipurpose, Powerful Motor, Removable Blade

Warranty and Customer Support

GRAEF products are manufactured with high-quality materials and undergo strict quality control. For information regarding

warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official GRAEF website.
For technical assistance, spare parts, or any questions not covered in this manual, please contact GRAEF customer support. Contact details can typically be found on the official GRAEF website or on your product's packaging.

© 2024 GRAEF. All rights reserved.