

[manuals.plus](#) /› [Consciōt](#) /› [Consciōt 44 inch Low Profile Ceiling Fan User Manual](#)**Consciōt CL17001226**

Consciōt 44 inch Low Profile Ceiling Fan User Manual

Model: CL17001226 | Brand: Consciōt

1. INTRODUCTION

Thank you for choosing the Consciōt 44 inch Low Profile Ceiling Fan. This modern ceiling fan is designed to provide efficient air circulation and customizable lighting for both indoor and covered outdoor spaces. Featuring a quiet, reversible DC motor, 6-speed settings, and a dimmable LED light with 3 color temperatures, this fan offers comfort and convenience. Please read this manual thoroughly before installation and operation to ensure proper use and safety.



Image 1.1: Conscient 44 inch Low Profile Ceiling Fan with included remote control and downrods.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or personal injury, always follow these basic safety precautions:

- Read all instructions before installing the fan.
- Ensure the power is turned off at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unsure, consult a qualified electrician.
- The fan must be mounted to a ceiling joist or support structure capable of supporting a minimum of 35 lbs (15.9 kg).
- Do not operate the fan with damaged blades or housing.
- Keep hands, hair, and clothing away from moving fan blades.
- This fan is damp-rated, suitable for indoor and covered outdoor use. Do not expose to direct rain or water.

3. PRODUCT SPECIFICATIONS

Feature	Description
Brand	Conscient

Feature	Description
Model Name	CL17001226
Size	44 inches
Color	White
Motor Type	Reversible DC Motor
Speed Settings	6
Noise Level	Max 42 dB
Air Flow Capacity	4544 Cubic Feet Per Minute (CFM)
Light Output	1500 LM LED
Color Temperature	3000K (Warm White), 4000K (Cool White), 5000K (Daylight)
Dimmable	Yes (5%-100%)
Control Method	Remote Control
Timer Settings	2H/4H
Included Components	Ceiling fan, Light Kit, Remote, 5" and 10" Downrods
Indoor/Outdoor Usage	Indoor, Covered Outdoor (Damp-rated)
Sloped Ceiling Support	Up to 15°

42dB Max Super Quiet



Image 3.1: Detailed dimensions of the ceiling fan and recommended room sizes (10ft x 10ft to 18ft x 18ft).

Light & Wind Memory Function , without any waiting time or gap

The fan light will memorize your settings for every time the light/fan turned on



Image 3.2: Illustration of the fan's damp rating, indicating suitability for bedrooms, laundry rooms, kitchens, and covered patios.

4. INSTALLATION GUIDE

This section provides step-by-step instructions for installing your ceiling fan. It is recommended to have two people for installation.

4.1 Pre-Installation Checklist

- Ensure all components listed in the package contents are present.
- Turn off power at the main circuit breaker.
- Confirm the mounting location can support the fan's weight.

4.2 Mounting Options

The fan supports both flat and sloped ceiling installations (up to 15 degrees). Two downrod lengths (5" and 10") are provided for flexible mounting.



Image 4.1: Visual guide for flat mount and sloped mount ceiling installations, including minimum height requirements.

4.3 Wiring and Assembly

Follow the detailed wiring diagram provided in the physical manual. Connect the fan to the power supply according to local electrical codes. Once wiring is complete, attach the fan blades and the light kit securely.

Image 4.2: Example of the ceiling fan installed in a bedroom, demonstrating its aesthetic integration.

5. OPERATING INSTRUCTIONS

Your Conscient ceiling fan is controlled by the included remote. Ensure 2 AAA batteries (not included) are installed in the remote.

5.1 Remote Control Functions

- **Fan On/Off:** Powers the fan on or off.
- **6 Level Speeds:** Adjusts fan speed from 1 (lowest) to 6 (highest).
- **Light On/Off:** Turns the LED light on or off.
- **Dimming +/-:** Adjusts the brightness of the light from 5% to 100%.
- **3CCT (Color Temperature Change):** Cycles through Warm White (3000K), Cool White (4000K), and Daylight (5000K).
- **Reversible Switch:** Changes the direction of the fan blades for summer (clockwise, cooling) or winter (anti-clockwise, air circulation) modes.

- **Timer Setting:** Sets the fan to turn off automatically after 2 or 4 hours.
- **Natural Wind:** Simulates a natural breeze by varying fan speeds.



Image 5.1: Detailed diagram of the remote control, highlighting each button's function.

1500LM Customizable Light



Image 5.2: Visual representation of the 1500LM customizable LED light, showing 3000K, 4000K, and 5000K color temperatures and 5%-100% dimming capability.

5.2 Reversible DC Motor Function

The reversible DC motor allows you to change the direction of the fan's rotation to optimize air circulation for different seasons.

- **Summer Mode (Clockwise Rotation):** Pushes air downwards, creating a cooling breeze.
- **Winter Mode (Anti-Clockwise Rotation):** Draws air upwards, circulating warm air trapped near the ceiling.

6 Speeds and Reversible



Image 5.3: Illustration demonstrating the airflow direction for summer (cooling) and winter (air circulation) modes.

5.3 Memory Function

The fan and light settings will be memorized after power loss, ensuring your preferred settings are restored when the fan is turned back on.



Image 5.4: Depiction of the fan's memory function, showing settings retention after power cycles.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Blade Care:** Periodically check blade screws for tightness. Loose blades can cause wobbling and noise.
- **Light Kit:** The LED light source is integrated and not user-replaceable. If issues arise, contact customer support.

7. TROUBLESHOOTING

If you encounter any issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control issues.	Check circuit breaker; Verify all wire connections are secure; Replace remote batteries; Re-pair remote if necessary.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use balancing kit (not included) if needed; Ensure mounting bracket is securely fastened.
Light does not work	Loose wire connection to light kit; Remote control issue.	Check light kit wiring; Replace remote batteries; Ensure light button on remote is pressed.
Fan is noisy	Loose screws; Motor hum; Blades hitting an obstruction.	Tighten all screws; Ensure fan is securely mounted; Check for any obstructions in the fan's path.

If the problem persists after trying these solutions, please contact Conscient customer support.




Image 7.1: The fan operates at a maximum of 42dB, ensuring quiet performance suitable for bedrooms.

8. WARRANTY AND SUPPORT

Conscient is committed to providing high-quality products and excellent customer service. Your Conscient 44 inch Low Profile Ceiling Fan comes with a **24-month worry-free warranty** for the motor and accessories.

For any product problems, technical assistance, or warranty claims, please contact our dedicated after-sales team. Refer to the contact information provided in your product packaging or visit the official Conscient website for support details. We value your satisfaction and are here to assist you.

Related Documents - CL17001226

	<p>Ceiling Fan Remote Control General Information and Operation</p> <p>This document provides general information, installation instructions, and operating procedures for a ceiling fan remote control system. It covers safety precautions, wiring diagrams, transmitter operation, and code setting between the remote and receiver.</p>
<p>Consciolt LED LANTERN</p> <p>Operation Guide For your safety, read before operating</p>  <p>Every purchase comes with an extended one-year return policy and friendly customer service provided by Consciolt.</p>	<p>Consciolt LED Lantern Operation Guide - Model ZY-CL503R</p> <p>Comprehensive operation guide for the Consciolt LED Lantern (Model ZY-CL503R), detailing package contents, specifications, operating modes, charging instructions, and warranty information.</p>
<p>TROUBLESHOOTING</p> 	<p>Consciolt Smart Bulb Troubleshooting Guide: Setup and Connectivity Issues</p> <p>A comprehensive troubleshooting guide for Consciolt smart bulbs, addressing common setup failures with Apple Home, Alexa, and general connectivity issues. Learn how to resolve pairing errors, device not found, offline status, and more.</p>
	<p>Consciolt C10 Rechargeable Disassembly Free Lantern User Manual</p> <p>User manual for the Consciolt C10 rechargeable lantern, detailing specifications, operation modes (floodlight, spotlight, red light), maintenance, and charging instructions for this disassembly-free LED light.</p>
<p>Consciolt LED LANTERN</p> <p>Operation Guide For your safety, read before operating</p>  <p>Every purchase comes with an extended one-year return policy and friendly customer service provided by Consciolt.</p>	<p>Consciolt LED Lantern (ZY-CL503) Operation Guide & Specifications</p> <p>Official operation guide and specifications for the Consciolt LED Lantern (Model ZY-CL503, AOL001-US-2-V1). Learn how to install batteries, operate modes, and understand its features. Includes warranty and contact information.</p>
<p>Consciolt</p> <p>User Manual Solar Landscape Light</p> 	<p>Consciolt Solar Landscape Light User Manual - Installation & Operation Guide</p> <p>Comprehensive user manual for the Consciolt Solar Landscape Light. Learn about specifications, installation, operation modes, warm tips, and troubleshooting for your outdoor solar lighting.</p>