Hendari P98CX3

Hendari Smart Watch P98CX3 User Manual

Model: P98CX3

Contents Introduction Package Setup Operation Maintenance Troubleshooting Specifications Warranty Support

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Hendari Smart Watch P98CX3. This device features a 1.96-inch HD touchscreen, Bluetooth calling capabilities, comprehensive health monitoring, and support for over 140 sports modes. Please read this manual thoroughly to ensure proper use and to maximize your experience with the smartwatch.

2. What's in the Box

Verify that all items are present in your product package:

- Hendari Smart Watch P98CX3
- Charging Cable (Magnetic USB)
- Quick Guide & User Manual

3. Setup

3.1 Charging the Smart Watch

Before initial use, fully charge your smartwatch. Connect the magnetic charging cable to the charging points on the back of the watch and to a standard USB power adapter (not included). A full charge typically takes approximately 2 hours.



Image: The smartwatch being charged via its magnetic USB cable. This image also highlights the IP68 waterproof rating and battery performance, including 30 days standby, 7 days battery life, and 2 hours charging time.

A full charge provides up to 7 days of typical usage or 30 days of standby time.

3.2 App Installation and Device Pairing

To unlock the full functionality of your smartwatch, download and install the **GloryFit** app on your smartphone. The app is compatible with both Android and iOS devices.

1. Scan the QR code provided in the quick guide or search for "GloryFit" in your smartphone's app store.
2. Install and open the GloryFit app.
3. Follow the on-screen instructions in the app to create an account and set up your personal profile.
4. In the app, navigate to the device section and select "Add Device."
5. The app will search for your smartwatch. Select "P98CX3" from the list of available devices to pair.
6. Confirm the pairing request on both your smartphone and the smartwatch.

For Bluetooth calling functionality, ensure your watch is also connected via your phone's Bluetooth settings. Go to your phone's Bluetooth settings, search for the watch (it might appear as 'P98CX3_CALL' or similar), and pair it.

4. Operation

4.1 Basic Navigation

The Hendari Smart Watch P98CX3 features a full-touch color screen for intuitive navigation:

- **Swipe Up/Down:** Scroll through menus and notifications.
- **Swipe Left/Right:** Access quick functions or different widgets.
- **Tap:** Select an item or confirm an action.
- **Press Side Button:** Return to the home screen or power on/off.

4.2 Customizable Watch Dials

Personalize your smartwatch display. The GloryFit app offers over 200 online dial backgrounds. You can also upload your own photos to create custom watch faces.



Image: The smartwatch display showcasing various functional icons and features available, including health monitoring, utility tools, and notification controls.

4.3 Health Monitoring

The smartwatch is equipped with high-precision motion sensors to monitor your health metrics:

- **Heart Rate Monitor:** Provides 24-hour continuous heart rate tracking.
- **Blood Oxygen (SpO2) Monitor:** Measures blood oxygen levels.
- **Sleep Monitor:** Tracks sleep patterns, including deep sleep and light sleep, to help you understand and improve your sleep habits.



Image: Visual representation of the smartwatch's heart rate and sleep monitoring functions, showing data display during activity and rest.

4.4 Activity and Sports Tracking

The watch supports over 140 sports modes, including running, dancing, yoga, cycling, and hiking. It functions as a pedometer, tracking steps, calories burned, distance, and exercise time. Real-time data helps adjust training intensity.



Image: The smartwatch tracking various sports activities, demonstrating its capability to record exercise data for over 140 different modes.

4.5 Bluetooth Call and Notifications

With its built-in microphone and speaker, the smartwatch allows you to make and receive calls directly from your wrist when connected via Bluetooth to your smartphone. It also supports AI voice assistants.



Image: The smartwatch showing an incoming call and the various Bluetooth call features, including the ability to dial, view contacts, and access call history.

Receive notifications for messages from various apps such as Facebook, WhatsApp, Instagram, and more, directly on your watch display.



Image: The smartwatch screen showing notifications from multiple applications, demonstrating its message alert capabilities.

4.6 Additional Smart Features

The smartwatch includes several practical functions:

- Weather Forecast
- Brightness Adjustment
- Stopwatch
- Alarm Clock
- Sedentary Reminder
- Find Watch Function
- Music Control
- Camera Remote Control
- Do Not Disturb Mode
- Breathe Training

- Weekly Report (via app)

5. Maintenance

5.1 Water Resistance

The Hendari Smart Watch P98CX3 is IP68 waterproof, meaning it is resistant to dust and can withstand immersion in water up to 1.5 meters for 30 minutes. It is suitable for daily activities such as bathing, sweating during exercise, and exposure to rain.

Important: The watch is not suitable for hot water baths, saunas, or deep diving. Avoid exposing the watch to hot water or steam, as this can compromise the waterproof seals.

5.2 Cleaning and Care

- Regularly clean the watch and strap with a soft, dry cloth.
- If necessary, use a slightly damp cloth to wipe away dirt, then dry thoroughly.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the watch's finish and components.
- Keep the charging contacts clean and dry to ensure efficient charging.

6. Troubleshooting

If you encounter issues with your smartwatch, try the following solutions:

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charging cable and allow it to charge for at least 10 minutes before attempting to power it on.
- **Cannot pair with phone:** Make sure Bluetooth is enabled on your phone and the watch. Ensure the watch is within range of your phone. Restart both the watch and your phone, then try pairing again through the GloryFit app.
- **Notifications not received:** Check that notifications are enabled in both the GloryFit app and your phone's system settings for the relevant applications. Ensure the watch is properly connected via Bluetooth.
- **Inaccurate health/activity data:** Ensure the watch is worn snugly on your wrist, about one finger's width above your wrist bone. For GPS-related tracking, note that the watch uses your smartphone's GPS, so your phone must be with you during outdoor activities for accurate route mapping and distance.
- **Bluetooth call issues:** Verify that the watch is connected for calls in your phone's Bluetooth settings (e.g., 'P98CX3_CALL'). Check the volume settings on both the watch and your phone.

For further assistance, consult the help section within the GloryFit app or contact Hendari customer support.

7. Specifications

Feature	Detail
Model Name	P98CX3
Brand	Hendari
Screen Size	1.96 Inches
Display Type	Digital, High Definition
Operating System	Android, iOS

Connectivity Technology	Bluetooth
Battery Capacity	300 Milliamp Hours
Battery Life (Typical Use)	Up to 7 days
Standby Time	Up to 30 days
Charging Time	Approx. 2 hours
Water Resistance Rating	IP68 (1.5 meters depth)
GPS	Via Smartphone
Health Metrics Measured	Heart Rate, Blood Oxygen, Sleep
Sports Modes	140+
Band Material	Silicone

8. Warranty Information

The Hendari Smart Watch P98CX3 comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual. Please retain your proof of purchase for warranty claims.

9. Support

For additional support, frequently asked questions, or to troubleshoot specific issues, please refer to the **GloryFit app**. The app often contains updated information and guides.
You may also visit the official Hendari store on Amazon for product information and customer service inquiries: Hendari Store

© 2024 Hendari. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question