Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Teufel 107002084

ROCKSTER AIR 2 Backpack Instruction Manual

Premium Transport System with Stable, Lightweight Aluminum Frame

Product Overview

The Teufel ROCKSTER AIR 2 Backpack is a premium carrying system designed specifically for the Fender x Teufel ROCKSTER AIR 2 speaker. Developed in partnership with deuter, a renowned backpack manufacturer, this system features a stable, lightweight aluminum frame to ensure secure and comfortable transport of your speaker.
Key features include thick and wide padding for shoulder straps and the back area, along with a stable, padded hip belt for optimal weight distribution, enhancing user comfort during extended periods of carrying.



Figure 1: Rear view of the ROCKSTER AIR 2 Backpack, highlighting the ergonomic design with thick padding on the shoulder straps and hip belt for enhanced comfort and support.



Figure 2: Side view illustrating the stable, lightweight aluminum frame that forms the core structure of the backpack, providing robust support for the speaker.



Figure 3: The Fender x Teufel ROCKSTER AIR 2 speaker securely attached to the backpack frame, demonstrating how the safety straps keep it firmly in place.



Figure 4: Side profile of the speaker mounted on the backpack, illustrating the precise fit and the positioning of the safety straps for stability.

Setup Instructions

1. **Unpack the Backpack:** Carefully remove the ROCKSTER AIR 2 Backpack from its packaging. Inspect all components for any signs of damage.
2. **Prepare the Speaker:** Ensure your Fender x Teufel ROCKSTER AIR 2 speaker is ready for transport. Make sure all cables are disconnected and any accessories are removed or secured.
3. **Mount the Speaker:** Position the ROCKSTER AIR 2 speaker onto the aluminum frame of the backpack. The base of the speaker should rest securely on the bottom support of the frame.



Ensure the speaker is centered and stable on the frame.

4. **Secure with Safety Straps:** Utilize the integrated safety straps to firmly secure the speaker to the backpack frame. There are typically straps that go around the body of the speaker. Tighten these straps until the speaker is snug and does not shift.



Verify that all straps are securely fastened and adjusted.

5. **Adjust Shoulder Straps:** Put on the backpack. Adjust the shoulder straps to ensure the weight is distributed comfortably across your shoulders. The thick padding should rest flat against your body.
6. **Fasten Hip Belt:** Engage the hip belt and tighten it around your hips. The padded hip belt is crucial for transferring the speaker's weight to your hips, reducing strain on your shoulders and back.
7. **Final Adjustments:** Make any final adjustments to the shoulder straps, hip belt, and sternum strap (if present) to achieve a balanced and secure fit. The backpack should feel stable and comfortable, even with the speaker loaded.

Operating Instructions

The ROCKSTER AIR 2 Backpack is designed for straightforward operation once the speaker is securely mounted and the straps are adjusted.

- **Carrying the Speaker:** With the speaker securely attached and the backpack properly adjusted, you can now comfortably transport your Fender x Teufel ROCKSTER AIR 2. The design allows for easy movement while keeping the speaker stable.



The backpack allows for comfortable transport of the speaker.

- **Accessing Speaker Controls:** While the speaker is mounted, its controls and ports may be partially obstructed. For full access, it is recommended to unmount the speaker from the backpack.
- **Removing the Speaker:** To remove the speaker, unfasten all safety straps. Carefully lift the speaker off the aluminum frame. Ensure the backpack is placed on a flat, stable surface during this process.

Maintenance

Proper maintenance will extend the lifespan of your ROCKSTER AIR 2 Backpack.

- **Cleaning:** Clean the backpack with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before storage.
- **Storage:** Store the backpack in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is clean and dry before storing to prevent mold or mildew.
- **Inspection:** Periodically inspect all straps, buckles, and the aluminum frame for signs of wear, tear, or damage. Address any issues promptly to maintain safety and functionality.

Troubleshooting

Problem	Possible Cause	Solution
Speaker feels unstable or shifts during transport.	Safety straps are not tightened sufficiently.	Ensure all safety straps are pulled taut and securely fastened around the speaker. Verify the speaker is properly seated on the frame.
Discomfort in shoulders or back.	Improper adjustment of shoulder straps or hip belt.	Adjust shoulder straps to ensure even weight distribution. Tighten the hip belt to transfer more weight to your hips. Ensure the backpack is worn high enough on your back.
Buckles or straps are difficult to operate.	Dirt or debris in buckles; straps are twisted.	Clean buckles if necessary. Untwist any straps. If a buckle is damaged, contact customer support.

Specifications

- **Product Dimensions:** 11.42 x 18.11 x 22.83 inches
- **Item Weight:** 8.06 pounds
- **Model Number:** 107002084
- **Color:** Black
- **Compatible Devices:** Fender x Teufel ROCKSTER AIR 2
- **Manufacturer:** Teufel
- **Country of Origin:** Vietnam
- **Special Features:** Portable, Backpack, Lightweight, Comfortable, Adjustable
- **Mounting Type:** Backpack Strap Mount

Warranty and Support

For information regarding warranty coverage and customer support for your Teufel ROCKSTER AIR 2 Backpack, please refer to the official Teufel website or contact their customer service directly.
You can visit the Teufel Store on Amazon for more product information and support resources.
For protection plans, consider options available at the time of purchase:

- 2-Year Protection Plan (ASIN: B07P83ZFZR)
- 3-Year Protection Plan (ASIN: B07PC66X77)
- Complete Protect (Monthly plan)

© 2024 Teufel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5D9WL7Y

More documents and user manuals: **https://manuals.plus/**