

- Manuals.plus /
- › Vicco /
- › Vicco Melisa Dressing Table with Lighting and Stool - Instruction Manual

Vicco Melisa 20996

Vicco Melisa Dressing Table with Lighting and Stool - Instruction Manual

Model: Melisa 20996 | Brand: Vicco

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Vicco Melisa Dressing Table. Designed with integrated lighting and an accompanying stool, this dressing table offers a functional and elegant solution for your cosmetic needs. Please read these instructions carefully before assembly and use to ensure safe and correct operation.



Image 1.1: The Vicco Melisa Dressing Table with its integrated lighting and matching stool, presented in a modern room environment.

2. SAFETY INFORMATION

- Always follow the assembly instructions precisely. Incorrect assembly can lead to instability and potential injury.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers or surfaces. Refer to specifications for weight limits if available.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- If the dressing table is designed to be wall-mounted, ensure it is securely fastened to a suitable wall structure to prevent tipping.
- Disconnect the power supply to the lighting before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Dressing table unit with integrated mirror and lighting
- Adjustable stool
- Assembly instructions manual
- Mounting hardware (screws, dowels, etc.)



Image 3.1: An overview of the main components of the Vicco Melisa Dressing Table and its accompanying stool.

4. SPECIFICATIONS

Feature	Detail
Brand	Vicco

Feature	Detail
Model Name	Melisa
Model Number	20996 (also 47689)
Color	Oak/Grey
Overall Dimensions (L x W x H)	40 cm x 120 cm x 161.1 cm
Item Weight	36.75 kg
Dressing Table Material	16 mm Melamine-coated Particle Board
Mirror Material	Glass
Stool Seat Material	Faux Leather
Number of Drawers	2
Assembly Required	Yes
Seat Height (Stool)	Adjustable, 52-65 cm





Image 4.1: Technical drawing illustrating the dimensions of the dressing table and stool components.

Energy Efficiency Information

The integrated lighting system has an energy efficiency rating. For detailed information, please refer to the energy label:



Further details can be found on the EPREL database: <https://eprel.ec.europa.eu/qr/1731338>

5. SETUP AND ASSEMBLY

Assembly of the Vicco Melisa Dressing Table requires careful attention to detail. Please follow the included graphical assembly instructions step-by-step. It is recommended to have two people for assembly.

5.1 Preparation

1. Clear a spacious, clean area for assembly.
2. Lay out all components and hardware. Check against the parts list in the separate assembly instructions.
3. Gather necessary tools (e.g., screwdriver, hammer, level).

5.2 Assembly Steps (General Guidance)

1. **Assemble the Dressing Table Frame:** Connect the main panels according to the diagrams, ensuring all cam locks and dowels are properly seated.
2. **Install Drawers:** Assemble the drawer boxes and attach the drawer slides to both the drawers and the main table unit. Insert the drawers into their respective compartments.
3. **Attach Mirror and Lighting:** Secure the mirror panel to the main unit. Connect the integrated lighting system as per electrical diagrams, ensuring all connections are safe and secure.
4. **Wall Mounting:** Due to its design, the dressing table unit must be securely mounted to a solid wall using the provided mounting hardware. Use a level to ensure it is straight.
5. **Assemble the Stool:** Attach the seat to the base and connect the hydraulic lift mechanism. Ensure the stool is stable and the height adjustment functions correctly.




Image 5.1: A detailed view of the integrated LED lighting strip around the mirror, providing optimal illumination.

6. OPERATING INSTRUCTIONS

6.1 Using the Drawers

The dressing table features two smooth-gliding drawers for storing cosmetics and accessories. To open, gently pull the drawer front. To close, push until it is fully recessed. Avoid forcing the drawers if they encounter resistance.



Image 6.1: One of the two drawers fully extended, revealing ample storage space for various items.



Image 6.2: A closer look at the drawer interior, demonstrating its capacity for organizing cosmetics.

6.2 Operating the Mirror Lighting

The integrated mirror lighting is typically operated via a discreet switch or touch sensor located on or near the mirror.

Refer to the specific instructions for your lighting unit for details on turning it on/off and adjusting brightness, if applicable.

6.3 Adjusting the Stool Height

The accompanying stool features a hydraulic lift mechanism for height adjustment. To raise the seat, lift the lever while standing. To lower the seat, sit on the stool and lift the lever. Release the lever to lock the height in place.

7. MAINTENANCE

7.1 Cleaning

- **Dressing Table Surfaces:** Wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the melamine finish. Dry immediately with a clean cloth.
- **Mirror:** Use a standard glass cleaner and a lint-free cloth. Spray cleaner onto the cloth, not directly onto the mirror, to prevent liquid from seeping into edges.
- **Stool (Faux Leather):** Wipe with a damp cloth and mild soap solution. Do not soak. Dry thoroughly.

7.2 General Care

- Avoid direct sunlight and extreme temperature changes to prevent material warping or discoloration.
- Do not place hot items directly on the surface without protection.
- Regularly check all fasteners and re-tighten if necessary to maintain stability.

8. TROUBLESHOOTING

- **Lighting not working:** Check power connection. Ensure the switch is in the 'on' position. If the issue persists, consult a qualified electrician.
- **Drawers sticking or not closing smoothly:** Check if the drawer slides are clean and free of obstructions. Ensure the drawer is correctly aligned on its runners. Verify that all assembly screws for the slides are tight.
- **Table feels wobbly:** Re-check all assembly screws and wall mounting points. Ensure the wall mounting is secure and the wall material is appropriate for the anchors used.
- **Stool height adjustment not working:** Ensure the lever mechanism is not obstructed. If the hydraulic cylinder is faulty, contact customer support for replacement parts.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided at the time of purchase or contact your retailer. If you require assistance with assembly, missing parts, or have any questions regarding your Vicco Melisa Dressing Table, please contact Vicco customer support or your point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D5DH3RYH>

More documents and user manuals: **<https://manuals.plus/>**