Manuals+

Q & A | Deep Search | Upload

BLW-BT940GD

Generic BLW-BT940GD Flex Around-the-Neck Wireless Earbuds User Manual

Model: BLW-BT940GD | Brand: Generic

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Generic BLW-BT940GD Flex Around-the-Neck Wireless Earbuds. Please read this manual thoroughly before using the product to ensure proper function and longevity.




Figure 1: Generic BLW-BT940GD Flex Around-the-Neck Wireless Earbuds. These earbuds feature a flexible neckband design with gold accents and in-ear buds.

PACKAGE CONTENTS

- Generic BLW-BT940GD Flex Around-the-Neck Wireless Earbuds
- Ear Cushions (various sizes)
- USB Charging Cable
- User Manual (this document)

SETUP

1. Charging the Earbuds

Before first use, fully charge the earbuds. Connect the provided USB charging cable to the charging port on the neckband and plug the other end into a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status and turn off or change color when fully charged.

2. Powering On/Off

- Power On: Press and hold the Power button (usually located on the neckband) for approximately 3-5 seconds until the LED indicator flashes.
- Power Off: Press and hold the Power button for approximately 3-5 seconds until the LED indicator turns off.

3. Bluetooth Pairing

- 1. Ensure the earbuds are powered off.
- 2. Press and hold the Power button for 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
- 3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
- 4. Select "BLW-BT940GD" from the list of found devices.
- 5. Once paired, the LED indicator will flash blue slowly, and you may hear an audible confirmation.

Note: The earbuds will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Controls

The control buttons are typically located on one side of the neckband. Refer to the diagram below for button identification (assuming standard layout).




Figure 2: Control buttons on the left side of the neckband. From top to bottom: Volume Up/Next Track, Multi-function Button (Power/Play/Pause/Call), Volume Down/Previous Track.

Earbud Control Functions

Button/Action	Function		
Power Button (Multi-function)	Press & Hold (3-5s): Power On/Off Press & Hold (5-7s): Enter Pairing Mode Single Press: Play/Pause music, Answer/End call Double Press: Redial last number		
Volume Up (+)	Single Press: Increase Volume Press & Hold: Next Track		

Button/Action	Function	
Volume Down (-)	Single Press: Decrease Volume Press & Hold: Previous Track	

Making and Receiving Calls

The built-in microphone allows for hands-free calling when connected to your smartphone.

- Answer Call: Press the Multi-function button once.
- End Call: Press the Multi-function button once during a call.
- Reject Call: Press and hold the Multi-function button for 2 seconds.
- Redial: Double-press the Multi-function button to redial the last number.

MAINTENANCE

- Cleaning: Use a soft, dry cloth to clean the earbuds and neckband. Do not use harsh chemicals or abrasive materials.
- Storage: Store the earbuds in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds frequently. Charge them regularly, even if not in use for extended periods.
- Ear Cushions: Periodically remove and clean the ear cushions with a damp cloth. Ensure they are completely dry before reattaching.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Solution
Earbuds won't turn on.	Ensure the earbuds are fully charged. Connect to a power source and allow sufficient charging time.
Cannot pair with device.	Ensure earbuds are in pairing mode (flashing red/blue). Make sure Bluetooth is enabled on your device. Move the earbuds closer to your device. Forget "BLW-BT940GD" from your device's Bluetooth list and try pairing again. Restart both the earbuds and your device.
No sound or low volume.	Increase volume on both the earbuds and your connected device. Ensure the earbuds are properly paired and connected. Check if the audio output on your device is set to the earbuds.
Poor sound quality or disconnections.	Move closer to your connected device to reduce interference. Avoid obstacles between the earbuds and your device. Ensure no other Bluetooth devices are causing interference. Re-pair the earbuds with your device.

SPECIFICATIONS

Feature	Detail			
Model Name	BLW-BT940GD			
Brand	Generic			
Connectivity Technology	Wireless (Bluetooth V5.0)			
Driver Unit	10mm Dynamic Driver			
Impedance	32 Ohms			
Frequency Range	20Hz - 20KHz			
Rated Power	150mW			
Battery Life	Up to 14 Hours Playtime			
Microphone	Built-in			
Design	Flexible Around-the-Neck			
Color	Gold			
Material	Flexible Material			
Dimensions (Package)	5.51 x 5.31 x 1.75 inches			
Item Weight	5.6 ounces (0.35 Pounds)			
Compatible Devices	Smartphones, Tablets, Laptops, Desktops, Smart TVs, Smart Speakers			

PRODUCT VIDEO

Your browser does not support the video tag.

Video: An overview of the Sentry BLW-BT940GD Wireless Earbuds, highlighting key features such as 14-hour playtime, Bluetooth 5.0 connectivity, built-in microphone, 10mm driver units, 32 Ohms impedance, and flexible around-the-neck design with a gold finish.

The video provides a visual demonstration of the product's design and features.

WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty. Please refer to the packaging or contact the retailer for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

SUPPORT

For technical support, troubleshooting assistance, or further inquiries, please contact the retailer or manufacturer directly. Refer to the product packaging for contact details.

Related Documents - BLW-BT940GD



Delmer Vacuum Pumps: Comprehensive Product Catalog and Technical Specifications

Explore the extensive range of Delmer vacuum pumps, including DEL-G, DEL, and BLW series, with detailed technical specifications, accessories, and model information for industrial and agricultural applications.



Wilfa SMOOTH 1000 Blender BLW-1000 Instruction Manual

User manual and safety instructions for the Wilfa SMOOTH 1000 blender (model BLW-1000), covering operation, cleaning, specifications, and warranty.



Manual de Usuario Cucharas de Aprendizaje BLW Sensbaby

Guía completa del usuario para las cucharas de aprendizaje BLW Sensbaby, cubriendo descripción del producto, uso previsto, instrucciones, mantenimiento, información legal y advertencias de seguridad.



Baby's First Foods Weaning Chart | Nombear

A comprehensive guide from Nombear for introducing first foods to babies, featuring lists of vegetables, fruits, proteins, grains, dairy, herbs, spices, and common allergens, along with essential weaning advice.



Baby's First Foods Weaning Chart by Nombear

Comprehensive guide for introducing first foods to babies, featuring Nombear's weaning chart. Lists vegetables, fruits, proteins, grains, dairy, herbs, spices, and common allergens with checkboxes. Includes advice on textures, choking prevention, and NHS guidelines.



DynaLabs DYN-PM-250 250 N PM Shaker Product Manual - Specifications, Operation, and Safety

Model DYN-PM-250 250 N PM Shaker Product Manual Detailed product manual for the DynaLabs DYN-PM-250 250 N PM Shaker. Includes system components, specifications, operation, installation, maintenance, troubleshooting, and safety guidelines for modal testing applications.