

LUCYPAL 169

LUCYPAL Slim Shoe Cabinet with 3 Flip Drawers (Model 169) Instruction Manual

Model: 169 | Brand: LUCYPAL

INTRODUCTION

Thank you for choosing the LUCYPAL Slim Shoe Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- Avoid placing heavy objects on the top surface of the cabinet to prevent tipping.
- Secure the cabinet to the wall using the provided anti-tipping device. This is crucial to prevent accidental tip-overs, especially in households with children or pets.
- Exercise caution when opening and closing the flip drawers to prevent finger pinching.
- Ensure all screws and fasteners are tightened securely during assembly and periodically check for tightness.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Top, Bottom, Sides, Back)
- Flip Drawer Assemblies (3 sets)
- Adjustable Shoe Baffles
- Hardware Pack (Screws, dowels, anti-tipping device, etc.)
- Assembly Instructions Manual

ASSEMBLY INSTRUCTIONS

Follow the detailed, step-by-step instructions provided in the included assembly manual. All parts are numbered for easy identification.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the numbering system in the assembly guide.
2. **Assemble the Main Frame:** Connect the side panels to the top and bottom panels using the designated hardware. Ensure all connections are secure.
3. **Install Back Panel:** Attach the back panel to the assembled frame.
4. **Assemble Flip Drawers:** Construct each of the three flip drawers according to the instructions. Pay close attention to the orientation of the components.
5. **Insert Shoe Baffles:** Place the adjustable shoe baffles inside each flip drawer. These can be adjusted to accommodate different shoe sizes and types.
6. **Attach Drawers to Frame:** Secure the assembled flip drawers to the main cabinet frame.
7. **Wall Mounting (Crucial Safety Step):** Locate a suitable wall position. Use the provided anti-tipping device to firmly secure the cabinet to the wall. This prevents the cabinet from falling forward.

Note: Installing screws may be easier and faster with an electric screwdriver.

SIZE




Image: Dimensions of the LUCYPAL Shoe Cabinet. Height: 43.01", Width: 31.5", Depth: 5.98".



Image: LUCYPAL Shoe Cabinet with all three flip drawers open, illustrating internal storage.

Suit for Different Home Layout



Image: Close-up of the flip drawer mechanism and adjustable shoe baffle.

OPERATING INSTRUCTIONS

The LUCYPAL Shoe Cabinet features three flip drawers designed for efficient shoe storage.

- **Opening Drawers:** Gently pull the top edge of each drawer outwards to flip it open. The drawers are designed to tilt forward, providing easy access to your shoes.
- **Storing Shoes:** Place shoes into the compartments within each drawer. The adjustable shoe baffles can be repositioned to accommodate different shoe sizes and types, such as high heels, sneakers, leather shoes, and slippers. Each drawer can typically hold 2-4 pairs of shoes depending on their size.
- **Closing Drawers:** Push the drawer back into the cabinet until it is flush with the cabinet front. Ensure it closes completely to keep dust out and maintain a neat appearance.



Image: Shoe cabinet with various shoes stored in its flip drawers.

Details in the Shoe Storage Cabinet



Spacious Tabletop

The spacious top surface is perfect for accessories, keys, wallets, etc., making it easier for



Apmle Stroage space

Suitable for different types of shoes, can fully meet your storage needs



Adjustable shoe baffle

The adjustable shoe baffle is designed to better organize the shoe cabinet and make it tidy



Sturdy Structure

More stable and safe, lasts a long time use.

Image: Adjustable shoe baffle for organizing shoes within the cabinet.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your shoe cabinet, follow these simple care guidelines:

- **Cleaning:** The cabinet features a smooth, easy-to-clean surface. Wipe down with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth to prevent dust buildup.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the surface.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.



Image: Features of the cabinet: friction resistance, waterproof, and easy to clean surface.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not close smoothly	Obstruction, misaligned hardware, or overfilled drawer.	Check for items blocking the drawer. Ensure all hardware is correctly installed and tightened. Reduce the number of shoes if overfilled.
Cabinet feels unstable	Not properly wall-mounted, loose fasteners, or uneven floor.	Ensure the anti-tipping device is securely attached to the wall. Tighten all assembly screws. Place shims under the cabinet if the floor is uneven.
Difficulty during assembly	Incorrect part orientation, missing hardware, or unclear instructions.	Review the assembly manual carefully, paying attention to diagrams. Contact customer support if parts are missing or instructions are unclear.

SPECIFICATIONS

- **Brand:** LUCYPAL
- **Model Number:** 169
- **Color:** White
- **Material:** Metal (Frame, Top Material, Handle Material), Engineered Wood (Back Material)
- **Product Dimensions:** 5.98"D x 31.5"W x 43.01"H
- **Number of Flip Drawers:** 3
- **Number of Shelves:** 2 (internal to drawers)
- **Installation Type:** Freestanding with Wall Mount Anti-Tipping Device
- **Item Weight:** 33.3 pounds
- **Assembly Required:** Yes

PRODUCT VIDEO

Watch this video for a visual overview of the LUCYPAL Shoe Cabinet and its features.

Your browser does not support the video tag.

Video: Overview of the LUCYPAL Slim Shoe Cabinet's design and functionality.

WARRANTY AND SUPPORT

LUCYPAL stands behind the quality of its products. For specific warranty details, please refer to the warranty card included with your purchase or contact LUCYPAL customer service directly. If you encounter any issues or have questions regarding your shoe cabinet, please reach out to our support team for assistance.

Customer Support Contact: Please refer to the contact information provided in your purchase documentation or on the official LUCYPAL website.