



[Manuals.plus](#) /

> [KRPTQJoo](#) /

> KRPTQJoo RM-RK50 Remote Control User Manual for JVC Car Stereo Systems

KRPTQJoo RM-RK50

KRPTQJoo RM-RK50 Remote Control User Manual

For JVC Car Stereo Systems

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your KRPTQJoo RM-RK50 replacement remote control. This remote is designed to be compatible with various JVC car stereo system models, including KD-G386, KD-G385, KW-XG706, KD-G369, KD-R751, KW-R950BT, KD-RD99BTS, KD-RD79BT, KD-R452, KD-R451, KD-R995BTS, KD-R990BTS, and KD-R895BTS. Please read this manual thoroughly before use.



Image: Front view of the KRPTQJoo RM-RK50 remote control. It is black with blue circular buttons for navigation (Up, Down, Left, Right, Source) and a blue power button. Other buttons include Sound, Volume -, and Volume +.

SETUP

1. Battery Installation

The RM-RK50 remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery cover detached, revealing the battery compartment.



Image: Back of the remote control with the battery cover partially slid off, showing the mechanism for removal.

2. Compatibility Check

This remote control is a replacement unit. It is designed to work with the JVC car stereo models listed in the introduction. No pairing or programming is required. However, some buttons may not function if your specific JVC model does not support those features. Refer to your JVC car stereo's original manual for detailed feature support.

OPERATING INSTRUCTIONS

Point the remote control directly at the infrared receiver on your JVC car stereo system. Ensure there are no obstructions between the remote and the stereo.

Button Functions:

- **Power (U/ATT):** Turns the stereo system on or off, or activates the attenuator function.
- **Sound:** Accesses sound settings or audio modes.
- **VOL - / VOL +:** Adjusts the volume level down or up.
- **SOURCE:** Changes the audio source (e.g., Radio, CD, USB, Bluetooth).
- **Navigation Buttons (U, D, R, F):** Used for menu navigation, track skipping (Up/Down), or fast forward/rewind (Left/Right) depending on the active source and stereo model.




Image: Detailed view of the remote control's buttons, showing the Power, Sound, Volume, Source, and navigation controls.

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it stops responding. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If not used for extended periods, remove the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote does not work.	<ul style="list-style-type: none"> • Batteries are dead or incorrectly installed. • Obstruction between remote and stereo. • Remote is out of range. 	<ul style="list-style-type: none"> • Replace batteries, ensuring correct polarity. • Remove any objects blocking the signal path. • Move closer to the stereo system (maximum range is 8 meters).
Some buttons do not function.	<ul style="list-style-type: none"> • The specific JVC stereo model does not support that feature. • Incorrect mode selected on the stereo. 	<ul style="list-style-type: none"> • Refer to your JVC stereo's original manual for supported features. • Ensure the stereo is in the correct operating mode (e.g., CD mode for CD controls).

SPECIFICATIONS

- **Model Name:** RM-RK50

- **Brand:** KRPTQJoo
- **Color:** Black
- **Connectivity Technology:** Infrared (IR)
- **Maximum Range:** 8 Meters
- **Power Source:** 2 x AAA batteries (not included)
- **Compatible Devices:** JVC Car Stereo Systems (specific models listed in Introduction)
- **Max Number of Supported Devices:** 1

WARRANTY INFORMATION

This product is a replacement remote control. For specific warranty details, please refer to the seller's policy at the time of purchase. Typically, replacement parts may come with a limited warranty against manufacturing defects.

SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact the seller directly through the platform where the purchase was made. Provide your order number and a detailed description of the problem for prompt support.

For information regarding your JVC car stereo system's features and functions, please consult the original JVC user manual.