

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [EDISHINE](#) /

› [EDISHINE Minimalist LED Corner Floor Lamp \(Model B0D5HB2SL7\) Instruction Manual](#)

## EDISHINE B0D5HB2SL7

# EDISHINE Minimalist LED Corner Floor Lamp

Model: B0D5HB2SL7

Brand: EDISHINE

## INTRODUCTION

Thank you for choosing the EDISHINE Minimalist LED Corner Floor Lamp. This instruction manual provides important information for the safe and efficient operation of your new lamp. Please read it thoroughly before assembly and use, and retain it for future reference.

## PACKAGE CONTENTS

Ensure all components are present and undamaged before proceeding with assembly.

- LED Corner Floor Lamp (2 units)
- Remote Control (2 units, 1 AAA battery included per remote)
- Power Adapter (2 units)
- User Manual

## SETUP AND ASSEMBLY

The EDISHINE LED Corner Floor Lamp is designed for quick and easy assembly. No special tools are required.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Base:** Screw the lamp column securely onto the circular base. Ensure it is tightened to prevent wobbling.
3. **Connect Power:** Connect the power adapter to the lamp's power input, then plug the adapter into a standard electrical outlet.
4. **Position Lamp:** Place the lamp in your desired corner or location. The slim design allows for placement in tight spaces.



Figure 1: Attaching the lamp column to the base.



Figure 2: Lamp dimensions (57.5 inches tall, 7.8 inch base) and remote control layout.

## OPERATING INSTRUCTIONS

Your EDISHINE LED Corner Floor Lamp can be operated using the included RF-433 remote control or the integrated foot switch.

### Remote Control Functions

The RF-433 remote allows for convenient control from up to 49 feet away. Each lamp comes with its own remote.

- **Power On/Off:** Press the 'O' button to turn the lamp off, and the 'I' button to turn it on.
- **Brightness Adjustment:** Use the '+' and '-' buttons (sun icon) to increase or decrease brightness from 10% to 100%.
- **Color Temperature (CCT) Adjustment:** Use the '+' and '-' buttons (snowflake/sun icon) to cycle through 7 color temperatures, ranging from 2700K (warm white) to 6000K (cool white).
- **3 CCT Preset:** Press the '3 CCT' button (triangle icon) to quickly switch between three common color temperature presets.
- **Night Light Mode:** Press the 'Night Light Mode' button (moon icon) for a soft 30% brightness setting.
- **Memory Function:** The lamp remembers your last brightness and color temperature settings when turned off and on again.



Figure 3: Remote control layout and functions.

## RF-433 Remote Control

The remote allows you to adjust any mode you need without leaving your comfort seat



## Foot Step Switch

Free your waist and hands

Short Press: ON/OFF

Long Press: 10%-100% adjust the brightness




Figure 4: Using the remote control and the foot switch.

### Foot Switch Operation

The lamp also features a convenient foot switch located on the power cord.

- **Short Press:** Press briefly to turn the lamp On or Off.
- **Long Press:** Press and hold to adjust the brightness from 10% to 100%.



10%

25%

75%

100%

## Dimmable & Memory Function

Memorize the brightness you set before turning it off




Figure 5: Dimmable feature and memory function.



## 7 Color Temperature 2700K-6000K

2700K

6000K

Sleeping/2700K

Relaxing/4000K

Working/6000K

Figure 6: 7 Color Temperature options (2700K-6000K).

### KEY FEATURES

- **Adjustable Color Temperature (7 CCT):** Choose from 7 color temperatures, from 2700K warm light to 6000K cool light, to create the desired ambiance.
- **Dimmable (10-100%):** Adjust the brightness level to suit your activity or mood.
- **Eye Care & Stable Light:** The lamp provides a soft, stable, and glare-free light, designed to reduce eye strain.
- **RF-433 Remote Control:** Control the lamp wirelessly from a distance with the included remote, featuring

memory function for your last settings.

- **Space-Saving Minimalist Design:** Its sleek, tall, and slim profile (57.5" H x 7.8" W base) fits perfectly in corners without occupying much floor space.
- **Long-Lasting LED:** Integrated LED lights have a lifespan of over 30,000 hours, eliminating the need for bulb replacement.
- **Safe and Stable:** Features a heavy metal anti-tipping base for enhanced stability, making it safe for households with children and pets. The LED remains cool to the touch even after extended use.



Figure 7: Versatile placement in different room types.

## CARE AND MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** The LED light source is integrated and not user-replaceable. It is designed for long-term use.
- **Storage:** If storing the lamp, ensure it is clean and dry. Store in a cool, dry place away from direct sunlight.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Power cord not securely plugged in. No power from outlet.	Check power connections. Test outlet with another device.
Remote control not working.	Remote battery is dead or incorrectly inserted. Remote is too far from the lamp.	Replace the AAA battery in the remote. Ensure correct polarity. Move closer to the lamp.
Light flickers or is unstable.	Loose connection. Power supply issue.	Check all connections. Try plugging into a different outlet. If problem persists, contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	EDISHINE
Model	B0D5HB2SL7
Product Dimensions	7.8"D x 7.8"W x 57.5"H
Item Weight	8.38 Pounds
Material	Aluminum
Finish Type	Painted
Light Source Type	LED
Wattage	19 watts
Light Output Maximum	1100 Lumens
Color Temperature	2700K - 6000K (7 adjustable levels)
Dimming Range	10% - 100%
Control Method	Remote, Foot Switch

Feature	Detail
Indoor/Outdoor Usage	Indoor
Batteries Required	1 AAA (for remote, included)

## WARRANTY AND SUPPORT

EDISHINE products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official EDISHINE website. Please have your model number (B0D5HB2SL7) and purchase date ready when contacting support.