

- Manuals.plus /
- › **PERFASCIN** /
- › PERFASCIN AB32 Replacement Remote Control User Manual for ANTTEQ Smart TV AB24

PERFASCIN ATTEQ-1

PERFASCIN AB32 Replacement Remote Control User Manual

For ANTTEQ Smart TV Models AB32 & AB24

1. INTRODUCTION

This manual provides detailed instructions for the PERFASCIN AB32 Replacement Remote Control, model ATTEQ-1. This remote is specifically designed as a direct replacement for ANTTEQ Smart TV models AB32 and AB24, offering immediate functionality without the need for complex programming or pairing procedures.

2. PRODUCT OVERVIEW

The PERFASCIN AB32 remote control is an ergonomic, black-colored device crafted for comfortable handling and intuitive operation. It features a standard button layout, including numerical keys, navigation controls, and dedicated function keys for media playback and TV settings.



Image 1: Front view of the PERFASCIN AB32 Replacement Remote Control, displaying all buttons and their labels.



Image 2: Angled view of the remote control, highlighting its ergonomic design.



22 cm / 8.66 in



Image 3: Side-by-side view of the remote control, illustrating its approximate dimensions (22 cm / 8.66 inches in length and 5 cm / 1.97 inches in width).





280401010980



Image 4: Rear view of the remote control, showing the battery compartment cover.





Image 5: Rear view of the remote control with the battery compartment open, revealing the battery slots.

3. SETUP: BATTERY INSTALLATION

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Ensure batteries are inserted correctly to prevent damage to the remote control and ensure proper functionality.

4. OPERATING INSTRUCTIONS

4.1. Initial Use

This PERFASCIN AB32 replacement remote control requires **no programming or pairing**. Once batteries are correctly installed, it is ready for immediate use with compatible ANTTEQ Smart TV models AB32 and AB24.

4.2. Basic Functions

- **Power Button (Red):** Turns the TV on or off.
- **Number Buttons (0-9):** Selects channels directly.
- **Volume Up/Down (VOL +/-):** Adjusts the sound volume.
- **Channel Up/Down (CH +/-):** Changes TV channels sequentially.
- **Mute Button:** Silences the TV audio.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through on-screen menus and confirms selections.
- **Menu Button:** Accesses the TV's main menu.
- **Exit Button:** Exits current menu or function.
- **Source Button:** Selects input sources (HDMI, AV, etc.).

4.3. Advanced Functions

- **Media Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.
- **Aspect Button:** Adjusts screen aspect ratio.
- **Subtitle Button:** Toggles subtitles on/off.

- **EPG (Electronic Program Guide):** Displays program information.
- **Colored Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or applications, as indicated on screen.

5. COMPATIBILITY

This replacement remote control is compatible with the following ANTTEQ Smart TV models:

- **AB32**
- **AB24**

Note: While designed for these specific models, compatibility with other ANTTEQ Smart TV models may vary.

6. MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** Store the remote in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact to prevent internal damage.

7. TROUBLESHOOTING

7.1. Remote Control Not Responding

- **Check Batteries:** Ensure batteries are correctly inserted with the proper polarity (+/-). Replace old or depleted batteries with new ones.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the TV's infrared receiver. Remove any obstructions.
- **Distance:** Operate the remote within a reasonable distance from the TV.
- **Interference:** Strong light sources or other electronic devices might interfere with the remote's signal. Try using the remote in a different environment.

7.2. Specific Buttons Not Working

- **Clean Buttons:** Ensure buttons are not stuck or obstructed by debris.
- **Battery Check:** Even if some buttons work, low battery power can affect others. Replace batteries.

If troubleshooting steps do not resolve the issue, please refer to the "Warranty and Support" section for further assistance.

8. SPECIFICATIONS

Feature	Detail
Product Model	ATTEQ-1
Compatible TV Models	ANTTEQ Smart TV AB32, AB24

Brand	PERFASCIN
Product Dimensions	6 x 3 x 0.5 inches
Item Weight	2 ounces
Color	Black
Special Feature	Ergonomic
Max Number of Supported Devices	15
Compatible Devices	Television

9. WARRANTY AND SUPPORT

If you encounter any issues with your PERFASCIN AB32 Replacement Remote Control, such as damage upon receipt or malfunction, please contact the seller directly for assistance. The seller is committed to providing satisfactory solutions and support.

For questions regarding product compatibility or operational concerns, it is recommended to reach out to the seller online. They will endeavor to resolve any problems and provide a satisfactory response.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D5HKCH2F>

More documents and user manuals: <https://manuals.plus/>