

[Manuals.plus](#) /

› [wellent](#) /

› wellent LED Foam Glow Sticks (130 PCS, Model TX-017) - Instruction Manual

wellent TX-017

wellent LED Foam Glow Sticks (130 PCS, Model TX-017) - Instruction Manual

Your guide to setting up, operating, and maintaining your wellent LED Foam Glow Sticks.

INTRODUCTION

The wellent LED Foam Glow Sticks are designed to enhance various events and celebrations with vibrant, colorful lighting. Each stick features three distinct flashing modes and is made from soft, durable foam for safe and enjoyable use. This manual provides essential information for proper setup, operation, and care of your glow sticks.

Fun Glow In The Dark Party Supplies



Figure 1: wellent LED Foam Glow Sticks illuminating a lively event.

1. SETUP

Your wellent LED Foam Glow Sticks come with pre-installed batteries. To activate them for the first time, you need to remove the insulating tab.

1. **Locate the Battery Compartment:** At one end of each foam glow stick, you will find a small plastic cap covering the battery compartment.
2. **Remove the Insulating Tab:** Gently pull out the small plastic insulating tab protruding from the battery compartment. This tab prevents battery drain during storage.
3. **Test Activation:** Press the small button located on the end of the stick (near where the tab was removed) to ensure the lights activate.



Figure 2: Removing the insulating tab to activate the glow stick.

Your browser does not support the video tag.

Video 1: A short demonstration showing how to activate the LED Foam Glow Stick by removing the battery tab and cycling through its light modes.

2. OPERATING INSTRUCTIONS

The wellent LED Foam Glow Sticks feature three distinct lighting modes to suit various atmospheres.

1. **Power On:** After removing the insulating tab (as described in Setup), press the small button on the end of the stick to turn it on.
2. **Change Modes:** Each subsequent press of the button will cycle through the available lighting modes:
 - **Fast Flashing:** Rapid, dynamic light changes.
 - **Slow Flashing:** Gradual, rhythmic light changes.
 - **Alternating Flashing (Forever Bright):** A continuous, vibrant display of blue, red, and green colors.

3. **Power Off:** Continue pressing the button until the lights turn off, or hold the button for a few seconds to power down.



Figure 3: The three distinct flashing modes of the LED Foam Glow Sticks.

Your browser does not support the video tag.

Video 2: A demonstration of the wellent LED Foam Glow Sticks in action, showcasing their various light modes and vibrant colors at an event.

3. MAINTENANCE

To ensure the longevity and optimal performance of your wellent LED Foam Glow Sticks, follow these maintenance guidelines:

- **Storage:** When not in use, turn off the glow sticks to conserve battery life. Store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** Wipe the foam sticks with a soft, damp cloth if they become dirty. Do not submerge them in water or use harsh cleaning agents.
- **Battery Replacement:** The glow sticks are equipped with long-lasting batteries. If the lights dim or stop working, the

batteries may need to be replaced. To replace, carefully open the battery compartment (usually by unscrewing a small cap or prying open a tab) and insert new batteries of the correct type. Ensure proper polarity.

- **Handling:** While the foam is soft and bendable, avoid excessive force or sharp objects that could damage the internal electronics.



Figure 4: The soft and bendable foam material ensures durability and safety.

4. TROUBLESHOOTING

If your wellent LED Foam Glow Sticks are not functioning as expected, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Glow stick does not light up.	Insulating tab still in place.	Ensure the plastic insulating tab has been completely removed from the battery compartment.

Problem	Possible Cause	Solution
Glow stick does not light up.	Depleted batteries.	Replace the batteries with new ones, ensuring correct polarity.
Lights are dim or inconsistent.	Low battery power.	Replace the batteries.
Button is unresponsive.	Internal connection issue or button malfunction.	Ensure the battery compartment is securely closed. If the issue persists, contact customer support.

5. SPECIFICATIONS

- **Brand:** wellent
- **Model Number:** TX-017
- **Quantity:** 130 Pieces
- **Material:** Foam
- **Light Modes:** Fast Flashing, Slow Flashing, Alternating Flashing (Blue, Red, Green)
- **Item Dimensions (L x W x H):** 1 x 1 x 1 inches (per stick, as per manufacturer data)
- **Item Weight:** 4.59 pounds (total package weight)
- **Recommended Age:** 3 years and up
- **Power Source:** 3 long-lasting batteries per stick

6. SUPPORT

wellent is committed to customer satisfaction. If you encounter any issues or have questions regarding your LED Foam Glow Sticks, please do not hesitate to contact our customer service team. We are dedicated to providing prompt and helpful after-sales service.

For assistance, please visit the [wellent Store on Amazon](#) or refer to your purchase documentation for direct contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D5HMFJ1D>

More documents and user manuals: <https://manuals.plus/>