Stokke 650103

Stokke Tripp Trapp Baby Set 2 Instruction Manual

Model: 650103 | Brand: Stokke

1. Introduction

The Stokke Tripp Trapp Baby Set 2 is designed to convert your Tripp Trapp Chair (sold separately) into a comfortable and secure high chair for infants and toddlers aged 6 to 36 months. This set provides essential side and back support, allowing your child to sit safely and comfortably at the family table.

This manual provides detailed instructions for the assembly, use, and maintenance of your Tripp Trapp Baby Set 2. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Stokke Tripp Trapp Baby Set 2 in white, shown with the included harness, ready for installation onto a Tripp Trapp chair frame (chair frame is outlined in grey).

2. Important Safety Information

WARNING: Failure to follow these instructions could result in serious injury or death.

- Always use the 5-point harness to secure your child in the Baby Set.
- Never leave your child unattended in the high chair.
- Ensure the Baby Set is correctly and securely attached to the Tripp Trapp Chair before placing your child in it.
- The maximum weight recommendation for the Baby Set is 33 pounds (approximately 6-36 months).
- Keep children away from the product during assembly.
- Regularly check all components for wear, damage, or loose parts. Discontinue use if any part is damaged.

- Do not use accessories or replacement parts other than those approved by Stokke.

3. What's Included

Your Stokke Tripp Trapp Baby Set 2 package includes the following components:

1. **Baby Set Backrest:** Provides side and back support.
2. **Baby Set Rail:** Forms the front and side barrier.
3. **Stokke Harness²:** A redesigned five-point safety harness.
4. **Extended Gliders:** For enhanced stability of the Tripp Trapp Chair when the Baby Set is in use.




Image: An exploded view showing the individual components of the Baby Set 2: (1) Baby Set backrest with harness, (2) Baby Set rail, and (3) Extended gliders. The harness is labeled as (4) Tripp Trapp Harness.

4. Setup and Installation

The Baby Set 2 is designed for tool-free attachment to the Tripp Trapp Chair. Ensure your Tripp Trapp Chair is assembled according to its own instruction manual before installing the Baby Set.

4.1. Installing the Extended Gliders

1. Locate the two extended gliders.
2. Slide each extended glider onto the bottom of the Tripp Trapp Chair's runners until they click securely into place. These gliders increase stability and are essential for safe use with the Baby Set.

4.2. Attaching the Baby Set Backrest

1. Ensure the Tripp Trapp Chair's backrest is in the correct position for infant use (usually the highest slot).
2. Align the Baby Set backrest with the top of the Tripp Trapp Chair's backrest.
3. Slide the Baby Set backrest downwards onto the chair's backrest until it is firmly seated.

4.3. Attaching the Baby Set Rail

1. Position the Baby Set rail over the seat plate of the Tripp Trapp Chair.
2. Ensure the rail's side clips align with the grooves on the chair's side rails.
3. Press down firmly until the Baby Set rail clicks into place on both sides. Verify it is securely fastened and does not wobble.

4.4. Installing the Stokke Harness²

The Stokke Harness² is pre-threaded into the Baby Set backrest. If it needs re-threading or adjustment:

1. Thread the shoulder straps through the two new notches located on the back of the Baby Set 2 backrest.
2. Ensure the waist straps pass through the designated slots on the Baby Set rail.
3. Connect all straps to the central buckle.



Image: A close-up of the Stokke Tripp Trapp Baby Set 2 installed on a chair, highlighting its easy assembly without tools, soft and easy-to-clean textile, and the quick-release button on the harness.

5. Operating Instructions

5.1. Placing Your Child in the Baby Set

1. Ensure the Baby Set is securely installed on the Tripp Trapp Chair.
2. Carefully place your child into the Baby Set.

5.2. Securing the Harness

1. Bring the shoulder straps over your child's shoulders and the waist straps around their waist.
2. Connect all five points of the harness into the central buckle until you hear a click.

3. Adjust the straps to ensure a snug but comfortable fit. The harness should be tight enough so that you cannot fit more than one finger between the strap and your child's body.

5.3. Releasing the Harness

1. Press the quick-release button on the central buckle. All five points will release simultaneously.
2. Loosen the straps and carefully remove your child from the Baby Set.



Image: A baby happily seated in a Stokke Tripp Trapp chair with the Baby Set 2, illustrating key features such as the 5-point safety harness, back and side support, 90-degree angle for optimal ergonomics, and spacious leg room.

6. Adjustments

The Tripp Trapp Chair, in conjunction with the Baby Set, offers adjustability to ensure ergonomic seating for your growing child.

6.1. Adjusting Seat and Footrest

- For optimal ergonomics, ensure your child's elbows are at table height and their feet are supported by the footrest.
- Adjust the height and depth of the seat plate and footrest of the Tripp Trapp Chair as your child grows. Refer to the Tripp Trapp Chair manual for detailed adjustment instructions.

6.2. Removing the Baby Set

Once your child outgrows the Baby Set (typically around 36 months or when they can climb in and out of the chair independently), it can be removed to allow continued use of the Tripp Trapp Chair.

1. First, remove your child from the Baby Set.
2. Unclip the Baby Set rail by pressing the side clips and lifting it upwards.
3. Slide the Baby Set backrest upwards to detach it from the chair's backrest.
4. Remove the extended gliders from the chair's runners.

7. Care and Maintenance

7.1. Cleaning

- Wipe the plastic components of the Baby Set with a damp cloth. A mild soap solution can be used for stubborn stains.
- Ensure all parts are dry before reassembly or storage.
- The harness straps can be hand-washed with mild soap and water. Allow to air dry completely.
- Avoid using abrasive cleaners or solvents, as these can damage the materials.

7.2. Storage

Store the Baby Set in a clean, dry place away from direct sunlight and extreme temperatures when not in use.

8. Troubleshooting

Problem	Possible Cause	Solution
Baby Set does not fit securely.	Incorrect alignment or insufficient pressure during installation.	Ensure the Baby Set backrest and rail are aligned correctly with the chair's components and pressed firmly until they click into place. Refer to Section 4.
Harness is difficult to adjust or release.	Straps may be twisted or buckle mechanism is obstructed.	Untwist straps and ensure no fabric is caught in the buckle. Press the quick-release button firmly. If issues persist, check for damage.

Problem	Possible Cause	Solution
Chair feels unstable with Baby Set installed.	Extended gliders are not installed or not installed correctly.	Always install the extended gliders when using the Baby Set. Ensure they are fully pushed onto the chair's runners until they click.

9. Specifications

- **Product Dimensions:** 16.5 x 8.3 x 10.6 inches (41.9 x 21.1 x 26.9 cm)
- **Item Model Number:** 650103
- **Maximum Weight Recommendation:** 33 Pounds (15 kg)
- **Recommended Age:** 6-36 Months
- **Material Type:** Plastic (Baby Set), Wood (Tripp Trapp Chair - sold separately)
- **Item Weight:** 1.3 pounds (0.59 kg)
- **Color:** White
- **Is Portable:** Yes (when detached)

10. Warranty and Support

For information regarding product warranty, spare parts, or customer support, please visit the official Stokke website or contact your local Stokke retailer. Keep your proof of purchase for warranty claims.

Online Resources: For additional assembly videos, FAQs, and product registration, please visitwww.stokke.com.

© 2025 Stokke AS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question